


# 7. SCHEMATIC DIAGRAM AND PARTS LOCATION (Pattern side)



0751, 0752	HT4150B0A0	250150B	VC80: 30V PC: 1.2V
0757, 0758	HT420331E0	25B2033 E	VC80: 120V PC: 1.0W
0759, 0760	HT213531E0	25B1353 E	VC80: -120V PC: 1.0W
0761, 0762	HT331B22C3	25C31B2	VC80: 140V PC: 100W IC: 10A
0763, 0764	HT112652C3	25A1265	VC80: -140V PC: 100W IC: -10A
0801	HT348B32A0	25C48B3	D.Y
0802	HT118592A0	25A1859	D.Y
0755, 0754	HT322402A0	25C2240	DR. BL
0701, 0702	HT109702A0	25A970	DR. BL
0803	HT20002001	15S176, MA145, 15S254	
0703, 0704	HT118592A0	25A1859	D.Y
0801	HT20015292	54V8-20	
0802	HT200029051	954880	VR: 400V IF: 1A

SOURCE DIRECT  
TONE DEFEAT  
ASW

