


LEFT CHANNEL

- P.B. TAPE-1
- REC
- AUX
- PHONO
- TUNER
- MIC
- TAPE-2
- OUT
- TAPE-2
- IN
- RIGHT CHANNEL**
- MIC
- PHONO
- AUX
- REC
- TAPE-1
- P.B.



Resistance values are indicated in ohms unless otherwise specified.
 (1,000 M=1,000,000).
 Resistance values are shown in brackets unless otherwise noted (micro-microfarads).
 Tapes are measured with respect to case ground in No signal.

- SW-1 SELECTOR**
1. MIC
 2. PHONO 2
 3. PHONO 1
 4. AUX
 5. TAPE-1
 6. TAPE-2
 7. MONO

- SW-5 LOUDNESS**
1. -20dB
 2. 0dB
 3. OFF
 4. M + R
 5. QUADRO

- SW-8 VU LEVEL**
1. -20dB
 2. 0dB
 3. OFF

- SW-9 POWER**
1. OFF
 2. MAIN
 3. REMOTE
 4. M + R
 5. QUADRO

