

---

---

## **Circuit Change**

---

---

***PROBLEM:*** Unit turns on briefly and then goes into protection mode.

---

***CAUSE:*** Power supply connector J781A on the main power supply board is making intermittent contact.

---

***SOLUTION:*** Unplug the connector, clean pins with a deoxidizing cleaner and reconnect J781A. Test unit, leave on for 3-5 minutes. If protection mode still occurs then check the power supply or amplifiers for the fault.

---

**Contact:**

**NAD Electronics International  
633 Granite Court  
Pickering, ON Canada L1K 3K1  
Voice: 905-831-0799 FAX 905-837-6357  
[www.nadelectronics.com](http://www.nadelectronics.com)**

03/28/03