


Oszillator- und Bandfilter-Anschlüsse (Ansicht Kaschierungsseite)



AM-Eingang					AM-Spulensatz										FM-Eingang					UKW-Baustein																			
1	2	3	4	5	13	21	22	23	24	25	41	42	43	44	45	46	47	48	49	50	51	52	53	54	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70
C																																							
R																																							
L																																							

UKW-Baustein					BF II					BF III					BF IV					BF V					ZF-Stufe														
71	72	73	74	75	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115
C																																							
R																																							
L																																							

ZF-Stufe					NF-Stufe										NF-Gegenläufstufen										Stromversorgung														
116	117	118	119	120	121	122	123	124	125	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	181	182	183	184	185	186	187	188	189	190	196	197	198	199	200
C																																							
R																																							
L																																							

Spannungsangaben bei [FM] bei [AM] gemessen mit Instrument 50000Ω/V im 10V Bereich gegen Masse ohne Eingangssignal. Batteriespannung dabei U<sub>B</sub> = 9Voll.

