Numark®

Service Information

DM1820X
(DM1835X)
(DM1885X)

www.numark.com

DM1820/DM1835/DM1885 SCHEMATIC DIAGRAM




MIC SEND L.
MIC SEND R.
DJ MIC
DJ MIC IN
SAMPLER IN
SAMPLER CUE IN
CUE CROSSFADER
MASTER OUT
REC OUT
ZONE1 OUT
ZONE2 OUT
SEND OUT
BAL. L.OUT
BAL. R.OUT
H/P OUT
POWER TRANSFORMER
VOLTAGE SW
POWER SW
FUSE 0.5A
AC IN 115V 60HZ 230V 50HZ
TO 12V LAMP
MAIN PCB