



TRANSISTOR CONNECTION (BOTTOM VIEW)

H801-852 HD2000601 U11C	H802-805 HT403314A 2SD331C,D,E,F	H803-804 HT309452A 2SC945 Qor R
H804-807, 809, 810 HD2000413 S18-01-02	H808 HD3002309 W Z 071	H811 HV0000110 RV

ALL SWITCHES VIEWED FROM FRONT AND SHOWN IN EXTREME CLOCKWISE POSITION SOO PHONO, SOO2 MONO, AND SOO3 REMOTE

PHONO TUNER TAPE 1 TAPE 2 2-CH DISCRETE PHONO AUX MONO MARI-MATRIX SO-DECODER
 HO01 HO02 HO03 HO04 HO05 HO06 HO07 HO08
 REMOTE LOCAL
 REMOTE CONTROL POSITION