

Service Manual

AV Control Receiver



SA-XR15E
SA-XR15EB
SA-XR15EG

Color

(S) Silver Type

(K) Black Type

Subject : Correction in Disassembly and Main component Replacement
Procedures & Operational checks

Please use this supplement manual together with the service manual for Model No. [SA-XR15EEBEG-SK,
 Order No. MD0305192C2].

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

CONTENTS

	Page
1 Disassembly and Main component Replacement Procedures and Operational check (Correction)	2

Panasonic


© 2003 PANASONIC AVC Networks Singapore Pte.
 Ltd. All rights reserved. Unauthorized copying and
 distribution is a violation of law.

1 Disassembly and Main component Replacement Procedures and Operational check (Correction)

Please refer to 8.1 Checking for the Main PCB and DSP PCB at page 10 and 11.


BEFORE

- Check the DSP P.C.B. (B side) and main P.C.B. as shown below.



AFTER

- Check the DSP P.C.B. (B side) and main P.C.B. as shown below.



NOTE: Please use the following tools for checking of DSP P.C.B.

Extension cable	
CN1002	JGS0098 (26pin)
CN1003	RFKZ0097 (10pin)