

Service Manual

Portable CD Player

SL-S145



DIGITAL

MASH[®]
multi-stage noise shaping



Colour

(H)...Gray Type

Area

Suffix for Model No.	Area	Colour
(P)	U.S.A.	(H)
(PC)	Canada.	

※ ● MASH is a trademark of NTT.

Please file and use this manual together with the service manual for Model No. SL-S140, Order No. AD9601012C1.

Note: ● This simplified service manual is provided to indicate the main differences between the original model No. SL-S140 (P) and the subsequent model No. SL-S145 (P, PC).

CHANGES


■ SUPPLY OF RECHARGEABLE BATTERY AS REPLACEMENT PARTS

Please take note of the following points relating to Carrying Case to be used for protection of Rechargeable Battery from shorting.

Replacement Parts:


- Rechargeable Battery (RP-BP60PYS) to be supplied will be provided with Carrying Case (RFKNLS370-K).
- No replacement parts will be supplied for Rechargeable Battery without Carrying Case.
- Replacement parts will be supplied for Carrying Case (RFKNLS370-K) without Rechargeable Battery.
- To your customers, delivery Rechargeable Battery together with Carrying Case to prevent shorting accidents that may occur when Rechargeable Battery is carried about without Carrying Case.

RP-BP60PYS
(Rechargeable Battery with Carrying Case)



RFKNLS370-K
(Carrying Case)

(OPEN)



■ CAUTION IN USE OF RECHARGEABLE BATTERY

- Take Rechargeable Battery out of Carrying Case and use it.
- Be sure to carry Rechargeable Battery in this Carrying Case.
If not, it may either heat or ignite by shorting with a metal.

⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

Panasonic[®]

© 1996 Matsushita Electric Industrial Co., Ltd.
All rights reserved. Unauthorized copying and distribution is a violation of law.

CHANGE IN REPLACEMENT PARTS LIST (SL-S140 Service Manual of pages 28, 30, 31.)

- Notes:**
- Mentioned in this parts list is only those different from Model No. SL-S140 (P).
 - All other parts are the same as for SL-S140 (P).
 - Important safety notice:


Components identified by Δ mark have special characteristics important for safety. Furthermore, special parts which have purposes of fire-retardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used. When replacing any of components, be sure to use only manufacturer's specified parts shown in the parts list.

Ref. No.	Change of Part No.		Part Name & Description	Remarks
	SL-S140 (P)	SL-S145 (P, PC)		
CABINET AND CHASSIS				
5	RFKJLS140P-K	RFKJLS145P-H	BOTTOM CABINET ASS'Y	
7	RYF0422-K	RYF0422E-H	CD COVER ASS'Y	
9	RGU1368-K	RGU1368-H	OPERATION BUTTON (A)	
10	RGU1369-K	RGU1369-H	OPERATION BUTTON (B)	
12	RFKCLS140P-K	RFKCLS145P-H	INTERMEDIATE CABINET ASS'Y	
PACKING MATERIAL				
P1	RPK0714	RPK0734	PACKING CASE	(P)
		RPK0737	PACKING CASE	(PC)
P2	RPQ0593	RPQ0593	SPACER	(P)
		RPQ0639	SPACER	(PC) Addition
P4	—	—	—	(P)
		RPF0046	PROTECTION BAG (F.B.)	(PC) Addition
ACCESSORIES				
A1	RQT3354-P	RQT3354-P	INSTRUCTION MANUAL	(P) ※1
		RFKSLS140PCK	INSTRUCTION MANUAL ASS'Y	(PC)
A2	RFEA405C-1W	RFEA403C-S	AC ADAPTOR	Δ
A3	RPHT103DPYS1	RPHT103DPYS1	STEREO HEADPHONES	(P)
		RFEV310P-K1S	STEREO EARPHONES	(PC)
A4	—	—	—	(P)
		SQX7185	WARRANTY CARD	(PC) Addition
A5	—	—	—	(P)
		SQX9131	SERVICENTER LIST	(PC) Addition
A6	—	—	—	(P)
		RKB205ZA-0	EAR PADS	(PC) Addition ※2
A7	—	RP-BP60PYS	RECHARGEABLE BATTERIES	Addition
A7-1	—	RFKNLS370-K	BATTERY CARRYING CASE	Addition


※1: The customer service list and the warranty are included in the instruction manual.
 ※2: This parts is supplied only with replacement parts list.

PACKAGING

• For (P) area.



• For (PC) area.



Printed in Japan
 H960203350NH/HH