Service Manual



Potable CD Player SL-S235

Colour

(S) Sliver Type

Area

(P) U.S.A.

Please file and use this manual together with the service manual for Model No. SL-S230. Order No. AD9803046C1.

Notes: • This simplified service manual is provided to indicate the differences between the original No. SL-S230 (P) and the subsequent model No. SL-S235 (P).

MASH multi-stage noise shaping

MASH is a trademark of NTT.

■ Replacement Parts List

Notes: • Important safety notice:

Components identified by A mark have special characteristics important for safety.

When replacing any of components, be sure to use only manufacture's specified parts shown in the parts list.

All parts are supplied by MESA.

Ref. No.	Change of Parts No.		Doub Name & Description	Domorto
	SL-S230	SL-S235	Part Name & Description	Remarks
CABINET PAF	RTS			•
1	RFKJLS230P-S	RFKJLS235P-S	BOTTOM CABINET ASS'Y	CHANGE
7	RYF0460-S	RYF0460D-S	CD COVER ASS'Y	CHANGE
11	RSL5203-C	EDD052CK7A4P	LCD	CHANGE
PACKING MA	TERIALS			
P3	RPQ0850	RPQ0877	GROUND PAPER	CHANGE
P4		RPQ0855	SPACER	ADDITION
ACCESSORIE	ES .			
A4 A		RP-BP60PYS	RECHARGEABLE BATTERY	ADDITION
A4-1		RXQ0449	BATTERY CASE	ADDITION

AWARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.



© 1998 Matsushita Electric Industrial Co., Ltd. All rights reserved. Unauthorized copying and distribution is a violation of law.

Packaging

