ervice Manu



DIGIT/IL MASH*

Portable CD Player

SL-S238

Colour

(K)...Black Type

Areas

Suffix for Model No.	Area	Colour
(E)	Europe.	(K)

MASH is a trademark of NTT.

Please file and use this manual together with the service manual for Model No. SL-XP240, Order No. AD9604095C8.

Note: ● This simplified service manual is provided to indicate the main differences between the original model No. SL-XP240 (E) and the subsequent model No. SL-S238 (E).

CHANGES

■ CHANGE IN REPLACEMENT PARTS LIST (SL-XP240 Service Manual of pages 32, 35.)

Notes: • Mentioned in this parts list is only those different from Model No. SL-XP240 (E). All other parts are the same as for SL-XP240 (E).

Ref. No.	Change of Part No.		Dad Name & David H	
nei. No.	SL-XP240(E) ■	SL-S238(E)	Part Name & Description	Remarks
CABINET A	ND CHASSIS			
5	RFKJLXP240EK	RFKJLS238E-K	BOTTOM CABINET ASS'Y	
7	RYF0402F-K	RYF0402E-K	CD COVER ASS'Y	
PACKING	MATERIAL			
P1	RPK0752	RPK0788	PACKING CASE	
P2	RPQ0660	RPQ0639	SPACER	, , , , , , , , , , , , , , , , , , , ,
ACCESSO	RIES			
A1	RFKSLXP240EK	RFKSLS238E-K	INSTRUCTION MANUAL ASS'Y	
A2	RFEA401E-2S			Deletion
A5 .	RFEV317A-KS	RFEV317P-KS	STEREO EARPHONES	
A8	RP-BP60EYS1			Deletion
A8-1	RFKNLS370-K	-		Deletion

△ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

anasonic

© 1996 Matsushita Electric Industrial Co., Ltd. All rights reserved. Unauthorized copying and distribution is a violation of law.