

Service Manual

Portable CD Player



SL-SV570EB
SL-SV570EG
SL-SV570GN
SL-SV572GC
SL-SV572GS
SL-SV570P
SL-SV570PC

Colour

(S).....Silver Type

Subject : Note for replacement of open knob

Please use this supplement manual together with the service manual for Model No. SL-SV570EB, SL-SV570EG, SL-SV570GN, SL-SV572GC, SL-SV572GS, Order No. AD0403024C8 and SL-SV570P, SL-SV570PC, Order No. AD0402023C1.

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

CONTENTS

Page

1 Replacement Parts List 1

1 Replacement Parts List

Ref.No.	Change of Parts No.		Part Name & Description	Pcs	Remarks
	Original	Supplement			
Cabinet Parts					
19	RGV0318-H	RGV0318H-KIT	KNOB & LOCK PLATE KIT	1	(EB/EG/GN)
19	RGV0318-H3	RGV0318H-KIT	KNOB & LOCK PLATE KIT	1	(GC/GS)
19	RGV0318-H2	RGV0318H-KIT	KNOB & LOCK PLATE KIT	1	(P/PC)
22	RMR1412-K1	RGV0318H-KIT	KNOB & LOCK PLATE KIT	1	

• When the open knob and lock plate as shown above is replaced, they are replaced simultaneously as a **KNOB & LOCK PLATE KIT (RGV0318H-KIT)** .

Panasonic

© 2004 Matsushita Electric Industrial Co., Ltd. All rights reserved. Unauthorized copying and distribution is a violation of law.