

# Service Manual

Portable CD Player

**COMPACT**  
**disc**  
**DIGITAL AUDIO**

**DIGITAL**

**MASH**  
multi-stage noise shaping

## SL-SW202



**Colour**

(Y)...Yellow Type

**Area**

Suffix for Model No.	Area	Colour
(P)	U.S.A.	(Y)
(PC)	Canada.	

※ • MASH is a trademark of NTT.

Please file and use this manual together with the service manual for Model No. SL-SW404, Order No. AD9603058C1.

**Note:** • This simplified service manual is provided to indicate the main differences between the original model No. SL-SW404 (P) and the subsequent model No. SL-SW202 (P, PC).

## CHANGES

### ■ LOCATION OF CONTROLS (SL-SW404 Service Manual of page 2.)

SL-SW404 (P)

SL-SW202 (P, PC)

⑪ Extra anti-shock switch  
(EXTRA ANTI-SHOCK)



⑪ Anti-shock switch  
(ANTI-SHOCK)

### ⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

# Panasonic®

© 1996 Matsushita Electric Industrial Co., Ltd.  
All rights reserved. Unauthorized copying and distribution is a violation of law.

# **CHANGE IN REPLACEMENT PARTS LIST (SL-SW404 Service Manual of pages 33, 35, 36.)**

**Note:** • Mentioned in this parts list is only those different from Model No. SL-SW404 (P) for yellow type.  
All other parts are the same as for SL-SW404 (P) for yellow type.

Ref. No.	Change of Part No.		Part Name & Description	Remarks
	SL-SW404 (P)	SL-SW202 (P, PC)		
INTEGRATED CIRCUIT(S)				
IC503	MN41440CSJ7T	LH6456K2	1 M DRAM	
CHIP JUMPER				
RJ502	ERJ6GEY0R00V	—	—	Deletion
CABINET AND CHASSIS				
5	RFKJLSW404PY	RFKJLSW202PY	BOTTOM CABINET ASS'Y	
6	RFKLLSW404PY	RFKLLSW202PY	CD COVER ASS'Y	
PACKING MATERIAL				
P1	RPK0751	RPK0782	PACKING CASE	(P)
		RPK0786	PACKING CASE	(PC)
ACCESSORIES				
A1	RQT3378-P	RQT3378-P	INSTRUCTION MANUAL	(P)
		RFKSLSW404PC	INSTRUCTION MANUAL ASS'Y	(PC)
A4	RQA0113	RQA0113	WARRANTY CARD	(P)
		SQX7185	WARRANTY CARD	(PC)
A5	RQX9028ZD	RQX9028ZD	SERVICENTER LIST	(P)
		SQX9131	SERVICENTER LIST	(PC)

**Note:** This section where part (CHIP JUMPER) have been removed from is open.