

Service Manual

COMPACT
disc
DIGITAL AUDIO

DIGITAL

MASH
multi-stage noise shaping

Portable CD Player

SL-XP145

Colour

(K)...Black Type



Area

Suffix for Model No.	Area	Colour
(E)	Europe.	(K)
(EG)	Germany and Italy.	

※ ● MASH is a trademark of NTT.

Please file and use this manual together with the service manual for Model No. SL-XP140, Order No. AD9603057C8.

Note: ● This simplified service manual is provided to indicate the main differences between the original model No. SL-XP140 (E) and the subsequent model No. SL-XP145 (E, EG).

CHANGES


■ SUPPLY OF RECHARGEABLE BATTERY AS REPLACEMENT PARTS

Please take note of the following points relating to Carrying Case to be used for protection of Rechargeable Battery from shorting.


Replacement Parts:

- Rechargeable Battery (RP-BP60EYS1) to be supplied will be provided with Carrying Case (RFKNLS370-K).
- No replacement parts will be supplied for Rechargeable Battery without Carrying Case.
- Replacement parts will be supplied for Carrying Case (RFKNLS370-K) without Rechargeable Battery.
- To your customers, delivery Rechargeable Battery together with Carrying Case to prevent shorting accidents that may occur when Rechargeable Battery is carried about without Carrying Case.

RP-BP60EYS1
(Rechargeable Battery with Carrying Case)



RFKNLS370-K
(Carrying Case)



■ CAUTION IN USE OF RECHARGEABLE BATTERY

- Take Rechargeable Battery out of Carrying Case and use it.
 - Be sure to carry Rechargeable Battery in this Carrying Case.
- If not, it may either heat or ignite by shorting with a metal.

⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

Technics®

© 1996 Matsushita Electric Industrial Co., Ltd.
All rights reserved. Unauthorized copying and distribution is a violation of law.

CHANGE IN REPLACEMENT PARTS LIST (SL-XP140 Service Manual of pages 28, 30, 31.)

Notes: • Mentioned in this parts list is only those different from Model No. SL-XP140 (E).
All other parts are the same as for SL-XP140 (E).

Ref. No.	Change of Part No.		Part Name & Description	Remarks
	SL-XP140 (E)	SL-XP145 (E, EG)		
CABINET AND CHASSIS				
5	RFKJLXP140EK	RFKJLXP145EK	BOTTOM CABINET ASS'Y	
7	RYF0422C-K	RYF0422F-K	CD COVER ASS'Y	
PACKING MATERIAL				
P1	RPK0739	RPK0741	PACKING CASE	
P5	SQZD3	SQZD3	AREA LABEL	(E)
		SQZD6	AREA LABEL	(EG)
ACCESSORIES				
A1	RFKSLXP140EK	RFKSLXP140EK	INSTRUCTION MANUAL ASS'Y	(E)
		RFKSLXP140EG	INSTRUCTION MANUAL ASS'Y	(EG)
A8	—	RP-BP60EYS1	RECHARGEABLE BATTERY	Addition
A8-1	—	RFKNLS370-K	R. BATTERY CARRYING CASE	Addition

PACKAGING (SL-XP140 Service Manual of page 32.)

