

# Pioneer

## Service Manual

ORDER NO.  
**RRV4378**

MULTI PLAYER

# CDJ-850-W

**THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).**

Model	Type	Power Requirement	Remarks
CDJ-850-W	SYXJ8	AC 220 V to 240 V	
CDJ-850-W	UXJCB	AC 120 V	
CDJ-850-W	FLXJ	AC 110 V to 240 V	
CDJ-850-W	AXJ5	AC 220 V to 240 V	

**This service manual should be used together with the following manual(s).**

Model No.	Order No.	Remarks
CDJ-850/SYXJ8	RRV4128	CDJ-850/CUXJ, /FLXJ, /AXJ5

**Descriptions to be written in the Service Manual for the CDJ-850-W**

**This product is the same as the CDJ-850, except for the colors.**

**The major changes are as shown below.**

**Exterior panels (control panel, chassis and JOG): Changed to white**

**When replacing the above-mentioned parts, be sure to use the parts described in this manual.**

**PIONEER CORPORATION** 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan

**PIONEER ELECTRONICS (USA) INC.** P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.

**PIONEER EUROPE NV** Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

**PIONEER ELECTRONICS ASIACENTRE PTE. LTD.** 253 Alexandra Road, #04-01, Singapore 159936

©PIONEER CORPORATION 2012

K-ZZZ SEPT. 2012 Printed in Japan

1 2 3 4

# 1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

● The  $\triangle$  mark found on some component parts indicates the importance of the safety factor of the part.

Therefore, when replacing, be sure to use parts of identical designation.

● Screws adjacent to  $\nabla$  mark on product are used for disassembly.

● For the applying amount of lubricants or glue, follow the instructions in this manual.

(In the case of no amount instructions, apply as you think it appropriate.)

● Nos. indicate the pages and Nos. in the service manual for the base model.

● When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

560Ω → 56 x 10<sup>1</sup> → 561 ..... RD1/4PU5 6 1 J  
 47kΩ → 47 x 10<sup>3</sup> → 473 ..... RD1/4PU4 7 3 J  
 0.5Ω → R50 ..... RN2HR5 0 K  
 1Ω → 1R0 ..... RS1P 1 R 0 K

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

5.62kΩ → 562 x 10<sup>1</sup> → 5621 ..... RN1/4PC 5 6 2 1 F

## CONTRAST TABLE

### CDJ-850-W/SYXJ8

CDJ-850/SYXJ8 and CDJ-850-W/SYXJ8 are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-850/SYXJ8	CDJ-850-W/SYXJ8	Remarks
		<b>PACKING SECTION</b>			
NSP	P57-24	Packing Case	DHG3075	DHG3190	
		Label/B	Not used	DRW2525	
		Label/IM1	Not used	DRW2534	
		<b>EXTERIOR SECION</b>			
$\triangle$	P59-21	Chassis	DNK5785	DNK6178	
		<b>CONTROL PANEL SECTION</b>			
	P61-29	Slide Sheet 1C	DAH2404	DAH2897	
$\triangle$	P61-36	Control Panel	DNK5786	DNK6176	
		<b>JOG DIAL SECTION</b>			
	P63-6	JOG Plate	DAH2839	DAH2898	
	P63-14	JOG B	DNK4068	DNK6135	

### CDJ-850-W/UXJCB

CDJ-850/CUXJ and CDJ-850-W/UXJCB are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-850/CUXJ	CDJ-850-W/UXJCB	Remarks
		<b>PACKING SECTION</b>			
	P57-9	Operating Instructions (En/Fr)	DRB1526	DRB1645	
	P57-24	Packing Case	DHG3072	DHG3189	
		<b>EXTERIOR SECION</b>			
$\triangle$	P59-21	Chassis	DNK5819	DNK6177	
		<b>CONTROL PANEL SECTION</b>			
	P61-29	Slide Sheet 1C	DAH2404	DAH2897	
$\triangle$	P61-36	Control Panel	DNK5786	DNK6176	
		<b>JOG DIAL SECTION</b>			
	P63-6	JOG Plate	DAH2839	DAH2898	
	P63-14	JOG B	DNK4068	DNK6135	

2

CDJ-850-W

1 2 3 4

**CDJ-850-W/FLXJ**

CDJ-850/FLXJ and CDJ-850-W/FLXJ are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-850/FLXJ	CDJ-850-W/FLXJ	Remarks
		<b>PACKING SECTION</b>			
	P57-10	Operating Instructions (En/Es/Zhtw)	DRB1528	DRB1646	
	P57-24	Packing Case	DHG3073	DHG3191	
		<b>EXTERIOR SECION</b>			
⚠	P59-21	Chassis	DNK5820	DNK6182	
		<b>CONTROL PANEL SECTION</b>			
	P61-29	Slide Sheet 1C	DAH2404	DAH2897	
⚠	P61-36	Control Panel	DNK5786	DNK6176	
		<b>JOG DIAL SECTION</b>			
	P63-6	JOG Plate	DAH2839	DAH2898	
	P63-14	JOG B	DNK4068	DNK6135	

**CDJ-850-W/AXJ5**

CDJ-850/AXJ5 and CDJ-850-W/AXJ5 are constructed the same except for the following:

Mark	No.	Symbol and Description	CDJ-850/AXJ5	CDJ-850-W/AXJ5	Remarks
		<b>PACKING SECTION</b>			
	P57-12	Operating Instructions (Zhcn/En)	DRB1529	DRB1647	
	P57-24	Packing Case	DHG3071	DHG3193	
		<b>EXTERIOR SECION</b>			
⚠	P59-21	Chassis	DNK5822	DNK6183	
		<b>CONTROL PANEL SECTION</b>			
	P61-29	Slide Sheet 1C	DAH2404	DAH2897	
⚠	P61-36	Control Panel	DNK5786	DNK6176	
		<b>JOG DIAL SECTION</b>			
	P63-6	JOG Plate	DAH2839	DAH2898	
	P63-14	JOG B	DNK4068	DNK6135	