### Pioneer sound.vision.soul

## Service Manual

ORDER NO. RRV2618

# DJM-600-K DJM-600-S

#### THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Туре	Model		B B	Domouleo
	DJM-600-K	DMJ-600-S	Power Requirement	Remarks
KUCXCN	0	-	AC120V	
WYXCN	-	0	AC220- 240V	

#### • This service manual should be used together with the following manual(s):

Model No.	Order No.	Remarks
DJM-600/ KUC, WY	RRV2234	

#### 1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: • Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

- ullet The riangle mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- $\bullet$  Screws adjacent to  $\nabla$  mark on product are used for disassembly.
- Reference Nos. indicate the pages and Nos. in the service manual for the base model.
- When ordering resistors, first convert resistance values into code form as shown in the following examples. Ex.1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J=5%, and K=10%).

 $\rightarrow 1R0 \qquad \qquad RSIP | \overline{I} | \overline{R} | 0 K$ 

Ex.2 When there are 3 effective digits (such as in high precision metal film resistors).

 $5.62k \rightarrow 562 \times 10^{1} \rightarrow 5621 \dots RN1/4PC[5]6[2]IF$ 

#### **■ CONTRAST TABLE**

DJM-600-K/KUCXCN and DJM-600/KUC are constructed the same except for the following:

Ref. No.	Mark	Symbol and Description	Part	Remarks	
Her. NO. Ivial		Symbol and Description	DJM-600/ KUC	DJM-600-K/ KUCXCN	Remarks
		PACKING SECTION			
P3 - 1		Pad A	DHA1456	DHA1541	
P3 - 2		Pad B	DHA1457	DHA1542	
P3 - 3		Pad C	DHA1458	DHA1543	
P3 - 4		Pad D	DHA1469	DHA1544	
P3 - 5		Packing Case	DHG1964	DHG2263	
P3 - 7		Operating Instructions (English, French)	DRB1251	DRB1319	
		EXTERIOR SECTION			
P5 - 25	NSP	Chassis	DNA1258	DNA1286	
		Washer	Not used	DEC2484	No.1
		CONTROL PANEL SECTION			
P7 - 47		Slider Panel	DAH1945	DAH2105	
P7 - 48		Sub Panel	DAH1946	DAH2103	
P7 - 50		Control Panel	DNB1075	DNB1112	

Note: The numbers in the remarks column correspond to the numbers on the "EXPLODED VIEWS".

#### ■ CONTRAST TABLE

DJM-600-S/WYXCN and DJM-600/WY are constructed the same except for the following:

Ref. No.	Mark	Symbol and Description	Par	Domonico	
	IVIAIK	Symbol and Description	DJM-600/ WY	DJM-600-S/ WYXCN	Remarks
		PACKING SECTION			
P3 - 1		Pad A	DHA1456	DHA1541	
P3 - 2		Pad B	DHA1457	DHA1542	
P3 - 3		Pad C	DHA1458	DHA1543	
P3 - 4		Pad D	DHA1469	DHA1544	
P3 - 5		Packing Case	DHG1959	DHG2262	
P3 - 7		Operating Instructions (English, French, German, Italian, Dutch, Spanish)	DRB1252	DRB1317	
		EXTERIOR SECTION			
P5 - 25	NSP	Chassis	DNA1256	DNA1285	
		Washer	Not used	DEC2484	No.1
		CONTROL PANEL SECTION			
P7 - 47		Slider Panel	DAH1955	DAH2104	
P7 - 48		Sub Panel	DAH1956	DAH2100	
P7 - 50		Control Panel	DNB1076	DNB1111	

Note: The numbers in the remarks column correspond to the numbers on the "EXPLODED VIEWS".

