

H-802®

8 TRACK TAPE PLAYER


**H-802**®










2SC644



2SA561  
2SC734  
2SC733



2SD130



- VR1, VR2 TONE
- VR3, VR4 VOLUME
- VR5 BALANCE

- SW-1 FUNCTION
- SW-2 POWER
- SW-3 MOTOR
- SW-4 POWER
- SW-5 VACANT
- SW-6 LINE VOLTAGE SELECTOR
- SW-7 LINE FREQUENCY SELECTOR
- SW-8 LINE VOLTAGE SELECTOR
- SW-9 PROGRAM
- SW-10 LINE VOLTAGE SELECTOR