



- FUNCTION**
- 1 ALL
 - 2 PHONO
 - 3 PHONO
 - 4 AUX/PH
- SWITCHES:**
- S₁ TAPE MONITOR 1 ON → OFF
 - S₂ TAPE MONITOR 2 ON → OFF
 - S₃ SP A-B
 - S₄ SP A-B
 - S₅ LOUDNESS ON → OFF
 - S₆ FM TUNING ON → OFF
 - S₇ AC LINE VOLTAGE SELECTOR 200V → 240V
 - S₈ MODE MONO → STEREO
- RESISTORS:** IN OHM 1/4W 1% TOLERANCE UNLESS OTHERWISE NOTED K: KΩ M: MΩ
- CAPACITORS:** IN μF UNLESS OTHERWISE NOTED P: pF
- Legend:**
- V : SIGNAL VOLTAGE NECESSARY FOR OBTAINING 750W/50.2 OUTPUT POWER
 - V : DC VOLTAGE AT NO INPUT SIGNAL
 - mA : DC CURRENT AT NO INPUT SIGNAL