




Power amp ass'y AWH-002




Control amp ass'y AWG-008




Equalizer amp ass'y W21-004




Power supply ass'y AWR-029




Switching circuit ass'y AWX-031




LW, MW tuner ass'y AWA-005




FM tuner ass'y AWE-049




Switch circuit ass'y AWS-033



Switch circuit ass'y AWS-034



Muting circuit ass'y AMM-040



LW/MW/FM STEREO RECEIVER

LX-626

FWV



**LX-626**

