


STEREO DISPLAY
SD-1000

UNIT	ROUND LABEL	F					
AF OSC UNIT		W18-039					
FM FRONT END							
FM IF UNIT							
MPX UNIT							
V-H AMP UNIT		W18-037					
MUTING UNIT							
METER AMP UNIT		W18-038					
CONTROL AMP UNIT							
MAIN AMP UNIT							
POWER SUPPLY UNIT		W16-037					
SWITCH UNIT		W18-040					
SWITCH UNIT							
SWITCH UNIT							
TONE COLOR UNIT							
CONTROL UNIT							
MIC AMP UNIT							
REVERBE AMP UNIT							
REVERBE UNIT							






AF OSCILLATOR UNIT

AF OSCILLATOR UNIT

W18-039




※ ADJUSTMENT

V. H. AMP UNIT

V. H. AMP UNIT

W18-037



V AMP

H AMP

METER AMP UNIT

METER AMP
ATTENUATOR
SWEEP TIME
& MIC AMP
UNIT

W18-038

