

Pioneer

Service Manual



SE-M290

ORDER NO.
TRT1183

STEREO HEADPHONES

SE-M290 /XZCUC

PIONEER CORPORATION 1-1, Shin-ogura, Saiwai-ku, Kawasaki-shi, Kanagawa 212-0031, Japan

PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A.

PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium

PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936

©**PIONEER CORPORATION** 2010

T-ZZZ JUNE 2010 Printed in Japan


1. SPECIFICATIONS

Model	Frequency response	Impedance	Noise Suppression	Sensitivity	Driver unit	Plug	Cord	Weight (Without cord)
SE-M290	5 Hz to 25 000 Hz	32 ohm	1 200 mW	102 dB	ø 40 mm	S/W	3.5 m	225 g

● Plug form : S (straight type), W (2Way plug)

2. EXPLODED VIEWS AND PARTS LIST

NOTES: ● Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

● The  mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.

2.1 FOR SE-M290



Exploded View



Packing View

SE-M290 Parts List

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
1	Plug Adaptor	WKX1036
2	Ear Pad	WNV1115