

S ₁ SELECTOR	S ₂ MODE
(1) MIC	(1) STEREO REV
(2) TAPE - HEAD	(2) STEREO NORM
(3) PHONO	(3) MONO A
(4) TUNER	(4) MONO B
(5) AUX	(5) MONO A+B

