



NOTES

- | | | | |
|------|---|-----|----------------------|
| S1 | FWD - REV SELECTOR SW (FWD POSITION) | VR1 | FWD - EQUALIZER ADJ |
| S2-1 | REC - P.B. SW (P.B. POSITION) | VR2 | REV - EQUALIZER ADJ |
| S2-2 | EQUALIZER SELECTOR SW (EQ POSITION) | VR3 | FWD - P.B. LEVEL ADJ |
| S2-3 | REC. MODE SW (ST. POSITION) | VR4 | REV - P.B. LEVEL ADJ |
| S2-4 | MUTING SW (PLAY POSITION) | VR5 | VU LEVEL ADJ |
| S7 | CONTACT POINT OFF SW (PLAY / STOP POSITION) | VR6 | REC. LEVEL ADJ |
| S8 | PRE SET SW | VR7 | Lch. BIAS ADJ |
| S9 | PLUNGER SW | VR8 | Rch. BIAS ADJ |
| S10 | MOTOR SW | VR9 | DH. DUMMY ADJ |
| S11 | SHUT OFF SW | | |
| S12 | POWER SW | | |
| S6 | OSC SW | | |
| RL1 | FWD - REV SELECTOR SW | | |