

Service Manual



ORDER NO.
RRV1637

STEREO CASSETTE DECK

T-C3

● Refer to the service manual RRV1041 for T-C3/HE and HEWM.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	The voltage can be converted by the following method.
	T-C3		
HE8	○	AC220-230V	AC230-240V, *
HEWM8	○	AC220-230V	AC230-240V, *

*: Alter the wiring of the Power-supply block at the primary winding of power transformer referring to the "Line Voltage Selection" described in Service Manual RRV1041.

T-C3

CONTRAST OF MISCELLANEOUS PARTS

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the parts. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "⊙" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

■ FOR T-C3/HE8

● Contrast of T-C3/HE8 and T-C3/HE

T-C3/HE8 and T-C3/HE have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		T-C3/HE	T-C3/HE8	
NSP	Warranty Card	ARW-088	ARY7008	
NSP	CE Mark Label	Not used	RRW1222	

■ FOR T-C3/HEWM8

● Contrast of T-C3/HEWM8 and T-C3/HEWM

T-C3/HEWM8 and T-C3/HEWM have the same construction except for the following:

Mark	Symbol & Description	Part No.		Remarks
		T-C3/HEWM	T-C3/HEWM8	
NSP	Warranty Card	ARW-088	ARY7008	
NSP	CE Mark Label	Not used	RRW1222	
NSP	SUB Unit	RWM1709	RWM1708 *	
NSP	— OPERATE Unit	RWZ3098	RWZ3098	
NSP	— FL Unit	RWZ3099	RWZ3099	
NSP	— TR1 Unit	RWZ3254	RWZ3253 *	
NSP	— TR2 Unit	RWZ3259	RWZ3259	
	— AC OUTLET Unit	Not used	RWZ3102 *	

* : Those Assembly are used for T-C3/HE, refer to the service manual RRV1041.