

Service Manual

ORDER NO. RRV4606

VSX-424-K

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Туре	Power Requirement	Remarks
VSX-424-K	SYXEV82	AC 220 V to 230 V	

This service manual should be used together with the following manual(s).

Model No.	Order No.	Remarks
VSX-424-K/SYXEV8	RRV4512	VSX-424-K/SYXEV8
VSX-523-K/CUXESM	RRV4418	VSX-523-K/CUXESM

For SPECIFICATIONS and PANEL FACILITIES, refer to the operating instructions.

1. CONTRAST OF MISCELLANEOUS PARTS

NOTES: • Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

- The extstyle extstyleTherefore, when replacing, be sure to use parts of identical designation.
- ullet Screws adjacent to lacktriangle mark on product are used for disassembly.
- For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

CONTRAST TABLE VSX-424-K/SYXEV8 and VSX-424-K/SYXEV82 are constructed the same except for the following:

	Mark	No.	Symbol and Description	VSX-424-K /SYXEV8	VSX-424-K /SYXEV82	Remarks
_			PACKING SECTION			
3		P45-5	Quick Start Guide	5707000008980S	5707000008981S	
		P45-6	Operating Instructions (CD-ROM)	6517000001750S	6517000001751S	
		P45-7	Box, Gift	6007212580060S	6007212580061S	
	NSP	P45-10	Warranty Card	ARY7158	ARY7191	
			EXTERIOR SECTION			
		P48-25	Back Chassis	3207214566140S	3207214566141S	