

**Pioneer**

# **Service Manual**

ORDER NO.  
RRV2052

STEREO CD/VCD CASSETTE DECK RECEIVER

# **XR-VS77**

## **XR-VS55**

● Refer to the service manual RRV2035 for XR-VS77/DBDXJ.

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model		Power Requirement	The voltage can be converted by the following method.
	XR-VS77	XR-VS55		
DAMXJ	○	○	AC110-127V/220-230V/240V	With the voltage selector

# 1. CONTRAST OF MISCELLANEOUS PARTS

- NOTES:
- Parts marked by "NSP" and ⊗ can not be supplied.
  - The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
  - Screws adjacent to ▼ mark on the product are used for disassembly.
  - Reference Nos. indicate the pages and Nos. in the service manual for the base model.

## ■ CONTRAST TABLE

XR-VS77/DAMXJ and XR-VS77/DBDXJ are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			XR-VS77 /DBDXJ	XR-VS77 /DAMXJ	
P3-10		<b>PACKING SECTION</b> Packing Case	XHD3054	XHD3066	No.1
P3-13	Δ	Power Cord	ADG1158	ADG7018	
		Label	Not used	ARW7038	
	NSP	Warranty Card	Not used	ARY7028	
P7-26	NSP	<b>EXTERIOR (2/2) SECTION</b> Name Label	XAL3008	XAL3009	No.2
		Label	Not used	PRW1499	


XR-VS55/DAMXJ and XR-VS55/DBDXJ are constructed the same except for the following :

Ref. No.	Mark	Symbol and Description	Part No.		Remarks
			XR-VS55 /DBDXJ	XR-VS55 /DAMXJ	
P3-10		<b>PACKING SECTION</b> Packing Case	XHD3056	XHD3068	No.1
P3-13	Δ	Power Cord	ADG1158	ADG7018	
		Label	Not used	ARW7038	
	NSP	Warranty Card	Not used	ARY7028	
P7-26	NSP	<b>EXTERIOR (2/2) SECTION</b> Name Label	XAL3023	XAL3024	No.2
		Label	Not used	PRW1499	

Notes: ● The numbers in the remarks column correspond to the numbers on "EXPLODED VIEWS".

## ■ EXPLODED VIEWS

### ● PACKING SECTION



### ● EXTERIOR (2/2) SECTION

