



PRIMARE

PRE32

Service Manual

1. Schematics and Pcb.


Confidential !

This document is not allowed to show for third part without written permission from Primare Systems AB.


This document is subject to change without notice.




Author:


Primare AB




Premare PRE32 FPP board VM1.0 2011-07-15











6 X BOARD $\longrightarrow$


	• •				
	Premare PRE32	INT board VM1.0	2011-07-13 • •		



[illegible]



REV.	ECN No.	DESCRIPTION	Date	APPRO.	Hansong (Nanjing) Technology Ltd. No.HS/QR-RD-25	
					THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HAN- SONG ENTERPRISES CO.,LTD. ANY REPRODUCTION IN PART OF WHOLE WITHOUT THE WRITTEN PERMISSION OF HANSONG ENTERPRISES CO.,LTD. IS PROHIBITED	
					Document Number: HS40-I32_FPP VC1-0.SCH	Sheet: 1/1
					Project:	State:
					Drafted by:	PL Checked by:
					Date:	Approved by:
					Date:	Date:







REV.	EON No.	DESCRIPTION	Date	APPRO.	Hansong (Nanjing) Technology Ltd. No HS/QR-RD-25 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF HANSON ENTERPRISES CO., LTD. ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF HANSON ENTERPRISES CO., LTD. IS PROHIBITED. Document Number: HS40-PRE32_PSU&OUT VCI-0.SCH Sheet: 1/1
Project: PRE32			State: VC		
Drafted by:			Pl. Checked by:		
Date:			Approved by:		
			Date:		

