


ACOUSTICAL A.M. TUNER



WAVECHANGE SWITCH S1 SHEWN IN M.W. POSITION. SELECTIVITY SWITCH S2 W= WIDE T= TUNE ALL RESISTORS ARE 1/2 WATT UNLESS OTHERWISE SHEW