


MASTER LEVEL A
MASTER LEVEL B

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

OUTPUT LEVELS



PHANTOM POWER

LINE/MIC A

LINE/MIC B

INPUT INPUT A


INPUT INPUT B

UPPER

LOWER


POWER

PREP NOTE
MASK THIS HOLE
TOUCH UP NOTE
TOUCH LEADS OF
POWER JACK (J11)



110724 FILM 1 OF 5 COMPONENT SIDE SILKSCREEN DA2165






NOTE:
 All input buttons switches
 are shown in the out (normal)
 position.
 All slide switches (output
 select) shown in the LEFT
 position.

INPUT PAD	GAIN	NET GAIN
IN	20dB	0dB
LINE	-20dB	+20dB
OUT	40dB	+40dB
MIC	0dB	+60dB



ACTION:	DRAWN BY: alf	CHECKED BY:
DA216S DISTRIBUTION AMP		
10902 47th Avenue West Mukilteo WA 98275-5098		
SHEET 1 OF 3		109503



ACTION:	
DRAWN BY:	alf
CHECKED BY:	
DA216S OUTPUT DRIVERS	
10902 47th Avenue West Mukilteo WA 98275-0088	SHEET 3 of 3
109503	