


SERVICE MANUAL

AM/FM STEREO TUNER SANSUI TU-517



Sansui

SANSUI ELECTRIC CO., LTD.

SPECIFICATIONS

FM Section



Tuning range	88 to 108 MHz
Usable sensitivity	
Mono IHF	9.8 dBf (1.7 μ V: T100)
DIN	1.0 μ V
Stereo IHF	19.0 dBf (4.9 μ V)
50 dB Quieting sensitivity	
Mono	12.5 dBf (2.24 μ V)
Stereo	34 dBf (27.5 μ V)
Signal to noise ratio at 65 dBf	
Mono	82 dB
Stereo	78 dB
Distortion (at 65 dBf)	
Mono: Wide	less than 0.06 % at 100 Hz
	less than 0.06 % at 1,000 Hz
	less than 0.08 % at 6,000 Hz
Narrow	less than 0.15 % at 100 Hz
	less than 0.12 % at 1,000 Hz
	less than 0.18 % at 6,000 Hz
Stereo: Wide	less than 0.1 % at 100 Hz
	less than 0.07 % at 1,000 Hz
	less than 0.1 % at 6,000 Hz
Narrow	less than 0.21 % at 100 Hz
	less than 0.15 % at 1,000 Hz
	less than 0.2 % at 6,000 Hz
Adjacent channel selectivity (at 200 kHz)	
Wide	3.5 dB
Narrow	8.0 dB
Alternate channel selectivity (at 400 kHz)	
Wide	50 dB
Narrow	80 dB
Capture ratio	
Wide	1.0 dB
Narrow	1.5 dB
Image response ratio	85 dB (at 98 MHz)
Spurious response ratio	90 dB (at 98 MHz)
Stereo separation	
Wide	45 dB at 100 Hz
	48 dB at 1,000 Hz
	38 dB at 10,000 Hz
	36 dB at 30 ~ 15,000 Hz
Frequency response	30 to 15,000 Hz +0.2 dB -1.0 dB
Antenna input impedance	
	300 ohms balanced
	75 ohms unbalanced

AM Section

Tuning range	530 to 1,600 kHz
Usable sensitivity (Bar antenna)	
	47 dB/m (220 μ V/m)
Selectivity (± 10 kHz)	35 dB
Signal to noise ratio	52 dB
Distortion at 80 dB/m	0.35 %


Others

Output level	
Output	0 to 1. V
Power requirements	100, 120, 220, 240 V 50/60 Hz
	120 V 60 Hz
	(For U.S.A. & Canada only)
Power consumption	20 W
Weight	9.2 kg (20.3 lbs) net
	11.0 kg (24.3 lbs) packed



* Design and specifications subject to change without notice for improvements.

1. BLOCK DIAGRAM




2. ADVANTAGES

1. Group Delay Equalizer (FM. IF Section)


In the IF amplification stage of model TU-517 group delay equalizer and ceramic filter of distinguished characteristics are employed for the purpose of obtaining excellent group delay characteristic. Generally, characteristics of both selectivity and group delay are inversely related and hard to be compatible.

The group delay equalizer (Sansui patent) used in TU-517 is provided to improve the group delay characteristic without sacrificing the selectivity in spite of its characteristic being inversely related to group delay characteristic of ceramic filter as shown in Fig. 1. Consequently, group delay characteristic is improved without changing selectivity characteristic after compounded both characteristics.



2. 19 kHz Trap (FM. MPX Section)

This circuit is furnished to prevent phase jitter of pilot signal which is occurred by main signal. As shown in Fig. 2, the B.P.F(Band-pass filter). is inserted between composite output and phase detector, which allows to pass the 19 kHz pilot signal. This procedure makes possible to eliminate beat noise of high frequency modulation signal (main signal of 6~12 kHz) and to improve distortion remarkably.




• Operation of pop noise protection circuit (When occurring to switch the FM-AM selector)

- When switching the FM AM push-selector ON or OFF, the sub-switch S05g, turns "ON" for a moment.
- TR₁₁ turns "ON" to be added a bias to its base.

- While the bias voltage is added to TR₁₁, the muting circuit functions.
- Resultly, the output voltage of this unit is 0V at the moment the selector being switched.

Fig. 3



3. ADJUSTMENTS (See the Top View on Page 8)

1. FM Adjustment

- Note:
1. Selector FM MONO
 2. FM Muting Switch OFF
 3. Connection . . Connect the output of genescope to TP through 100 pF ceramic capacitor.
 4. Bandwidth Wide
 5. Confirm the voltage, DC 11.5 ~ 12.5 V at tap of 08 on F-2681. If not, set VR01 on F-2681 to DC 12 V.






Fig. 3-1



(1) FM IF, RF Adjustment and Dial Calibration

STEP	SUBJECT	FEED SIGNAL		MEASURE OUTPUT	ADJUST	ADJUST FOR	CONDITION
		FROM	TO				
1.	IF Coil	Output 60 dB Genescope	TP01 F-2678	TP04 F-2678 Use Detector Probe	T01, T02 F-2678	Max. IF waveform	
2.	Discriminator Coil In case of using Genescope	Same as above	Same as above	TP01 F-2730	T01 F-2730	Steep linearity of S curve	
	Discriminator Coil In case of using Dist meter	98 MHz ANT Input 65 dBf (59.8 dB) 1000 Hz (100% MOD) FM SSG	ANT terminal 300Ω	OUT L or R-CH Dist Meter	T01, T02 F-2730	Min THD	If not turn VR01 on F-2678 slightly
3.	90 MHz Dial Calibration	90 MHz ANT Input 65 dBf (59.8 dB) 1000 Hz (100% MOD) FM SSG	ANT terminal 300Ω	OUT L or R-CH VTVM & Scope	L04 F-2678	Max. Output	
	106 MHz Dial Calibration	106 MHz ANT Input 65 dBf (59.8 dB) 1000 Hz (100% MOD) FM SSG	Same as above	Same as above	TC04 F-2678	Same as above	
4.	90 MHz RF Adj	90 MHz ANT Input Minimum value with sine wave 1000 Hz (100% MOD) FM SSG	Same as above	Same as above	L01, L02, L03 F-2678	Same as above	
	106 MHz RF Adj.	106 MHz ANT Input Minimum value with sine wave 1000 Hz (100% MOD) FM SSG	Same as above	Same as above	TC01, TC02, TC03 F-2678	Same as above	
5.	Signal Meter Volume	98 MHz ANT Input 65 dBf (59.8 dB) 1000 Hz (100% MOD) FM SSG	Same as above	Signal Meter	VR02 F-2678	4.3 on Meter	
6.	Tune Meter	Same as above	Same as above	Tune Meter	T03 F-2678	Center on Meter	

(2) FM STEREO Adjustment

Note: Selector FM AUTO

STEP	SUBJECT	FEED SIGNAL		MEASURE OUTPUT	ADJUST	ADJUST FOR	REMARKS
		FROM	TO				
1.	PLL VCO Adj.	98 MHz ANT Input 65 dBf (59.8 dB) FM SSG Pilot 19 kHz (9% MOD) R (or L) Mode 1 kHz + Pilot (100% MOD) STEREO SG	ANT terminal 300Ω	Stereo indicator	VR04 F-2678	Light indicator	Adjust the VR within center of lighting level.
	PLL VCO Adj. In case of using Freq.	98 MHz ANT Input 65 dBf (59.8 dB) FM SSG (No MOD)	Same as above	TP06 F-2678 Use Freq. counter	VR04 F-2678	76 kHz ± 150 Hz	
2.	Separation	98 MHz ANT Input 65 dBf (59.8 dB) FM SSG Pilot 19 kHz (9% MOD) R Mode 1 kHz + Pilot (100% MOD) STEREO SG	Same as above	OUT L-CH VTVM & Scope	VR02 F-2680	OUT -45 dB	Confirm separation L-CH → R-CH (-45 dB)
3.	Muting level	98 MHz ANT Input 20 dBf (14.8 dB) FM SSG Pilot 19 kHz (9% MOD) SUB 1 kHz + Pilot (100% MOD) STEREO SG	Same as above	Stereo indicator	VR03 F-2678	Muting level 20 dBf (14.8 dB) indicator turns ON.	FM MUTING Switch ON


•NEW MEASUREMENT FOR FM.

Input signal level under the provision of IHFM-T-200, a new measurement method is indicated by available power ratio "dBf". To obtain approximate available power ratio "dBf", abstract 0.8 from attenuator indication of general FMSG (open load indication type); however, the former measurement, IHFM-T-100 is designated together too.

The way of modulation on IHFM-T-200 is shown below.


	modulation frequency	modulation mode	modulation factor
FM MONO	1000 Hz		100%
FM STEREO	1000 Hz	SUB	Pilot 9% Pilot + SUB 100%

- The relation between the standard input 65 dBf of IHFM-T-200 and the former indication "dB" is shown below.



2. AM IF Adjustment & Dial Calibration

Note: 1. Selector AM 2. Confirm start point of dial pointer before alignment.



STEP	SUBJECT	FEED SIGNAL		MEASURE OUTPUT	ADJUST	ADJUST FOR	REMARKS
		FROM	TO				
1.	IF Coil	Genescope Output 70 dB	TC06 F-2678	TP07 F-2678	CF05 LC02 F-2678	Max. IF waveform	
2.	600 kHz Dial Calibration	600 kHz ANT Input 60 dB 400 Hz (MOD 30%) AM SSG	AM ANT terminal	OUT L or R-CH VTVM & Scope	T04 F-2678	Max. Output	
	1400 kHz Dial Calibration	1400 kHz ANT Input 60 dB 400 Hz (MOD 30%) AM SSG	Same as above	Same as above	TC06 F-2678	Same as above	
3.	600 kHz RF Adj.	600 kHz ANT Input 50 dB 400 Hz (MOD 30%) AM SSG	Same as above	Same as above	Bar Antenna L702	Same as above	
	1400 kHz RF Adj.	1400 kHz ANT Input 50 dB 400 Hz (MOD 30%) AM SSG	Same as above	Same as above	TC05 F-2678	Same as above	
4.	Signal Meter volume	1000 kHz ANT Input 94 dB 400 Hz (MOD 30%) AM SSG	Same as above	Signal Meter	VR05 F-2678	4.5 on meter	


Abbreviations
Equipment
AM FM Generator Oscilloscope Genescope
AM Standard Signal Generator AM SSG
FM Standard Signal Generator FM SSG
FM Stereo Generator Stereo SG
Oscilloscope Scope
Audio Oscillator Audio Osc.
Distortion Meter Dist. Meter
Others
Antenna ANT.
Modulation MOD.
Total Harmonic Distortion T.H.D.

4. PARTS LOCATION & PARTS LIST

Since some of capacitors and resistors are omitted from parts lists in this Service Manual, refer to the Common Parts List for capacitors & resistors which was appended previously to each Sansui Manual.

1. F-2678 Tuner Circuit Board (Stock No. 7521771)

Conductor Side




Parts List

Parts No.	Stock No.	Description	Position	Parts No.	Stock No.	Description	Position	Parts No.	Stock No.	Description	Position
TR01, 02	0305801, 2	2SC1047 B, C	2A	D 17	0340120	VD1212 Varistor	1D	L 06	4290011	Peaking Coil	1C
TR03	0300282, 3	2SA628 E, F	1A	D 21	0311160	1S2473D Diode	1C	L 07	4900100	3.3 μ H	1C
	0306340, 1	2SC1674 M, L		D 22, 23	0340120	VD1212 Varistor	1C	L 08	4290300	18 μ H	1D
TR04, 05, 06	0305731	2SC711 E, F	2, CB	ZD01	0315560	RD-6A N	1B	L 09	4900100	3.3 μ H	1D
TR07	0300510, 1	2SA733 P, Q	2B		0315770	EQA01-06S		L 10	4240720, 1	MPX Coil	3B
TR08, 09	0305731, 2	2SC711 E, F	3D	C 01	0669350	15 PF 50V	3A	L 11, 12	4900140	1 μ H	3B
TR10	0300510, 1	2SA733 P, Q	3D	C 04	0659015	2200 PF 50V	3A	L 14	4900110	100 μ H	3B
TR11	0305951, 2	2SC945 P, O		C 06	0669350	15 PF 50V	3A	T 01, 02	4235930	IF Coil	2A, C
TR12	0305731, 2	2SC711 E, F	3D	C 07	0659015	2200 PF 50V	2A	T 03	4235860	FM IF Coil	1D
TR13, 14	0300510, 1	2SA733 P, Q	2D	C 08	0679024	0.33 PF 500V Gimmick C	2, 3A	T 04	4220650	O.S.C. Coil	3B
TR15, 16	0306010, 1	2SC1222 (2) U, E	2D	C 10	0669350	15 PF 50V	2A	CF 01 ~ 04	0910380	Ceramic Filter	1A, B
TR21	0306342	2SC1674 K	2D	C 11	0669507	7 PF 50V	2A	CF 05	0910370	Ceramic Filter	2B
IC 01, 02	0360510	LA-1222		C 16	0679006	0.82 PF 500V Gimmick C	2A	LC 01, 02	4230620	IF Coil	3B, C
IC 03	0360350	HA1137W	1C	C 17	0669355	20 PF 50V	2A	LF 01	0910210	Low Pass Filter	
IC 04	0360730	HA1196		C 18, 19, 20	0669210	10 PF 50V	2A	VR01	1035120	Volume 6.8K Ω B, Phase adj.	1C
IC 05	0360390	HA1197		C 37	0661150	15 PF 50V	1B	VR02	1035110	Volume 47 k Ω B, FM meter	2C
FT01	0370131	3SK41 (1) L F.E.T.		C 63	0629001	6800 PF 50V	2C	VR03	1035190	Volume 100 K Ω B, FM muting	2C
D 01	0311160	1S2473D	1B	C 66	0629005	360 PF 50V	P.C.	VR04	1034250	Volume 4.7 K Ω B, V.C.O.	2D
D 02, 03	0310330, 1	IN60	1B	C 67	0573159	1.5 μ F 35WV	E.C.	VR05	1035110	Volume 4.7 K Ω B, AM meter	3C
D 04, 05	0311160	1S2473D	Diode	C 69	0573228	0.22 μ F 35WV	E.C.	VC01	1220260	Variable Capacitor	
D 06	0310330, 1	IN60	1B, C	C 79	0669415	15 PF 50V	C.C.	TC 04	1230090	Trimmer Capacitor	
D 07, 09	0340120	VD1212 Varistor	2C	C 80	0620361	360 PF 50V	P.C.				
D 10	0311160	1S2473D Diode	2C	C 81	0669415	15 PF 50V	C.C.				
D 11	0340120	VD1212 Varistor	2C	C 85, 86	0661150	15 PF 50V	C.C.				
D 12, 13	0311160	1S2473D Diode	2B	L 01	4200720	Antenna Coil	3A				
D 14	0310340	10D1 (1S2226)	Diode	L 02, 03	4210340	RF Coil	2, 3A				
D 15	0311160	1S2473D	3C	L 04	4220400	O.S.C. Coil	2A				
				L 05	4900140	1 μ H Inductor	2A				

2. F-2730 FM Discriminator Circuit Board (Stock No. 7521791)


Conductor Side



Parts No.	Stock No.	Description	Position
TR01	0300510, 1	2SA733 P, Q	2B
TR02	0306010, 1	2SC1222 (2) U, E	2B
IC 01	0360510	LA-1222	2A
IC 02	0360540	μ PC1163H	2A
D 01, 02	0311160	1S2473D Diode	1B
R 26	0191479	4.7 Ω 1W F.R.	2A
L 01	4900100	3.3 μ H Inductor	2A
L 02	4290011	Peaking Coil	1A
L 03	4900110	100 μ H Inductor	1B
T 01	4236010	IF Coil	1A
T 02	4236020	IF Coil	1B
LC01	0910400 2410590	Adjacent Channel Filter 4P Pin Ass'y Type D	

3. F-2680 Selector SW & Muting Circuit Board (Stock No. 7596071)


Conductor Side



Parts No.	Stock No.	Description	Position
TR01 ~ 04	0306010, 1	2SC1222 (2) U, E	2B
TR05, 06	0305952, 3	2SC945 P, K	1B
TR07, 08	0306010, 1	2SC1222 (2) U, E	1B
TR09, 10	0305952, 3	2SC945 P, K	1B
TR11	0300510, 1	2SA733 P, Q	2A
D 01	0311160	1S2473D Diode	2A
C 01, 02	0602109	1.0 μ F 100WV M.C.	2B
C 03, 04	0620101	100 PF 50V P.C.	2B
C 05, 06	0661150	15 PF 50V C.C.	2B
C 07, 08	0661180	18 PF 50V C.C.	2B
VR01	1015250	2-ganged volume, 50 k Ω B output level	2B
VR02	1035350	Volume, 4.7 k Ω B separation	1A
S 05	1131440	Push Switch, selector	
S 06	1110270	Slide Switch, De-emphasis	

4. F-2679 Accessory SW & Calibration Circuit Board (Stock No. 7596061)


Conductor Side



Parts No.	Stock No.	Description	Position
D 01, 02	0311160	1S2473D Diode	B
R 12	0210680	68 Ω 1W N.I.R.	B
S 02 ~ 04	1171130	Lever Switch, Noise Canceller	
	2410700	Muting Band Width 6 P Pin Ass'y Type F	

5. F-2681 Power Supply Circuit Board (Stock No. 7502751)

Conductor Side



Parts No.	Stock No.	Description	Position
TR01	0308391 ~ 3	2SD313AL D, E, F	1, 2B
TR02, 03	0305731 ~ 3	2SC711 E, F, G	1B
D 01 ~ 03	0310340	1001 (1S2226) Diode	1, 2AB
ZD01	0315770	EQA01-06S Zener Diode	1B
C 01, 02	0655103	10,000 PF 500V C.C.	1, 2A
C 05	0620471	470 PF 50V P.C.	1, 2A
R 01	0210100	10 Ω 1W N.I.R.	1, 2A
R 02	0191479	4.7 Ω 1W F.R.	2B
VR01	1035110	Volume, 4.7 k Ω B DC Adj.	1B
F 02, 03	0432210	0.5A 250V AC Fuse	1, 2A
F 04	0432250	2.5A 250V AC Fuse	1A

5. OTHER PARTS

1. Front View

Parts List		
Parts No.	Stock No.	Description
1 S 701	{ 1171530 5326611	Lever Switch, Power Knob, lever switch
2 S 04	{ 1171130 5326611	Lever Switch, band width Knob, lever switch
3 S 03	{ 1171130 5326611	Lever Switch, muting Knob, lever switch
4 S 02	{ 1171130 5326611	Lever Switch, noise canceller Lever Switch, noise canceller
5	5065211	Bottom Plate
6	5318801	Knob, tuning
7	7050510	Tuning unit
	5507070	Leg

Parts No.	Stock No.	Description
8	{ 5318850 1015250	Knob, output level 2-gang of Volume, 50 kΩ B.
9	{ 7286020 7286340	Rack mounting adaptor (set) Rear stand (each)
10	{ 1131440 5326620	Push Switch Push Knob
11	LD701	Spring, push switch
12	{ 6906490 5006680	LED, stereo indicator Bonner Unit
	5109246	B Type Screw M4 x 16

2. Top View

Parts List

Parts No.	Stock No.	Description
1	{ 3800010.4 3910600	Power Cord Strain Relief
2	{ 2410991 2410830	Voltage Selector, plug Voltage Selector, socket
3 C 702	{ 0659802 5616220	0.0047 μF 150V C.C. Capacitor Cover
4	4002430	Power Transformer
5	5037530	Blue Filter

Parts List

Parts No.	Stock No.	Description
6 C 701	{ 0659801 5616220	0.01 μF 150V C.C. Capacitor Cover
7	7726130	Illumination Unit Ass'y 8V, 0.3A
8	2200300	2 Pin Input Terminal
9	{ 6146721 5286450	Tension Unit 0.5A 250V AC Fuse, 220V/240V
10	0432210	1A 250V AC Fuse, 100V/120V
11	2210310	Antenna Holder
12 L 702	4200680	Antenna Terminal Board Bar Antenna

Parts List

Parts No.	Stock No.	Description
13 R 701	0200122	1.2 kΩ 1/2W N.L.R.
14	5206480	Antenna Holder (B)
15	2200300	2 Pin Input Terminal
16 F 701	{ 0432220 2300060	0.5A 250V AC Fuse, 220V/240V 1A 250V AC Fuse, 100V/120V Fuse Holder

Parts List

Parts No.	Stock No.	Description
TP01	TP01	TP01
TP02	TP02	TP02
TP03	TP03	TP03
VR01	VR01	VR01
VR04	VR04	VR04
LC02	LC02	LC02
CF05	CF05	CF05
VR05	VR05	VR05
TO4	TO4	TO4
LC01	LC01	LC01
TP06	TP06	TP06
TP07	TP07	TP07
TC05	TC05	TC05
TC06	TC06	TC06
TC07	TC07	TC07
TC08	TC08	TC08
TC09	TC09	TC09
TC10	TC10	TC10
TC11	TC11	TC11
TC12	TC12	TC12
TC13	TC13	TC13

Parts List

Parts No.	Stock No.	Description
TP01	TP01	TP01
TP02	TP02	TP02
TP03	TP03	TP03
VR01	VR01	VR01
VR04	VR04	VR04
LC02	LC02	LC02
CF05	CF05	CF05
VR05	VR05	VR05
TO4	TO4	TO4
LC01	LC01	LC01
TP06	TP06	TP06
TP07	TP07	TP07
TC05	TC05	TC05
TC06	TC06	TC06
TC07	TC07	TC07
TC08	TC08	TC08
TC09	TC09	TC09
TC10	TC10	TC10
TC11	TC11	TC11
TC12	TC12	TC12
TC13	TC13	TC13

Parts List

Parts No.	Stock No.	Description
TP01	TP01	TP01
TP02	TP02	TP02
TP03	TP03	TP03
VR01	VR01	VR01
VR04	VR04	VR04
LC02	LC02	LC02
CF05	CF05	CF05
VR05	VR05	VR05
TO4	TO4	TO4
LC01	LC01	LC01
TP06	TP06	TP06
TP07	TP07	TP07
TC05	TC05	TC05
TC06	TC06	TC06
TC07	TC07	TC07
TC08	TC08	TC08
TC09	TC09	TC09
TC10	TC10	TC10
TC11	TC11	TC11
TC12	TC12	TC12
TC13	TC13	TC13

Parts List

Parts No.	Stock No.	Description
TP01	TP01	TP01
TP02	TP02	TP02
TP03	TP03	TP03
VR01	VR01	VR01
VR04	VR04	VR04
LC02	LC02	LC02
CF05	CF05	CF05
VR05	VR05	VR05
TO4	TO4	TO4
LC01	LC01	LC01
TP06	TP06	TP06
TP07	TP07	TP07
TC05	TC05	TC05
TC06	TC06	TC06
TC07	TC07	TC07
TC08	TC08	TC08
TC09	TC09	TC09
TC10	TC10	TC10
TC11	TC11	TC11
TC12	TC12	TC12
TC13	TC13	TC13

Parts List

Parts No.	Stock No.	Description
TP01	TP01	TP01
TP02	TP02	TP02
TP03	TP03	TP03
VR01	VR01	VR01
VR04	VR04	VR04
LC02	LC02	LC02
CF05	CF05	CF05
VR05	VR05	VR05
TO4	TO4	TO4
LC01	LC01	LC01
TP06	TP06	TP06
TP07	TP07	TP07
TC05	TC05	TC05
TC06	TC06	TC06
TC07	TC07	TC07
TC08	TC08	TC08
TC09	TC09	TC09
TC10	TC10	TC10
TC11	TC11	TC11
TC12	TC12	TC12
TC13	TC13	TC13

Parts List

Parts No.	Stock No.	Description

<tbl_r cells="3" ix="5" maxcspan="

6. SCHEMATIC DIAGRAM

A

३


2

四

1


8

五



7. THREADING OF DIAL CORD

- If a dial cord is cut off or slips, replace it by following procedures.
As this unit uses 0.5 mm ϕ cord, please replace it with the same type certainly.
- The length of dial cord is approximately 170 cm (66.9 inch).



1. Threading of Dial Cord

Thread the dial cord in numerical order from 1 to 10 as Fig. 1.

- Open the variable capacitor completely.


Stock No.	Description
6036050	Dial Cord (0.5 mm ϕ)
6146721	Dial pulley

2. Attachment of Dial Pointer

- (1) Close the variable capacitor completely.
 - (2) Set the dial pointer to the line at most left on dial scale as Fig. 2.
- Confirm that the dial pointer runs smoothly on the dial scale by turning the tuning shaft.

8. PACKING LIST

Parts No.	Stock No.	Description
1	9116670	Vinyl Cover
2	9028021	Stylofoam Packing (L)
3	9028031	Stylofoam Packing (R)
4	9000500	Carton Case
5	5996080	Curl Stopper



9. ACCESSORY PARTS LIST

Stock No.	Description
9203780	Operating Instructions
5192082	Hexagon Wrench (1.5 mm)
9237770	Schematic Diagram
7296020	Rack-mounting Adaptor (set)
[5396340	Rack-mounting Adaptor (each)
[5216100	Rear Stand (each)
3820100	FM Antenna
3810280	Pin Plug Cord

MEMO

SANSUI ELECTRONICS CORPORATION: 55-11 Queens Blvd. Woodside, N.Y. 11377 U.S.A.
 333 West Alondra Blvd. Gardena, California 90247 U.S.A.
 3036 Koapaka St. Honolulu, Hawaii 96819 U.S.A.

SANSUI AUDIO EUROPE N.V.: North Trade Bldg (9th floor) Noorderlaan 133-Bus 1,2030 Antwerp, Belgium
 SANSUI AUDIO EUROPE S.A.: Arabella center, 6 Frankfurt AM Main, Lyoner Strasse 44-48, West Germany

SANSUI ELECTRIC COMPANY LTD.: 14-1, Izumi 2-chome, Suginamiku, Tokyo 168 Japan PHONE: (03) 323-1111/TELEX:232-2076

Sansui