

**LUXOR**

KOPPLINGSSCHEMA  
CIRCUIT DIAGRAM  
SCHALTSCHHEMA  
KYTKINKAAVA

**SKANTIC**

15050821


Ser. 1  
Sarja 1

15050822

Nov. 1978

FM-ANT. 300  
75 ohm  
Bn 001  
LA 1052  
FD782U51  
L002 L003 L004 LA  
TC003 TC004 TC005 TC

NOTES:  
1. Unless otherwise specified ceramic capacitors used are of 0.04uF  
2. ALL CAPACITORS IN MICRO FARADS(P-10<sup>12</sup>FARAD)  
3. ALL RESISTORS IN OHMS(K-10<sup>3</sup> M-10<sup>6</sup>) 1/4 W



- SW001 POWER (ON/OFF)
- SW201 PRE SETTER
  - a. Manual
  - b. 1
  - c. 2
  - d. 3
  - e. 4
  - f. 5
- SW202 FUNCTION
  - AM
  - FM
  - FM
  - Phono
  - AUX
- SW203 TAPE DUBBING
  - 1 → 2
  - Source
  - 2 → 1
- SW204 TAPE MONITOR
  - Source
  - 2
- SW205 MODE (MONO/STEREO)
- SW206 LOUDNESS
  - (ON/OFF)
- SW207 FM HIGH BLEND
  - (ON/OFF)
- SW208 HIGH CUT FILTER
  - (ON/OFF)
- SW209 LOW CUT FILTER
  - (ON/OFF)
- SW401 SPEAKER A
  - (ON/OFF)
- SW402 SPEAKER B
  - (ON/OFF)

