AZ-BS1/BS32

SERVICE MANUAL

Ver 1.0 2004.05



US Model AZ-BS32 AEP Model AZ-BS1

SPECIFICATIONS

USB memory player

Supported audio file format

MP3 Bit rate: 8 - 320 kbps* Sampling frequencies: 24/22.05/16/12/ 11.025/8/32/44.1/48 kHz

* 128 kbps or higher bit rate is recommended.

Frequency response 20 - 20,000 Hz (single signal measurement)

Radio

Frequency range FM 1/FM 2: 87.5 - 108.0 MHz

Antenna

FM antenna built in the player's handle FM wire antenna supplied with the player

General

Speakers

3.6 cm (1 $^{7/16}$ in.) diameter, cone type, 4 $\Omega \times 2$

Output

Headphones: Stereo mini-jack

Maximum power output 160 mW + 160 mW (SPEAKER OUTPUT)

Operating temperature

5°C - 35°C (41°F - 95°F)

Power source

3 V DC, LR6 (size AA) alkaline batteries $\times\,2$

Battery life*

Music data playback: Approx. 16 hours

Radio reception: Approx. 16 hours * When using two Sony LR6 (size AA) alkaline batteries

Dimensions

Approx. $115 \times 115 \times 39.3$ mm (4 $^{5}/_{8} \times 4 {}^{5}/_{8} \times 1 {}^{9}/_{16}$ in.) (w/h/d, excluding projecting parts) Approx. $115 \times 115.2 \times 39.3$ mm (4 $^{5}/_{8} \times 4 {}^{5}/_{8} \times 1 {}^{9}/_{16}$ in.) (w/h/d, including projecting parts)

Mass

Approx. 193 g (6.8 oz) (including the "pavit")

Accessories

- USB memory player with FM radio (1)
- USB storage media "pavit"* (1)
- CD-ROM (Music Transfer pavit Edition) (1)
- FM wire antenna (1)
- Operating instructions for the USB Memory Player with FM Radio (1)
- Operating instructions for the application
- software Music Transfer pavit Edition (1)
- Quick start guide (1)
- Strap (1)
- * Supplied with AZ-BS32 only.

Design and specifications are subject to change without notice.

• This set is not serviceable, and only the main unit and the part of exterior parts and accessories are serviceable.


USB MEMORY PLAYER WITH FM RADIO



9-877-947-01 2004E05-1 © 2004.05 Sony Corporation Personal Audio Company Published by Sony Engineering Corporation GENERAL

Locating controls

Player (front/top)



1 PLAY MODE switch (on the rear side) 2 EXT ANT socket for FM wire antenna

- (on the rear side)
- **3** MENU button
- 4 PRESET button5 TUNER button
- **6** ► **(**PLAY/STOP)/POWER* button
- * The button has a tactile dot.


9 VOLUME /+* buttons

10 Display

7 ÒpavitÓslot cover
8 I III (SKIP/DOWN/UP) buttons

11 \bigcirc (headphones) jack (on the lateral side)

Display



- **1** QuavitÓinsertion indicator
- The QavitÓis inserted in the player correctly.
- : The QavitOis not inserted in the player.
- **2** Operation status indication Displays the icon for music data playback, radio, stopwatch or countdown timer.
- **3** Play mode indication SHUE: Playing all tracks in random order **G1**: Playing a track repeatedly **ÚBESET** Ois displayed in the radio preset mode.


4 Volume indication Roughly shows the current volume level.

- **5** Battery level indication Roughly shows the remaining power of the batteries. If Q_Óflashes, the batteries are depleted.
- 6 Character information display Displays the title, file name of music data, etc.
 - During radio reception, displays the band and frequency.
- 7 Track number/elapsed playing time indication Displays the preset numbers in the radio preset mode.

PARTS LIST

Part No. X-2021-660-1 X-2021-662-1 4-253-386-01 A-4715-331-A 4-253-371-01	DescriptionRemMAIN ASSY (SERVICE) (CE7) (AZ-BS1)MAIN ASSY (SERVICE) (U) (AZ-BS32)COVER (HP)LID BLOCK ASSY, BATTERY CASEPAVIT LID	<u>nark</u>
4-253-372-01 4-253-388-01 4-254-822-01 3-254-022-01 not supplied	HOLDER (BATTERY CASE LID) PACKING (PAVIT) SHAFT (LID) SCREW MEMORY, USB AZ-RM32 (AZ-BS32 only)	
4-252-295-01 X-2022-450-1 4-253-596-11 4-253-596-21	MANUAL INSTRUCTION (M-T)	,
4-253-596-31	(FRENCH, SPANISH, PORTUGUESE) (AZ MANUAL INSTRUCTION (M-T) (Music Transfer pavit Ed	-BS1) lition)
4-254-827-11 4-254-827-21		
4-254-827-31 4-255-100-01	MANUAL, INSTRUCTION	-BS1) -BS1)
	X-2021-660-1 X-2021-662-1 4-253-386-01 A-4715-331-A 4-253-371-01 4-253-372-01 4-253-388-01 4-254-822-01 3-254-022-01 not supplied 4-252-295-01 X-2022-450-1 4-253-596-21 4-253-596-21 4-253-596-31 4-254-827-11 4-254-827-21 4-254-827-31	X-2021-660-1 MAIN ASSY (SERVICE) (CE7) (AZ-BS1) X-2021-662-1 MAIN ASSY (SERVICE) (U) (AZ-BS32) 4-253-386-01 COVER (HP) A-4715-331-A LID BLOCK ASSY, BATTERY CASE 4-253-371-01 PAVIT LID 4-253-388-01 PACKING (PAVIT) 4-253-388-01 PACKING (PAVIT) 4-254-822-01 SCREW not supplied MEMORY, USB AZ-RM32 (AZ-BS32 only) 4-252-295-01 CD-ROM (Music Transfer pavit Edition) X-2022-450-1 WIRE (ANTENNA) ASSY 4-253-596-21 MANUAL INSTRUCTION (M-T) (Music Transfer pavit Edition) (ENG (FRENCH, SPANISH, PORTUGUESE) (AZ- 4-253-596-31 4-253-596-31 MANUAL INSTRUCTION (M-T) (Music Transfer pavit Edition) (AZ- (GERMAN, DUTCH, ITALIAN) (AZ- (AZ- 4-254-827-21 4-254-827-21 MANUAL, INSTRUCTION (ENGLISH) (AZ- 4-254-827-31 4-254-827-31 MANUAL, INSTRUCTION (GERMAN, DUTCH, ITALIAN) (AZ- (AZ- 4-254-827-31

USB memory player with FM radio (1)



9 USB storage media "pavit"* (1) (not supplied)



* Supplied with AZ-BS32 only.

10 CD-ROM (Music Transfer pavit Edition) (1)



11 FM wire antenna (1)



Notes: The part name in a figure has indicated the name currently used by instruction manual.

REVISION HISTORY

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the upper right on the revised page allows you to jump to the next revised page.

Ver.	Date	Description of Revision
1.0	2004.05	New
		1