

SERVICE MANUAL

US Model

CDP-19 and CDP-39 are almost the same as model CDP-190 and CDP-390 respectively, previously produced. Therefore, see the service manual for the information not contained in this manual.

PARTS LIST (The difference between CDP-190/390 and CDP-19/39)

Page	CDP-190/390		CDP-19/39	
	No.	Part No.	Part No.	Description
21	3	X-4933-103-4	X-4933-108-1	(19) ... PANEL ASSY, FRONT
		X-4933-102-1	X-4933-107-1	(39) ... PANEL ASSY, FRONT
	5	4-933-117-01	4-933-117-31	(19) ... PANEL, LOADING
		4-933-117-11	4-933-117-21	(39) ... PANEL, LOADING
	13	*4-933-101-01	*4-933-101-61	(19) ... PANEL, BACK
		*4-933-102-01	*4-933-102-61	(39) ... PANEL, BACK
26	Acc.	3-750-716-21	3-751-319-21	MANUAL, INSTRUCTION
	Acc.	*4-925-388-71	*4-933-231-41	(19) ... INDIVIDUAL CARTON
	Acc.	*4-925-388-61	*4-933-231-31	(39) ... INDIVIDUAL CARTON

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

COMPACT DISC PLAYER

SONY®

Sony Corporation
Audio Group