

CDP-CX88ES

SERVICE MANUAL

US Model
Canadian Model

The mechanical and electrical specifications of CDP-CX88ES is almost same as CDP-CX70ES.

This manual contains only the points which differ from CDP-CX70ES. However accessories and packing materials are all listed.

For the informations not contained in this manual, please refer to the CDP-CX70ES/CX255 service manual (9-920-919-00) previously issued.

1. DIFFERENT PARTS LIST

| Page | CDP-CX70ES | | | CDP-CX88ES | | |
|------|------------|--------------|------------------------|------------|--------------|------------------------|
| | Ref. No. | Part No. | Description | Ref. No. | Part No. | Description |
| 62 | * 3 | A-4699-701-A | MAIN BOARD, COMPLETE | * 3 | A-4724-051-A | MAIN BOARD, COMPLETE |
| | * 7 | 4-983-366-52 | PANEL, BACK (US) | * 7 | 4-983-366-72 | PANEL, BACK (US) |
| | * 7 | 4-983-366-62 | PANEL, BACK (Canadian) | * 7 | 4-983-366-82 | PANEL, BACK (Canadian) |
| 64 | 108 | X-4948-513-1 | PANEL ASSY, FRONT | 108 | X-4949-666-1 | PANEL ASSY, FRONT |
| 72 | * | A-4699-701-A | MAIN BOARD, COMPLETE | * | A-4724-051-A | MAIN BOARD, COMPLETE |
| 74 | IC301 | 8-752-884-85 | IC CXP84332-052Q | IC301 | 8-752-893-09 | IC CXP84332-079Q |

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

2. ACCESSORIES & PACKING MATERIALS

| Part No. | Description |
|--------------|--|
| 1-475-789-11 | REMOTE COMMANDER (RM-DX260) |
| 1-475-790-11 | RECEIVE UNIT |
| 1-475-791-11 | ADAPTOR, AC |
| 1-551-734-11 | CORD, CONNECTION (RK-74A) (AUDIO) |
| 1-777-172-11 | CORD, CONNECTION (CONTROL-A1) |
| 3-810-765-11 | MANUAL, COMMONNESS, INSTRUCTION (CONTROL-A1) (ENGLISH) (US) |
| 3-810-765-21 | MANUAL, COMMONNESS, INSTRUCTION (CONTROL-A1) (ENGLISH, FRENCH, GERMAN, SPANISH, DUTCH, SWEDISH, ITALIAN, PORTUGUESE, CHINESE) (Canadian) |
| 3-862-074-11 | MANUAL, INSTRUCTION (ENGLISH, FRENCH) |
| 4-210-990-01 | LID (RM-LJ301), BATTERY CASE (FOR RM-DX260) |
| 4-212-262-01 | COVER (FOR RM-DX260) |
| 4-984-086-01 | BOOKLET (100) |

COMPACT DISC PLAYER

SONY®

