

CDP-H6600D

SONY® SERVICE MANUAL

AEP Model

- CDP-H6600D is similar to the earlier CDP-H6600 (AEP model).
- Refer to CDP-H6600 service manual for information not contained in this service manual.

PARTS LIST (The difference between CDP-H6600 and CDP-H6600D)

NOTE :

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

CDP-H6600			CDP-H6600D	
<u>Page</u>	<u>No.</u>	<u>Part No.</u>	<u>Part No.</u>	<u>Description</u>
23	4	X-4941-525-1	X-4941-800-1	PANEL ASSY, FRONT
	3	X-4941-527-1	X-4941-799-1	LID (TRAY) ASSY
	1	4-932-844-01	*4-932-844-71	CASE
15		4-942-636-01	4-942-636-11	EMBLEM (No. 3.5), SONY
	7	*4-943-175-11	*4-943-175-91	PANEL, BACK
14		4-944-445-01	4-944-445-11	PANEL, FRONT