


Service Manual

Tape recorders 3300X / 3400X




TANDBERG




The Circuit Diagram of the 3400X tape recorder reel to reel machine.


Q302



Latest change:
S DN S switch
turned 180°




When replacing the transistor be sure to position the metal side against the mica washer.




SEEN FROM SOLDER SIDE

SOURCE/TAPE



REC. SELECTOR



SOUND ON SOUND SWITCH

