


TANDBERG

TCD 320 / 330 / 340 A RACK MOUNTING KIT

The rack mounting kit is designed to allow the TCD 320, TCD 330, and TCD 340A to be mounted in a 19" rack.



- Remove the four screws holding the side panels to the cassette deck, and remove the side panels.
- Insert the four nuts (A) into the square holes in the side brackets (B).
- Mount the side brackets to the cassette recorder.
- Screw the bottom panel (C) to the side brackets.
- Put the cassette recorder into the rack and mount it from behind.
- Supply the side panels (D) and use the four screws (E) to fix the cassette recorder to the rack.