




USB2.0 Audio/MIDI Interface **US-1800**


CONTENTS (目次)


ANALOG (1/9)	2
ANALOG (2/9)	3
ANALOG (3/9)	4
ANALOG (4/9)	5
ANALOG (5/9)	6
ANALOG (6/9)	7
ANALOG (7/9)	8
ANALOG (8/9)	9
ANALOG (9/9)	10
USB (1/6)	11
USB (2/6)	12
USB (3/6)	13
USB (4/6)	14
USB (5/6)	15
USB (6/6)	16
F_JACK	17
R_JACK	18
PHONE	19
REAR	20
POWER	21
VR	22
LED	23
WIRING	24






























































To PCB USB/PCB POWER

