


# Schematic Diagram ... Model SH-8015 (This schematic diagram may be modified at any time with the development of new technology.)

## NOTE:

- S1: Power switch in "on" position
- S2: EQ switch in "on" position
- S3: EQ position switch in "source" position
- S4: Tape-monitor switch in "source" position
- S5: Variable range switch in "±12 dB" position
- S6: Voltage selector in "240 V" position
- ⚠ Indicates that only parts specified by the manufacturer be used for safety.

## TERMINAL GUIDE (BOTTOM VIEW)



(X L)

