



ALIGNMENT AND SENSITIVITY

STEP	APPLY SIGNAL		THRU SERIES TUNING	SET GANG AT	ADJUST FOR MAX. OUTPUT	NOMINAL SENSITIVITY
	KC.	TO				
1	455	12BA6*1	.05 μ f.d.	MIN. CAP.	2ND. I.F.	2000 μ v.
2	455	12BE6*7	.05 μ f.d.	MIN. CAP.	1ST. I.F.	65 μ v.
3	1460	*ANT.	—	1460	OSC. TRIMMER	—
4	1460	*ANT.	—	1460	ANT. TRIMMER	275 μ v./m.
5	535	*ANT.	—	MAX. CAP.	CHECK ONLY	—
6	600	*ANT.	—	600	CHECK ONLY	475 μ v./m.

* FASHION LOOP CONSISTING OF SEVERAL TURNS OF WIRE AND RADIATE SIGNAL, FROM GENERATOR TO LOOP OF RECEIVER.

VIKING RMK-316
RM-318, RM-318R