


TR301
2SA352(A)
FREQ. CONV.
D301
1N34A
AGC
TR302
2SA12(D)
I.F. AMP
TR303
2SA353(C)
I.F. AMP
D302
1N34A
DET. & AGC
TR001
2SA12(A)
I.F. OSCILLATOR
D001
1N34A
MIXER
D002
1N34A
RECTIFIER
TR002
2SB77(C)
RELAY CONTROL
TR401
2SB77(C)
A.F. AMP.
TH401
D-2B
TEMPERATURE COMPENSATOR
TR402.403.
2SB77(C)(P)x2
POWER AMP.
J1
EARPHONE JACK
SP1
2½" SPEAKER
DX—MEDIUM
-LOCAL SWITCH
SW3 RELAY SWITCH
UM-3x4
6V

Hitachi TH-800






TR301
2SA352(A)
FREQ. CONV.
D301
1N34A
AGC
TR302
2SA12(D)
I.F. AMP
TR303
2SA353(C)
I.F. AMP
D302
1N34A
DET. & AGC
TR001
2SA12(A)
I.F. OSCILLATOR
D001
1N34A
MIXER
D002
1N34A
RECTIFIER
TR002
2SB77(C)
RELAY CONTROL
TR401
2SB77(C)
A.F. AMP.
TH401
D-2B
TEMPERATURE COMPENSATOR
TR402, 403.
2SB77(C)(P)x2
POWER AMP.
J1
EARPHONE JACK
SP1
2½" SPEAKER
DX—MEDIUM
—LOCAL SWITCH
SW3 RELAY SWITCH
UM-3x4
6V