NIKKO

TRM-800

Service manual



www.hifiengine.com

OVERALL DIAGRAM MODEL TRM-800



LAST NO.
Q716, R756, C714
L702, D708

NOTES;

When any two pair of the buttons. (A+B, B+C, C+A) are depressed the corres ponding pair of speaker systems come into operation.
However all three buttons even though depressed at the same time (A+B+C) Only system "A" come into operation.