

marantz®

Service Bulletin

No. : MZ07-018

Date: February 22, 2007

Model: CC4001

Subject: Software Update

Symptom: When playing CD audio tracks with the running times displayed as minus figures (ex. -00:01:00), the product does not pick up any audio while displaying the minus figures. When a disc with many such tracks is being played back, the output is interrupted each time the minus figure is displayed.


Solution: 1. Update the firmware in the microprocessor (U3). After the update, the version of the firmware is Ver: 18.

2. Firmware update data and part number

1) Update Data: cc400118.hex (448KB)

2) Part No: 00M08CW499C02

3) Firmware Version: Buffer 18 [bU 00 18] For the checking procedure, please refer to Page 7 in the Service Manual [6.SERVICE MODE].

<p>3) Press 2 (Disc Select) and DISC SKIP button. Microprocessor (U3) version is displayed on FLD.</p>	<p>3) ディスクセレクトボタン2とDISC SKIPボタンを押します。 フロントパネルの表示窓にマイコン (U3) のバージョンが表示されます。</p>
 <p>The image shows the front panel of a Marantz CD player. The display is divided into several sections. On the left, there are buttons for '1', '2', '3', '4', and '5'. The main display area shows 'MP3 CD PROGRAM' and 'RANDOM REPEAT 1DISC'. Below this, 'TRACK' is displayed with '18' in large digits. To the right of 'TRACK', 'TOTAL EACH REMAIN' is shown with '00' and '05'. Further right, 'MIN' and 'SEC' are shown with '00' and '05'. On the far right, there is a row of 20 small numbers (1-20) representing tracks. A red arrow points from the number '18' in the track list to the large '18' in the 'TRACK' display.</p>	

CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.

Parts:

Ref#	Description	Part Number
NA	Microprocessor U3 Update	00M08CW499C02

Serial Number Range:

Applicable serial number range: MZ0006xx000001 ~ MZ0007xx006030

Already updated: MZ0007xx006031 ~ later

CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.