



Service Bulletin

No. : MZ09-176

Date: April 9, 2010

Model: SR6004, SR5004

Subject: Correction of the Firmware.

Countermeasure is applicable upon every repair (within S/N range) and upon customer complaint.

Symptom: The protection mode will happen after repeating "Pause" and "Play" in the state that "Audyssey Dynamic EQ " is set by On when SR6004/5004 is connected to a TiVo Hard disc recorder.

Solution: We corrected the MICON Software so that no malfunction occurs.

MODIFICATION: Please refer to page 25 "8. WRITING AND UPDATE SOFTWARE" in Service Manual.

Parts:

Ref#	Description	Part Number
SR5004	Ver. V1003241	SR5004_00M26DW499A05.ZIP
SR6004	Ver. V1003241	SR6004_00M27DW499A05.ZIP

Serial Number Range:

Please apply the above modification to the production models in the following serial numbers. (Full-digits)

SR6004 MZ00****000001 ~ MZ04*****
SR5004 MZ00****000001 ~ MZ04*****

CONFIDENTIALITY NOTICE:

The information contained in this document is intended for the exclusive use by MARANTZ Authorized Service Centers and their employees. This document may contain information that is privileged, confidential and may be protected from disclosure under applicable laws and terms of the MARANTZ Service Agreement. Any distribution, disclosure, dissemination or copying of this document and the information it contains is prohibited. No responsibility will be accepted by MARANTZ for any damage, injury or loss resulting from the misuse of the information contained in this document.