CR16 Mechanism

Procedure for CD Test Mode to check mechanism after repair

Plug in unit, then with unit in Standby follow the procedure below

- 1) Press "Power" to turn unit on
- 2) Press "Tape"
- 3) Press "Stop" until display changes
- 4) While still pressing "Stop", also press "FF" until display shows "T"
- 5) Release buttons
- 6) Press "CD"
- 7) Press "REW"

Mechanism will now automatically load and unload discs. An incremental display will be shown, allow this to reach 20 to ensure correct operation. If it fails during this mode, re-align mechanism and try again.

"Power" off to escape out of this mode.