

**712**

TUNER  
AMPLIFIER

# SERVICE MANUAL

**NAD**


## SERVICE SAFETY PRECAUTIONS (UL)

1. Use exact replacement parts for critical locations marked “”
2. Return lead dress to original position and re-install protective covers.
3. Before returning to customer, test for shock hazard; use either method A or B:
  - A. Leakage test “cold”:
    1. Unplug the AC cord; turn power switch ON.
    2. Connect one lead of High Voltage Insulation Tester to both prongs of the AC plug.
    3. Touch other lead to all exposed metal parts.
    4. Impedance measurement must be 0.3-5.0 Megohms.
  - B. Leakage test, “live” :
    1. Plug unit directly into the AC outlet; do not use isolation transformer.
    2. Connect one lead of the Leakage Current Tester to earth ground.
    3. Touch other lead to all exposed metal parts.
    4. Leakage measurement must be less than 0.5 millamps.

**712**  
**TUNER**  
**AMPLIFIER**

# SERVICE SAFETY PRECAUTIONS

## 1. Replacing the fuses



This symbol located near the fuse indicates that the fuse used is fast operating type. For continued protection against fire hazard, replace with same type fuse. For fuse rating refer to the marking adjacent to the symbol.

<u>Reference No</u>	<u>Part Number</u>	<u>Description</u>
F503-F504*AH	5120-0019-0	Fuse 4A 125V Time Lag LBC (UL/CSA)
F503-F504*B,B1,C	5120-0017-0	Fuse 4A 250V Time Lag HBC (SEMKO/VDE)
F505-F507*AH	5120-0026-0	Fuse 315mA 250V Time Lag LBC (UL/CSA)
F505-F507*B,B1,C	5120-0027-0	Fuse 315mA 250V Time Lag LBC (SEMKO/VDE)

### NOTE :

- <\*AH> : USA, CANADIAN MODEL ONLY.
- <\*B> : UK MODEL ONLY.
- <\*B1> : AUSTRALIAN MODEL ONLY.
- <\*C> : EUROPEAN MODEL ONLY.

## 2. Safety-check out

(Only U.S.A. model)

After correcting the original service problem perform the following safety check before releasing the set to the customer.

Connect the insulating-resistance tester between the plug of power supply cord and the screw on the back panel.

Specifications : 3.3 Mohm±10% at 500V.

## CONTENTS

DESCRIPTION	PAGE
SPECIFICATIONS .....	4-5
REAR PANEL / FRONT PANEL VIEW.....	6
BLOCK DIAGRAM .....	7
WIRING DIAGRAM .....	8
DISASSEMBLY INSTRUCTIONS .....	9
ADJUSTMENT POINTS DIAGRAM .....	10
ALIGNMENT PROCEDURE .....	11-12
PCB LAYOUT .....	13-16
SCHEMATIC DIAGRAM .....	17-26
IC BLOCK DIAGRAM .....	27-30
EXPLODED VIEW .....	31
EXPLODED VIEW PARTS LIST .....	32-33
ELECTRICAL PARTS LIST .....	34-39
PACKING DIAGRAM / PACKING LIST.....	40

## SPECIFICATIONS

<u>POWER AMPLIFIER SECTION</u>	
THD (0.25W-30W, 20 Hz-20 kHz)	$\leq 0.03\%$
Continuous Power Output (0.03% THD)	8-ohm 4-ohm
Clipping Power Output (1kHz, 0.1% THD)	8-ohm
Signal / Noise Ratio (A-wtd, ref.1W, 220-ohm source)	8-ohm
Frequency Response (20 Hz-20 kHz)	$\geq 99$ dB
Dynamic Power (1 kHz)	$0 \pm 0.6$ dB
Damping Factor at 50 Hz	$\geq 50$
Input Sensitivity (30W)	$\geq 50$
Channel Separation (15W)	$1.07 \pm 0.05$ V
Soft Clipping (0.1% THD, 8-ohm)	$\geq 70$ dB
THD (SC ON)	$\geq 60$ dB
Output Reduction(SC ON)	$\leq 10\%$ $\leq 1.5$ dB
<u>PREAMPLIFIER SECTION</u>	
Input Sensitivity (1V out, pre-out)	$165 \pm 20$ mV
Frequency Response (20 Hz-20 kHz, 500 mV in/out, pre-out)	$0 \pm 0.6$ dB
THD (20Hz-20KHz, 2V in/out, pre-out)	$\leq 0.02\%$
Signal / Noise Ratio (A-wtd, 1W SPK out, 1K-ohm source, 500 mV in)	$\geq 85$ dB
Tone Control Responses	$\pm 10 \pm 1.5$ dB
Bass (50 Hz)	$\pm 7 \pm 1.5$ dB
Treble (10 kHz)	
Channel Balance L & R	$\pm 0.5$ dB
Maximum Volume (15W)	$\pm 1.5$ dB
-1 dB to -20 dB	$\pm 3$ dB
-21 dB to -60 dB	$\pm 5$ dB
-61 dB to -70 dB	$\geq 65$ dB
Channel Separation (2V in/out, pre-out)	$\geq 55$ dB
1 kHz	
10 kHz	
Crosstalk	$\geq 83$ dB
Source-to-Source (2V in/out, pre-out)	$\geq 68$ dB
1 kHz	$\geq 75$ dB
Tape replay-to-tape record (2V in/out, tape out)	$\geq 60$ dB
1 kHz	
10 kHz	
Maximum Output Level (0.1%THD, 500 mV)	$\geq 6$ V
Pre-out	$\geq 10$ V
Headphone (600-ohm load)	
1 kHz	
Maximum Input Signal (0.1%THD, pre-out)	$\geq 6$ V
1 kHz	

## REAR PANEL / FRONT PANEL VIEW

### FM TUNER SECTION

Input level is expressed as the reading in open-circuit of 75-ohm source impedance signal generator

Usable Sensitivity (98 MHz)

50 dB Quieting

Mono  $\leq 23 \text{ dB}\mu$   
Stereo  $\leq 9.5 \text{ dB}\mu$

60 dB Quieting

Mono  $\leq 21 \text{ dB}\mu$   
Stereo  $\leq 14 \text{ dB}\mu$

Signal / Noise Ratio  
(60 dB $\mu$ , IHF wtd)

Mono  $\geq 73 \text{ dB}$   
Stereo  $\geq 65 \text{ dB}$

Frequency Response (30 Hz - 15 kHz, 60 dB $\mu$ )

30 Hz  $0 \pm 0.7 \text{ dB}$   
1 kHz  $\geq 30 \text{ dB}$

Channel Separation (60 dB $\mu$ )  
30 Hz  $\geq 35 \text{ dB}$   
1 kHz  $\geq 32 \text{ dB}$   
10 kHz  $\geq 27 \text{ dB}$

Alternate Channel Selectivity  
(40 dB $\mu$ ,  $\pm 400$  kHz)

$\geq 65 \text{ dB}$

Capture Ratio (40 dB $\mu$ )

$\leq 7 \text{ dB}$

AM Suppression  
(60 dB $\mu$ , 100% Mod.FM, 30% Mod AM)

$\geq 54 \text{ dB}$

Image Rejection (119.4 MHz)

$\geq 74 \text{ dB}$

I.F. Rejection (10.7 MHz)

$\geq 75 \text{ dB}$

Pilot Suppression (60 dB $\mu$ )

$\geq 60 \text{ dB}$

THD (60 dB $\mu$ , 100%Mod. for AH, 40% Mod. for C,1 kHz)

Mono  $\leq 0.2\%$

L - R  $\leq 0.3\%$

L + R  $\leq 0.2\%$

Auto-Search Sensitivity

$27 \pm 5 \text{ dB}\mu$

Center Tune Sensitivity

$20 \pm 3 \text{ dB}\mu$

Stereo Indicator Sensitivity

On  $23 \pm 4 \text{ dB}\mu$

Off  $21 \pm 4 \text{ dB}\mu$

### AM TUNER SECTION

Usable Sensitivity (1000 kHz or 999 kHz)

$\leq 17 \text{ dB}\mu$

Signal / Noise Ratio

(66 dB $\mu$ , 30% Mod, 1000 kHz or 999 kHz)

THD (66 dB $\mu$ , 1000 kHz or 999 kHz)

Adjacent Channel Selectivity

( $\pm 10$  kHz or  $\pm 9$  kHz)

$\geq 19 \text{ dB}$

Image Rejection (1900 kHz or 1899 kHz)

$\geq 36 \text{ dB}$

I.F. Rejection (450 kHz)

$\geq 46 \text{ dB}$

Auto-Search sensitivity

$40 \pm 7 \text{ dB}\mu$

### DIMENSIONS AND WEIGHTS

Net Weight : 6.9 kg, 15.2 lb




Shipping Weight : 8 kg, 17.6 lb

Dimensions (WxHxD) : 435 x 110 x 310 mm


### \*B,\*B1,\*C

### \*AH

### FRONT PANEL




### REAR PANEL CONNECTIONS




1. FM ANTENNA
2. AM ANTENNA
3. TAPE 2 IN/OUT
4. CD INPUT
5. AUX INPUT
6. LD INPUT
7. VIDEO SOUND INPUT
8. TAPE 1 IN/OUT
9. PRE OUT/MAIN IN
10. NAD LINK IN/OUT
11. SPEAKERS A AND B
12. SOFT CLIPPING SWITCH
13. IMPEDANCE SWITCH
14. AC POWER CORD
15. AC OUTLETS (ONLY IN 120V MODEL)

# BLOCK DIAGRAM


## SIGNAL FLOW DIAGRAM



## POWER SUPPLY




## **WIRING DIAGRAM**




## DISASSEMBLY INSTRUCTIONS

1. Remove machine screws M4.0 x 6.0 (① to ④) from the side panels.  
Remove tapping screw 3.0 x 8.0 ⑤ from the back panel.  
Refer to **Figure No. 1**.



**Figure No. 1.**




**Figure No. 2.**

2. Pull both sides of the TOP COVER slightly outwards, tilt approximately 35° and then move in the direction shown in **Figure No. 2**.


## **ADJUSTMENT POINTS DIAGRAM**

## **1. TUNER**



**CAUTION:** REPLACE WITH SAME TYPE FUSE

## 2. IDLE CURRENT



# ALIGNMENT PROCEDURES

## FM SECTION

AF MODULATION: 1 kHz, 75 kHz DEVIATION, MONO MODE  
STORE FREQUENCY: 98 MHz, 87.5 MHz, 108 MHz, 90 MHz, 106 MHz  
RF LEVEL: 75-ohm IMPEDANCE, OPEN CIRCUIT

## OSCILLATION TUNING VOLTAGE

Connect DVM between TP701 & GND.

For A16 Front-end Module:

- Tune to 87.5 MHz, adjust FE4 (osc coil) to read  $3 \pm 0.5$  V.
- Tune to 108 MHz, adjust FE4 (osc coil) to read  $20.5 \pm 0.5$  V.

For G55 or G58 Front-end Module:

- Tune to 87.5 MHz, adjust FE4 (osc coil) to read  $1.6 \pm 0.5$  V.
- Tune to 108 MHz, adjust FE4 (osc coil) to read  $8.0 \pm 0.5$  V.

## I.F.

Connect DVM between TP703 & TP704

Apply 10.7 MHz, 90 dB $\mu$  via 1K-ohm to TP702.

Adjust L706 to read  $0 \pm 50$  mV.

Adjust L707 for minimum distortion (THD).

Repeat adjustment until no further improvement.

## SYNTHESIZER I.F. TRACKING

Disconnect 10.7MHz tap to TP702.

Maintain connection of DVM across TP703 & TP704.

Apply 98 MHz, 60 dB $\mu$  to antenna input.

Tune to 98 MHz.

Adjust C701 to read  $0 \pm 20$  mV.

Fine adjust L707 for minimum distortion.

Repeat until no further improvement.

## FRONT-END IF

Connect DVM between TP705 and ground.

Turn RR742 fully clockwise and R736 fully anti-clockwise.

Apply 98 MHz, 18 dB $\mu$  to antenna input.

Adjust FE5 to obtain minimum reading on DVM.

## R.F.

Apply 98 MHz, 8 dB $\mu$  for AH or 22 dB $\mu$  for C, to antenna input.

Check THD.

If THD > 3%, adjust FE1, FE2 & FE3 in the front-end module with non-metallic tool for minimum THD.

Check THD at 90 MHz & 106 MHz with 9 dB $\mu$  input for AH, or 23 dB $\mu$  for C.

## AUTO-SEARCH LEVEL

Turn R736 fully clockwise and RR742 fully anti-clockwise.

Set stereo modulator to L = R mode.

Apply 98 MHz, 18 dB $\mu$  to antenna input.

Adjust R736 until Center Tune LED just light.

Increase input level to 22 dB $\mu$ .

Adjust RR742 until FM stereo LED just light.

Check if auto-search works at 28 dB $\mu$ .

FM Stereo: 1kHz, 67.5kHz devi., 60dB $\mu$ V, Pilot signal 19kHz, 7.5kHz devi.

## STEREO SEPARATION & PILOT SUPPRESSION

Set modulated signal to Left only.

Adjust R753 for minimum output at Right channel.

Set modulated signal to Right only.

Adjust R753 for minimum output at Left channel.

Repeat until readings are the same.

Turn off modulating signal, leaving the pilot tone.

Adjust FL704 and FL705 for minimum outputs on Right and Left channels respectively.

## **AM SECTION**

**For version conversion, press Tune UP while pressing Mode switch to toggle the AM steps between 9 kHz and 10 kHz.**

AF MODULATION: 400 Hz, 30%

FOR AH VERSION, STORE FREQUENCIES 600, 1000, 1400 kHz.

FOR C & B VERSIONS, STORE FREQUENCIES 603, 999, 1404 kHz.

Connect 22 pF ceramic capacitor between signal generator and antenna terminal.

## **OSCILLATION TUNING VOLTAGE**

Connect DVM between TP701 & GROUND.

Tune to 603/600 kHz.

Adjust L705 for  $1.75 \pm 0.05$  V.

### **I.F.**

Apply 999/1000 kHz, 35dB $\mu$  to antenna input.

Tune to 999/1000 kHz.

Adjust L708 for maximum output.

### **R.F.**

Apply 603/600 kHz, 45dB $\mu$ .

Tune to 603/ 600 kHz.

Adjust L704 for maximum output.

Apply 1404/1400 kHz, 45dB $\mu$ .

Tune to 1404/ 1400 kHz.

Adjust C721 for maximum output.

Repeat until no further improvement.

## **AMPLIFIER ADJUSTMENT**

### **IMPORTANT**

*Speaker impedance switch should be in the 8 ohms position while adjusting the amplifier.  
Reset switch after adjustment procedure is completed.*

#### **1) Output Offset Voltage (No load, no input Signal)**

Connect DC voltmeter across L channel speaker terminals.

Adjust R411 for  $0 \pm 30$  mV reading.

Connect DC voltmeter across R channel speaker terminals.

Adjust R412 for  $0 \pm 30$  mV reading.

#### **2) Idle Current**

Remove solder link in between TP 401 and TP403, or cut LK53.

Connect DC millivoltmeter at TP401 and TP403 (i.e. across R455, 1-ohm resistor).

Adjust R443 for 25-35mV reading on voltmeter.

Remove solder link in between TP 402 and TP404, or cut LK322.

Connect DC millivoltmeter at TP402 and TP404 (i.e. across R456, 1-ohm resistor).

Adjust R444 for 25-35 mV reading on voltmeter.

#### **3) Final Adjustment**

Leave power on for at least 5 minutes.


Repeat step 1

Repeat step 2


Replace solder link between T401 and T403 for left channel, and TP402 and TP404 for right channel, or reconnect LK53 and LK322.

## PCB LAYOUT



### AC




### EXTRA SPEAKER SWITCH




### MOTOR DRIVE




### IMPEDANCE SWITCH




### SPEAKER TERMINAL




### ANTENNA



## **FRONT PANEL**




MAIN BOARD & TUNER





## **SCHEMATIC DIAGRAM**

PSU & MAINS




Resistors: F - Fusible  
FP - Flame Proof  
Not specified are Carbon Film




NOTE: 1. RESISTORS, UNLESS OTHERWISE SPECIFIED, ARE 1/4 WATT.  
2. ALL CERAMIC CAPACITORS, UNLESS OTHERWISE SPECIFIED, ARE 50V, 10%.  
3. COMPONENTS MARKED WITH " # " ARE AH VERSION ONLY.  
4. COMPONENTS MARKED WITH "▲" ARE SAFETY CRITICAL PARTS.


## INPUT, SPEAKER & HEADPHONE




## AMPLIFIER




- NOTE:
1. RESISTORS, UNLESS OTHERWISE SPECIFIED, ARE 1/4 WATT.
  2. ALL CERAMIC CAPACITORS, UNLESS OTHERWISE SPECIFIED, ARE 50V, 10%.
  3. COMPONENTS MARKED WITH " #" ARE AH VERSION ONLY.
  4. COMPONENTS MARKED WITH "▲" ARE SAFETY CRITICAL PARTS.



## TUNER




## **FRONT PANEL & MOTOR POT**




## IC BLOCK DIAGRAM

IC201: TC9163N




IC701: LM7000 (BLOCK DIAGRAM)



IC202: NJM072D


IC203, IC204: NJM4558, IC301: NJM2068




IC01: TMS77C82

B5/R/W	1	V <sub>ss</sub>
B&/CLKOUT	2	B6/ENABLE
BQ/T2OUT	3	B4/ENABLE
B1/T1OUT	4	B3/TXD
B2	5	MC
A0	6	C7
A1	7	C6
A2	8	C5
A3	9	C4
A4/SCLK	10	C3A7/EC1
A7/EC1	11	C2
INT3	12	C1
INT1	13	C0
RESET	14	D0
A6/EC2	15	D1
A5.RXD	16	V <sub>cc</sub>
XTAL2/CLKIN	17	D2
XTAL1	18	D3
D7	19	D4
D6	20	D5
	21	


IC703: LA1266 (BLOCK DIAGRAM)



IC704: LA3401




IC02: LC7582A (BLOCK DIAGRAM)




29


IC03: MC14094BCP



IC901: LB1642




Q710: X24C01P



30

## EXPLODED VIEW



## EXPLODED VIEW PARTS LIST

<u>Item</u>	<u>Part No</u>	<u>Description</u>	<u>Qty</u>
0001	N14630511-0	FASCIA	1
0002	N14023820-0	SUBFASCIA	1
0003	1402-3720-0	CHASSIS	1
0004	N14023810-0	BASE COVER	1
0005*AH	1402-4012-0	REAR PANEL	1
0005*B,B1,C	1402-3833-0	REAR PANEL W/SS	1
0006	N14023840-0	TOP COVER	1
0007	N2437510B-0	DIA 9.5 POWER BUTTON	1
0008	N14023460-0	35MM KNOB SKIN	1
0009	N24377601-0	35MM KNOB CORE	1
0010	N24377706-0	35MM KNOB LENS	1
0011	N37146111-0	WINDOW LENS	1
0012	N24376001-0	LONG BUTTON 8.0MM	2
0013	N37145706-0	LED LENS	6
0014	N24377301-0	SINGLE BUTTON	6
0015	N21502171-1	LIGHTBOX (WHITE REFLECTOR)	1
0016	N24375701-1	KNOB 18.5MM (BASS,TREBLE,BALANCE)	3
0017	N41520041-0	POINTER	3
0018	N37143306-0	BUTTON LENS	6
0019	N24377401-0	SINGLE LENS BUTTON	6
0020	4152-0791-0	PCB SUPPORT CBS-18R 18MM HIGH	4
0021	N54000831-0	HEATSINK 20MM-HIGH HOLE	3
0022 ▲	N41519461-0	STRAIN RELIEF BUSHING	1
0023	N41321021-0	U-SHORTING BAR 18MM PI	2
0024	N41519431-0	PLATE SWITCH 0.5 PVC	1
0025*AH	N21036004-0	SPK TERM W/O PLUG	2
0025*B,B1,C	2103-6604-1	SPK TERM W PLUG	2
0026*AH	N21070641	ANT-TERMINAL F-TYPE	1
0026*B,B1,C	N21070681	ANT TERMINAL DIN-TYPE	1
0101*AH ▲	N70093100-1	AC CORD	1
0101*B ▲	N70095110-1	AC CORD	1
0101*C ▲	N70093110-1	AC CORD	1
0101*B1 ▲	N70091190-0	AC CORD	1
0102*AH ▲	2103-7701-2	AC OUTLET	1
0103*AH ▲	N41519941-0	AC OUTLET COVER PLATE	1
0201	2954-3008-0000	TAPPING 3X8MM B-TITE (YEL.ZN)	22
0202	2954-3008-3000	TAPPING 3X8MM B-TITE (BLK.ZN)	41
0203	2900-4006-3010	M4X0.5PX6MM W/FLAT WASHER	4
0204	2842-3367-0	METAL WASHER ID=3.3 OD=6.7	4
0205	2904-3006-0000	SCREW M3X6 MM (YEL.ZN)	6
0207	2954-3006-0000	TAPPING 3X6MM B-TITE (YEL.ZN)	6
0208	2904-3010-0000	SCREW M3X10MM (YEL.ZN)	4
0209	2950-3008-0000	TAPPING 3X8 B-TITE PH (YEL.ZN)	4
0210	2601-2608-0601	FIBRE WASHER M2.6 0.8T OD=6	3

<u>Item</u>	<u>Part No</u>	<u>Description</u>	<u>Qty</u>
0213	2904-3004-4000	SCREW M3X4 MM (WHI.ZN)	2
0302	N3714110B-0	LEE FILTER NO217 BLUE DIFFUSER	1
0303	3714-640B-0	LEE FILTER NO202 1/2 CT BLUE	3
0304	N37141006-0	DIFFUSER LENS 1MM PC SHEET	1
0306	2944-3006-3000	SCREW D3X6 S-TITE BH,BK	2
0307	2900-4006-3010	M4X0.5PX6MM W/FLAT WASHER	4
0320	5400-1081-1	HEAT SINK EXTRUSION	2
0321	5400-1121-1	HEAT SINK BAR	1
0330 △	N16600640-0	SHRINKABLE TUBE ID=30 UL/CSA	1
0405	N41519371-1	RUBBER FOOT 14.8MM HIGH	4
0406*B,B1,C	1808-0130-0	FERRITE CORE D19 X T/O	1
FH503-FH507	4131-9131-0	FUSE HOLDER 6.5MM PITCH	10
J101	N21039102-0	2P RCA JACK 1020-060 ORG	1
J201, J209	N21037604-2	4P RCA JACK R/W NI HSP-204V-01	2
J203, J211	N21038506-2	6P RCA JACK R/W NI HSP-206V-01	2
T001 △	N18062120-1	MAIN TRANSFORMER	1
T002 △	N18062096-0	STANDBY TRANSFORMER	1
VR302	N47503676-0	VR-BASS 2X50KC W/WASHER & NUT	1
VR303	N47503646-0	VR-TRE 2X10KC W/WASHER & NUT	1
VR304	N47503656-0	VR-BAL 1X10KW W/WASHER & NUT	1
S801	N52003131-0-01	2P2T SLIDE SW 3.5T22KYGX	1
SW201	N52003121-0-01	2P2T ALPS SPUN W/O FRAME	1
SW301	N52002081-0-01	PUSH BUTTON SW 2P2J ALPS 1 KEY	1

- NOTE :** – The components identified by △ mark are critical for risk of fire and electrical shock.  
 Replace only with part number specified.
- <\*AH> : USA, Canadian model only.
  - <\*B> : UK model only.
  - <\*B1> : Australian model only.
  - <\*C> : European model only.

## ELECTRICAL PARTS LIST

<b>Reference No</b>	<b>Part Number</b>	<b>Description</b>
<b><u>SWITCH ASSEMBLY</u></b> <b><i>PC BOARD</i></b>		
<b><i>SWITCH</i></b> S502	MI-21490G-01-S N52003031-0-01	SWITCH ASSEMBLY SLIDE SWITCH 5.2T22SS28G10
<b><u>MOTOR POT ASSEMBLY</u></b> <b><i>PC BOARD</i></b>		
<b><i>CAPACITOR</i></b> C901	MI-21480F-01-S 157D-106M-5-II	MOTOR POT ASSEMBLY CE 16V 10µF 20%
<b><i>IC</i></b> IC901A	N31303410-0	IC LB1642 SANYO MOTOR DRIVER
<b><u>VARIABLE RESISTORS</u></b> VR901A	4750-3860-0	MOTOR POT 50KAX2 VOL
<b><u>HEADPHONE ASSEMBLY</u></b> <b><i>PC BOARD</i></b>		
<b><i>PHONE JACK</i></b> W401	MI-21490C-01-S 2113-1011-0	HEADPHONE ASSEMBLY PHONE JACK 6312-03-070 W/CLIP
<b><u>ANTENNA ASSEMBLY</u></b> <b><i>PC BOARD</i></b>		
*AH *B,B1,C	MI-21490H-01-S MI-21490H-02-S	ANTENNA ASSEMBLY ANTENNA ASSEMBLY
<b><u>LAMP ASSEMBLY</u></b> <b><i>PC BOARD</i></b>		
<b><i>LAMP</i></b> LP901-LP902	MI-21490J-01-S 2450-0716-0	LAMP ASSEMBLY LAMP 12V 90MA 5X10MM
<b><u>SPEAKER OUTPUT TERMINAL</u></b> <b><i>PC BOARD</i></b>		
*AH *B,B1,C	MI-21480E-01-S MI-21480E-02-S	SPEAKER ASSEMBLY SPEAKER ASSEMBLY

<b>Reference No</b>	<b>Part Number</b>	<b>Description</b>
<b>MAINS ASSEMBLY</b>		
<b>PC BOARD</b>		
*AH	MI-21480D-01-S	MAINS ASSEMBLY
*B,B1,C	MI-21480D-02-S	MAINS ASSEMBLY
<b>DIODE</b>		
D001	4804-1480-C	DIODE 1N4148
<b>CAPACITORS</b>		
C001-C002	△ N89100049-0	CAP400V 4700P DE7150F472MVA1KC
<b>RESISTOR</b>		
*AH	4705-275J-2	RCF 2.7M Ohm 1/4W 5% (DISCHARGE)
<b>TRANSISTOR</b>		
Q001	N4851815Y-5	TR 2SC1815-Y HFE 120-240
<b>RELAY</b>		
RLY1	△ N45000110-0	RELAY 12V DC TAIKO DGX1-12M
<b>SWITCH</b>		
SW1	△ 5200-3481-0	POWER SW TV-3 3A/250V
<b>FRONT PANEL ASSEMBLY</b>		
<b>PC BOARD</b>		
	MI-21480B-01-S	FRONT PANEL ASSEMBLY
<b>CAPACITORS</b>		
C01	157F-105M-5-IU	CE 50V 1µF 20%
C04	153I-474J-9-NO	CM 63V 0.47µF 5%
<b>RESONATOR</b>		
CR01	N27030120-0	CERAMIC RESONATOR CSA 4.91MG
<b>DIODES</b>		
D001,D003	4804-1480-C	DIODE 1N4148
D04	N37003512-G	LED GREEN (L-424GDT)3MM
D05-D06	N37003513-Y	LED AMBER (L-424YDT)3MM
D07-D09	N37003512-G	LED GREEN (L-424GDT)3MM
D015-D017	4804-1480-C	DIODE 1N4148
<b>ICS</b>		
IC01	3130-4250-0	IC TMS77C82 OTP PROGRAMMED
IC02	N31303420-0	IC LC7582A SANYO LCD DRIVER
IC03	N31303600-0	MC14094BCP 8-BIT SIPO SR 3S
IC04	N31303450-0	IC X24C01P XICOR EEPROM
IC05	N89100033-0	IR RX KODENSHI HC-341F
<b>LCD DISPLAY</b>		
LCD01	N24601010-0	LCD DISPLAY
<b>TRANSISTORS</b>		
Q01	N4851815Y-5	TR 2SC1815-Y HFE 120-240
Q02-Q03	N48600660-5	TR 2SA1015GR

<b>Reference No</b>	<b>Part Number</b>	<b>Description</b>
<b>SWITCHES</b>		
SW1-SW4	N52003201-0-01	TACT LED GREEN SKWQFG ALPS
SW5	N52003231-0-01	TACT LED AMBER SKHQFH ALPS
SW6	N52003201-0-01	TACT LED GREEN SKWQFG ALPS
SW8-SW13	N52003241-0-01	TACT NO LED SKHQAC ALPS
<b>TUNER &amp; MAIN ASSEMBLY</b>		
<b>PC BOARD</b>		
*AH	MI-21490A-01-S	TUNER & MAIN ASSEMBLY
*B,B1,C	MI-21490A-02-S	TUNER & MAIN ASSEMBLY
<b>CAPACITORS</b>		
C126	153F-473K-4-RY	CM 50V 0.047µF 10%
C132*AH	150F-470J-5-IF	CC 50V 47pF 5%
C132*B,B1,C	150F-390J-5-GG	CC 50V 39pF 5%
C209-C210	157D-106M-5-IU	CE 16V 10µF 20%
C216-C217	157D-106M-5-IU	CE 16V 10µF 20%
C227-C230	157D-106M-5-IU	CE 16V 10µF 20%
C233-C234	157D-106M-5-IU	CE 16V 10µF 20%
C237-C240	157D-106M-5-IU	CE 16V 10µF 20%
C243-C244	157D-106M-5-IU	CE 16V 10µF 20%
C280-C281	157D-106M-5-IU	CE 16V 10µF 20%
C301-C304	157D-106M-5-IU	CE 16V 10µF 20%
C305-C306	157D-476M-5-KW	CE 16V 47µF 20%
C307-C308	157D-107M-5-KW	CE 16V 100µF 20%
C309-C310	153F-823J-5-SY	CM 50V 0.082µF 5%
C311-C312	153I-474J-9-NO	CM 63V 0.47µF 5%
C313-C314	153F-183J-5-KP	CM 50V 0.018µF 5%
C315-C316	153F-104J-5-SY	CM 50V 0.1µF 5%
C401-C402	157D-106M-5-IU	CE 16V 10µF 20%
C405-C406	153F-152J-5-KW	CM 50V 1500pF 5%
C407-C408	153F-821J-5-HS	CM 50V 820pF 5%
C409-C410	157D-476M-5-KW	CE 16V 47µF 20%
C411-C412	153F-102J-5-IM	CM 50V 1000pF 5%
C415-C416	157C-228M-5-S9	CE 10V 2200µF 20%
C417-C418	153F-104J-5-SY	CM 50V 0.1µF 5%
C427-C428	157E-476M-5-IU	CE 25V 47µF 20%
C429-C432	153F-104J-5-SY	CM 50V 0.1µF 5%
C447-C448	15CH-300J-5-IG	CC 50V 30pF 5% NPO
C508-C509	N89100029-0	CE 50V 6800µF 20%
C516-C517	157I-477M-5-X&	CE 63V 470µF 20%
C518-C519	157F-227M-5-S5	CE 50V 220µF 20%
C522	157F-106M-5-IU	CE 50V 10µF 20%
C523	157F-476M-5-OW	CE 50V 47µF 20%
C526-C527	157F-227M-5-S5	CE 50V 220µF 20%
C540	157E-477Z-5-S5	CE 25V 470µF +80/-20%
C541-C543	157F-105M-5-IU	CE 50V 1µF 20%
C544-C545	157F-106M-5-IU	CE 50V 10µF 20%
C546	157D-106M-5-IU	CE 16V 10µF 20%
C701	1551-0210-0	TRIMCAP 5.2-30P TZ03R300FR MUR
C703	157B-107M-5-KM	CE 6.3V 100µF 20%
C704	157F-107M-5-OW	CE 50V 100µF 20%
C705	157F-335M-5-IU	CE 50V 3.3µF 20%
C707	157F-474M-5-IU	CE 50V 0.47µF 20%
C709	157Q-474M-5-IU	CE 35V 0.47µF 20%
C711	158F-101J-5-KW	CP 50V 100pF 5%
C712	157D-106M-5-IU	CE 16V 10µF 20%

<b>Reference No</b>	<b>Part Number</b>	<b>Description</b>
C721	1551-0210-0	TRIMCAP 5.2-30P TZ03R300FR MUR
C725	157D-106M-5-IU	CE 16V 10µF 20%
C726	157F-475M-5-IU	CE 50V 4.7µF 20%
C733	157F-335M-5-IU	CE 50V 3.3µF 20%
C738	157F-335M-5-IU	CE 50V 3.3µF 20%
C739	158F-101J-5-KW	CP 50V 100pF 5%
C741	157D-107M-5-KW	CE 16V 100µF 20%
C742	157F-104M-5-IU	CE 50V 0.1µF 20%
C743	157D-106M-5-IU	CE 16V 10µF 20%
C744	158F-391J-5-KW	CP 50V 390pF 5%
C745	157D-476M-5-IU	CE 16V 47µF 20%
C746	157D-107M-5-KW	CE 16V 100µF 20%
C747	157F-105M-5-IU	CE 50V 1µF 20%
C748	157F-224M-5-IU	CE 50V 0.22µF 20%
C749-C750	157F-105M-5-IU	CE 50V 1µF 20%
C751	157D-106M-5-IU	CE 16V 10µF 20%
C752-C753*AH	158F-911J-5-KW	CP 50V 910pF 5%
C752-C753*B,B1,C	158E-421J-5-KW	CP 25V 420pF 5%
C754-C755	153F-152J-5-KW	CM 50V 1500pF 5%
C756-C757	157D-476M-5-IU	CE 16V 47µF 20%
C801	157C-226M-5-IM	CE 10V 22µF 20%
C803-C804	157C-226M-5-IM	CE 10V 22µF 20%
C806	157C-226M-5-IM	CE 10V 22µF 20%
<b>DIODES</b>		
D202-D203	4804-1480-2	DIODE 1N4148
D403-D404	4804-1480-2	DIODE 1N4148
D411-D412	4804-1480-2	DIODE 1N4148
D505-D508	4805-4010-1	DIODE 1N5401
D511	N48400470-0	BRIDGE RECTIFIER RS102 100V 1A
D513	4837-24B4-2	ZD 0.5W 27V
D515,D517*AH	635N-0001-0	JUMPER #23 TAPE & WHEEL
D516*AH	471A-330J-1-X	RFP 33 Ohm 3W 5%
D518*AH	471A-470J-1-X	RFP 47 Ohm 3W 5%
D515-D518*B,B1,C	4840-1140-0	ZD 1.3W 3.3V 5%
D520	4840-0810-0	BRIDGE DIODE RB154 400V 1.5A
D521	4837-33V0-2	ZD 1/2W 33V (32.2-33.6)
D701-D702	N4801N60P-1	GERMANIUM DIODE IN60P
D703-D704	484C-321D-5	SVC321-D AM CAR. DIODE
D705-706	4804-1480-2	DIODE 1N4148
D801-D804	4804-1480-2	DIODE 1N4148
D805-D806	4837-8C20-2	ZD 1/2W 11.1-11.6V
<b>ICS</b>		
IC201	N31303710-0	IC TC 9163N HV ANALOG SW
IC202	N31303560-0	IC NJM072 (D)
IC203-IC204	3130-0890-0	IC NJM4558D DUAL OP AMP
IC301	N31303660-0	IC NJM2068D DUAL LN-OP AMP
IC501	3130-2020-3	IC L7805 5V REGULATOR
IC502	N31302520-1	IC L7812 12V REGULATOR
IC503	3130-3520-1	IC L7912CV -12V REGULATOR
IC701	N31303430-0	IC LM7000 SANYO DTS
IC702*AH	N89100034-0	TUNER MODULE MITSUMI FE407-A16
IC702*B,B1,C	1300-0606-0	FM TUNER MODULE FE407-G58
IC703	N31303390-0	IC LA1266 SANYO FM/AM TUNER
IC704	N31303400-0	IC LA3401 PLL MPX


<b>Reference No</b>	<b>Part Number</b>	<b>Description</b>
<b>FILTERS &amp; INDUCTORS</b>		
FL1-FL3*AH	N27010546-1-0	CF SFE 10.7 ML-A
FL1-FL3*B,B1,C	N27010556-1-0	CF SFE 10.7 MZ2-A
FL703	N56002296-S	FTZ COIL SUMIDA
FL704-FL705	N56002236-S	19KHZ FILTER COIL
FL706	2701-0066-0	CF SFZ450G
L401-L402	1804-0540-0	SPRING COIL 1μH
L701, L703	1801-2R2M-M	INDUCTOR 2.2μH 20%
L702*B,B1,C	2701-0609-4	BPF BPEB1
L704	N56002276-S	AM RF COIL
L705	N56002286-S	AM OSC COIL
L706	N56002256-S	FM QUAD COIL PRIMARY
L707	N56002266-S	FM QUAD COIL SECONDARY
L708	N56002246-S	AM IF COIL
L710	N1801680M-M	INDUCTOR 68μH 20%
<b>TRANSISTORS</b>		
Q005-Q009	485C-930E-5	TR 2SC930E HFE 100-200
Q200, Q304	4860-0700-5	TR 2SC1815GR
Q201, Q303	N4851015Y-5	TR 2SA1015-Y HFE 100-200
Q202-Q203	N485363BL-5	TR N-FET 2SK-363
Q301-Q302	N48600770-5	TR 2SC2878 (A,B)
Q401-Q402	N485C550C-5	TR BC550C
Q403-Q406	N485C556B-5	TR BC556B
Q407-Q410	N485D1390-5	TR BD139-10 PHILIPS HFE63-160
Q411-Q412, Q507	N485669AC-5	TR 2SD669A-C
Q413-Q414, Q508	N485649AC-5	TR 2SB649A-C HFE 100-200
Q415-Q416	N48600730-5	TR 2SC3519 (0,P,Y)
Q417-Q418	N48600690-5	TR2SA1386 (0,P,Y)
Q509, Q701-Q703, Q710-Q713	4860-0700-5	TR 2SC1815GR
Q510	N4851015Y-5	TR 2SA1015-Y HFE 100-200
Q521	N485C546B-5	TR BC546B
Q704, Q714	N48600660-5	TR 2SA1015GR
<b>RESISTORS</b>		
R162*AH	4705-220J-2	RCF 22 Ohm 1/4W 5%
R162*B,B1,C	4715-100J-2-F	RFU 10 Ohm 1/4W 5%
R437-R438*AH	4705-680J-2	RCF 68 Ohm 1/4W 5%
R437-R438*B,B1,C	4715-470J-2-F	RFU 47 Ohm 1/4W 5%
R457-R458	N4718100J-L-F	RFU 10 1W 5%
R463-R464	N47183R3J-2-F	RFU 3.3 1W 5%
R465-R466*AH	635N-0001-0	JUMPER #23 TAPE & WHEEL
R465-R466*B,B1,C	4715-220J-2-F	RFU 22 Ohm 1/4W 5%
R467-R470	N4719R22J-1	RCE 0.22 2W 5%
R511	N4718100J-L-F	RFU 10 1W 5%
R512*AH	N4715101J-2-P	RFP 100 2W 5%
R512*B,B1,C	4718-101J-1-F	RFU 100 Ohm 1W 5%
R707*AH	4705-101J-2	RCF 100 Ohm 1/4W 5%
R707*B,B1,C	4715-470J-2-F	RFU 47 Ohm 1/4W 5%
R735*AH	4705-103J-2	RCF 10K Ohm 1/4W 5%
R735*B,B1,C	4705-432J-2	RCF 4.3K Ohm 1/4W 5%
R752*AH	4705-220J-2	RCF 22 Ohm 1/4W 5%
R752*B,B1,C	4715-100J-2-F	RFU 10 Ohm 1/4W 5%
R756-R757*AH	4705-823J-2	RCF 82K Ohm 1/4W 5%

<b>Reference No</b>		<b>Part Number</b>	<b>Description</b>
R756-R757*B,B1,C		4705-124J-2	RCF 120K Ohm 1/4W 5%
R901	△	4718-470J-1-X	RFP 47 Ohm 1W 5%
R920*AH		4705-750J-2	RCF 75 Ohm 1/4W 5%
R920*B,B1,C		4705-390J-2	RCF 39 Ohm 1/4W 5%
R925*AH		4705-331J-2	RCF 330 Ohm 1/4W 5%
R925*B,B1,C		4705-152J-2	RCF 1.5K Ohm 1/4W 5%
R928*AH		4705-220J-2	RCF 22 Ohm 1/4W 5%
R928*B,B1,C	△	4715-100J-2-F	RFU 10 Ohm 1/4W 5%
R933*AH		4705-220J-2	RCF 22 Ohm 1/4W 5%
R933*B,B1,C	△	4715-100J-2-F	RFU 10 Ohm 1/4W 5%
R935*AH		4705-331J-2	RCF 330 Ohm 1/4W 5%
R935*B,B1,C		4705-152J-2	RCF 1.5K Ohm 1/4W 5%
<b>TRIMMER RESISTORS</b>			
R411-R412		4756-2216-3-06	SVR 220 H3 7X7.6
R443-R444		4756-2216-3-06	SVR 220 H3 7X7.6
R736		N47562240-3-11	SVR 220K H3 10X10
RR742		N47561040-3-11	SVR 100K H3 10X10
R753		N47563330-3-11	SVR 33K H3 10X10
<b>BREAKERS</b>			
E401-E402	△	8910-0088-0	BREAKER 2.5A A-25
<b>FUSES</b>			
F503-F504*AH	△	5120-0019-0	FUSE 4A 125V TIME LAG LBC UL/CSA
F505-F507*AH	△	5120-0026-0	FUSE 315mA 250V TIME LAG LBC UL/CSA
F503-F504*B,B1,C	△	5120-0017-0	FUSE 4A 250V TIME LAG HBC SEMKO/VDE
F505-F507*B,B1,C	△	5120-0027-0	FUSE 315mA 250V TIME LAG LBC SEMKO/VDE
<b>RESONATOR</b>			
X102		2703-0020-0	CR RESONATOR CSB456F11
<b>CRYSTAL</b>			
X701		N23000440-0	CRYSTAL 7.2MHZ 20PPM

**NOTE :** – The components identified by △ mark are critical for risk of fire and electrical shock.  
 Replace only with part number specified.

- <\*AH > : USA, Canadian model only.
- <\*B > : UK model only.
- <\*B1 > : Australian model only.
- <\*C > : European model only.
- Capacitors : CP-Polystyrene, CM-Mylar, CE-Electrolytic, CC-Ceramic.
- Resistors : RMF-Metal Film, RFU-Fusible, RCF-Carbon Film, RCE-Ceramic Case, RFP-Flame Proof.

## PACKING DIAGRAM



## PACKING LIST

<u>Item</u>	<u>Part No</u>	<u>Description</u>	<u>Qty</u>
1	1490-1843-1	POLYFOAM END CAP	2
2	N14971332-1	UNIT POLYBAG	1
3	N14971442-0	FASCIA COVER	1
4	4301-3587-1	INSTRUCTION MANUAL	1
5	N14763601-0	CARTON BOX	1
6	4060-0580-0	BATTERIES	2
7	8900-1070-0	REMOTE CONTROL	1
8	1497-1302-0	ACCESSORIES POLYBAG	1
9	N14971062-0	MANUAL POLYBAG	1
10*AH	N21036101-0	RF CONNECTOR PLUG F-Type	1
10*B,B1,C	N21036201-0	RF CONNECTOR PLUG DIN-Type	1
11	N21070661-1	300-OHM T ANTENNA	1
12	N70093220-0	200CM WHITE AWG22	1

NOTE : <<sup>\*</sup>AH> : USA, Canadian model only.

<<sup>\*</sup>B> : UK model only.

<<sup>\*</sup>B1> : Australian model only.

<<sup>\*</sup>C> : European model only.

Proprietary information for servicing purposes only. The information herein may not be used commercially without the prior written agreement of NAD Electronics Ltd., London, England.