

DENON

Ver. 2

Please refer to the
MODIFICATION NOTICE.

SERVICE MANUAL

MODEL	JP	E3	E2	EK	E2A	E1C	E1K	EUT
DBP-1610		✓						

BLU-RAY DISC/DVD VIDEO PLAYER

- For purposes of improvement, specifications and design are subject to change without notice.
- Please use this service manual with referring to the operating instructions without fail.
- Some illustrations using in this service manual are slightly different from the actual set.

DENON

D&M Holdings Inc.

SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Before returning the unit to the customer, make sure you make either (1) a leakage current check or (2) a noise to chassis resistance check. If the leakage current exceeds 0.5 mA, or if the resistance from chassis to ether side of the power cord is less than 460 kohms, the unit is defective.

LASER RADIATION

Cat on - Class 1M vs be and never be laser radiation when open.
Do not view directly instruments.

CAUTION

Please heed the points listed below during servicing and inspection.

◎ **Heed the cautions!**

Spots requiring particular attention when servicing, such as the cabinet parts, chassis, etc., have cautions indicated on labels. Be sure to heed these cautions and the cautions indicated in the handling instructions.

◎ **Caution concerning electric shock!**

- (1) An AC voltage is impressed on the set, so touching internal metal parts when the set is energized could cause electric shock. Take care to avoid electric shock, by for example using an isolation transformer and gloves when servicing the set is energized, unplugging the power cord when replacing parts, etc.
- (2) There are high voltage parts inside. Handle with extra care when the set is energized.

◎ **Caution concerning disassembly and assembly!**

Through great care is taken when manufacturing parts from sheet metal, there may in some rare cases be burrs on the edges of parts which could cause injury if fingers are moved across them. Use gloves to protect your hands.

◎ **Only use designated parts!**

The set's parts have specific safety properties (resistance, voltage resistance, etc.). For replacement parts, be sure to use parts which have the same properties. In particular, for the important safety parts that are marked \triangle on wiring diagrams and parts lists, be sure to use the designated parts.

◎ **Be sure to mount parts and arrange the wires as they were originally!**
For safety reasons, some parts use tape, tubes or other insulation materials, and some parts are mounted away from the surface of printed circuit boards. Care is also taken with the positions of the wires outside and clamps are used to keep wires away from heating and high voltage parts, so be sure to set everything back as it was originally.

◎ **Inspect for safety after servicing!**

Check that all screws, parts and wires removed or disconnected for servicing have been put back in their original positions, inspect that no parts around the area that has been serviced have been negatively affected, conduct an inspection on the external metal connectors and between the bases of the power plug, and otherwise check that safety is ensured.

(Insulation check procedure)
Unplug the power cord from the power outlet, disconnect the antenna, plugs, etc., and turn the power switch on. Using a 500V insulation resistance tester, check that the input and the externally exposed metal parts (antenna terminal, headphones terminal, input terminal, etc.) is $1M\Omega$ or greater. If it is less, the set must be inspected and repaired.





CAUTION Concerning important safety parts

Many of the electrical and structural parts used in the set have specific safety properties. In most cases these properties are difficult to distinguish by sight, and using replacement parts with higher ratings (rated power and withstand voltage) does not necessarily guarantee that safety performance will be preserved. Parts with safety properties are indicated as shown below on the wiring diagrams and parts lists in service manual. Be sure to replace them with parts with the designated part number.

- (1) Schematic diagrams Indicated by the \triangle mark.
- (2) Parts lists Indicated by the \triangle mark.

Using parts other than the designated parts could result in electric shock, fires or other dangerous situations.

DIMENSION ▲




WIRE ARRANGEMENT

If wires are untied or moved to perform adjustment or parts replacement etc., be sure to rearrange them neatly as they were originally bunched or packed afterward.

Otherwise, incorrect arrangement can be a cause of noise generation.

Wire arrangement viewed from the top



SPECIFICATIONS

SIGNAL SYSTEM	NTSC color
APPLICABLE DISCS	
(1)	BD/DVD-Video Discs 1-layer 12cm single-sided discs, 2-layer 12cm single-sided discs, 2-layer 12cm double-sided discs (1 layer per side)
(2)	BD-RE/BD-R (Recorded in BD MV format) 1-layer 12cm single-sided discs, 2-layer 12cm single-sided discs 1-layer 8cm single-sided discs, 2-layer 8cm single-sided discs
(3)	DVD-R 1-layer 12cm single-sided discs, 2-layer 12cm single-sided discs 1-layer 8cm single-sided discs, 2-layer 8cm single-sided discs
(4)	DVD-RW 1-layer 12cm single-sided discs 1-layer 8cm single-sided discs
(5)	Compact discs (audio CD) 12cm discs, 8cm discs
(6)	CD-RW/R 12cm discs, 8cm discs
APPLICABLE MEMORY CARDS	
(1)	SD Memory Card
(2)	SDHC Memory Card
(3)	miniSD Card
(4)	microSD Card
VIDEO OUTPUT	
	Y output level: 1Vp-p (75Ω/ohms) Output connectors: Pin jack, 1 set
COMPONENT OUTPUT	
	Y output level: 1Vp-p (75Ω/ohms) PB/CB output level: 0.7Vp-p (75Ω/ohms) PR/CR output level: 0.7Vp-p (75Ω/ohms) Output connectors: Pin jacks, 1 set
HDMI OUTPUT	
	Output jack: 19-pin HDMI terminal, 1 set HDMI ver. 1.3a (Deep Color, Dolby Digital Plus, Dolby TrueHD, DTS-HD)
ETHERNET TERMINAL	
	10BASE-T/ 100BASE-TX

ANALOG AUDIO OUTPUT

Output level: 2Vrms (10kΩ/kohms)

2 channel (L, R) output connector: Pin jacks, 1 set

AUDIO OUTPUT PROPERTIES

- (1) Frequency response
 - 1 BDs (linear PCM) : 20Hz to 22kHz (48kHz sampling)
: 20Hz to 44kHz (96kHz sampling)
: 20Hz to 88kHz (192kHz sampling)
 - 2 DVDs (linear PCM) : 20Hz to 22kHz (48kHz sampling)
: 20Hz to 44kHz (96kHz sampling)
: 20Hz to 88kHz (192kHz sampling)
 - 3 CDs : 20Hz to 20kHz
(2) S/N ratio : 115dB
 - (3) Total harmonic distortion : 1kHz 0.004%
 - (4) Dynamic range : 100dB (BD/DVD) / 98dB (CD)

DIGITAL AUDIO OUTPUT

Coaxial digital output: Pin jack, 1 set

POWER SUPPLY

AC 120V, 60Hz

POWER CONSUMPTION

30W (Standby: 0.6W)

MAXIMUM EXTERNAL DIMENSIONS

W : 435mm (17-3/16")
H : 106mm (4-3/16")
D : 309.3mm (12-3/16")
(including protruding parts)

MASS

4.1 kg (9.1 lbs)

REMOTE CONTROL

RC-11128

Infrared pulse type

Supply: DC 3V, 2 R6/AA batteries

External dimensions:

W : 52mm (2-1/16")

H : 227mm (8-15/16")


D : 30mm (1-3/16")

Mass: 138g (0.3 lbs) (including batteries)

- For purposes of improvement, specifications and design are subject to change without notice.

LASER BEAM SAFETY PRECAUTIONS


This BD player uses a pickup that emits a laser beam.



Do not look directly at the laser beam coming from the pickup or allow it to strike against your skin.

The laser beam is emitted from the location shown in the figure. When checking the laser diode, be sure to keep your eyes at least 30 cm away from the pickup lens when the diode is turned on. Do not look directly at the laser beam.

CAUTION: Use of controls and adjustments, or doing procedures other than those specified herein, may result in hazardous radiation exposure.



CAUTION - LASER RADIATION WHEN OPEN. DO NOT STARE INTO BEAM. (FDA 21 CFR Class II)
CAUTION - CLASS 2 LASER RADIATION WHEN OPEN DO NOT STARE INTO THE BEAM (IEC60825-1/Class 2) ATTENTION - RAYONNEMENT LASER DE CLASSE 2 EN CAS D'OUVERTURE NE PAS REGARDER DANS LE FAISCEAU - ここを覗くとクラス2のレーザー放射が出来る ビームを見るのは危険なことです
注意

Location: Inside Top of BD mechanism.

Safety Check after Servicing

Examine the area surrounding the repaired location for damage or deterioration. Observe that screws, parts, and wires have been returned to their original positions. Afterwards, do the following tests and confirm the specified values to verify compliance with safety standards.

1. Clearance Distance

When replacing primary circuit components, confirm specified clearance distance (d) and (d') between soldered terminals, and between terminals and surrounding metallic parts. (See Fig. 1.)

Table 1: Ratings for selected area

AC Line Voltage	Clearance Distance (d), (d')
120 V	$\geq 3\text{mm}(d)$ $\geq 4\text{mm}(d')$

Note: This table is unofficial and for reference only. Be sure to confirm the precise values.




Fig. 1

2. Leakage Current Test

Confirm the specified (or lower) leakage current between B (earth ground, power cord plug prongs) and externally exposed accessible parts (RF terminals, antenna terminals, video and audio input and output terminals, microphone jacks, earphone jacks, etc.) is lower than or equal to the specified value in the table below.

Measuring Method (Power ON):

Insert load Z between B (earth ground, power cord plug prongs) and exposed accessible parts. Use an AC voltmeter to measure across the terminals of load Z. See Fig. 2 and the following table.




Fig. 2

Table 2: Leakage current ratings for selected areas


AC Line Voltage	Load Z	Leakage Current (i)	One side of power cord plug prongs (B) to:
120 V	2kΩ RES. Connected in parallel	$i \leq 0.7\text{mA}$ AC Peak $i \leq 2\text{mA}$ DC	RF or Antenna terminals
	50kΩ RES. Connected in parallel	$i \leq 0.7\text{mA}$ AC Peak $i \leq 2\text{mA}$ DC	A/V Input, Output

Note: This table is unofficial and for reference only. Be sure to confirm the precise values.


STANDARD NOTES FOR SERVICING

Circuit Board Indications


1. The output pin of the 3 pin Regulator ICs is indicated as shown.



2. For other ICs, pin 1 and every fifth pin are indicated as shown.




3. The 1st pin of every male connector is indicated as shown.



Instructions for Connectors

1. When you connect or disconnect the FFC (Flexible Foil Connector) cable, be sure to first disconnect the AC cord.
2. FFC (Flexible Foil Connector) cable should be inserted parallel into the connector, not at an angle.



* Be careful to avoid a short circuit.

Pb (Lead) Free Solder

When soldering, be sure to use the Pb free solder.

How to Remove / Install Flat Pack-IC

1. Removal

With Hot-Air Flat Pack-IC Desoldering Machine:

1. Prepare the hot-air flat pack-IC desoldering machine, then apply hot air to the Flat Pack-IC (about 5 to 6 seconds). (Fig. S-1-1)




Fig. S-1-1

2. Remove the flat pack-IC with tweezers while applying the hot air.

3. Bottom of the flat pack-IC is fixed with glue to the CBA; when removing entire flat pack-IC, first apply soldering iron to center of the flat pack-IC and heat up. Then remove (glue will be melted). (Fig. S-1-6)
4. Release the flat pack-IC from the CBA using tweezers. (Fig. S-1-6)



CAUTION:

1. The Flat Pack-IC shape may differ by models. Use an appropriate hot-air flat pack-IC desoldering machine, whose shape matches that of the Flat Pack-IC.
2. Do not supply hot air to the chip parts around the flat pack-IC for over 6 seconds because damage to the chip parts may occur. Put masking tape around the flat pack-IC to protect other parts from damage. (Fig. S-1-2)


3. The flat pack-IC on the CBA is affixed with glue, so be careful not to break or damage the foil of each pin or the solder lands under the IC when removing it.

With Soldering Iron:

1. Using desoldering braid, remove the solder from all pins of the flat pack-IC. When you use solder flux which is applied to all pins of the flat pack-IC, you can remove it easily. (Fig. S-1-3)



2. Lift each lead of the flat pack-IC upward one by one, using a sharp pin or wire to which solder will not adhere (iron wire). When heating the pins, use a fine tip soldering iron or a hot air desoldering machine. (Fig. S-1-4)





3. Bottom of the flat pack-IC is fixed with glue to the CBA; when removing entire flat pack-IC, first apply soldering iron to center of the flat pack-IC and heat up. Then remove (glue will be melted). (Fig. S-1-6)
4. Release the flat pack-IC from the CBA using tweezers. (Fig. S-1-6)

With Iron Wire:

2. Installation

1. Using desoldering braid, remove the solder from all pins of the flat pack-IC. When you use solder flux which is applied to all pins of the flat pack-IC, you can remove it easily. (Fig. S-1-3)
2. Affix the wire to a workbench or solid mounting point, as shown in Fig. S-1-5.
3. While heating the pins using a fine tip soldering iron or hot air blower, pull up the wire as the solder melts so as to lift the IC leads from the CBA contact pads as shown in Fig. S-1-5.
4. Bottom of the flat pack-IC is fixed with glue to the CBA; when removing entire flat pack-IC, first apply soldering iron to center of the flat pack-IC and heat up. Then remove (glue will be melted). (Fig. S-1-6)
5. Release the flat pack-IC from the CBA using tweezers. (Fig. S-1-6)

Note: When using a soldering iron, care must be taken to ensure that the flat pack-IC is not being held by glue. When the flat pack-IC is removed from the CBA, handle it gently because it may be damaged if force is applied.



Instructions for Handling Semiconductors


Electrostatic breakdown of the semi-conductors may occur due to a potential difference caused by electrostatic charge during unpacking or repair work.

1. Ground for Human Body


Be sure to wear a grounding band ($1 M\Omega$) that is properly grounded to remove any static electricity that may be charged on the body.

2. Ground for Workbench

Be sure to place a conductive sheet or copper plate with proper grounding ($1 M\Omega$) on the workbench or other surface, where the semi-conductors are to be placed. Because the static electricity charge on clothing will not escape through the body grounding band, be careful to avoid contacting semi-conductors with your clothing.



<Incorrect>




<Correct>

CABINET DISASSEMBLY INSTRUCTIONS

1. Disassembly Flowchart

This flowchart indicates the disassembly steps to gain access to item(s) to be serviced. When reassembling, follow the steps in reverse order. Bend, route, and dress the cables as they were originally.



ID/ Loc. No.	Part	Fig. No.	Remove/*Unhook/ Unlock/Release/ Unplug/Desolder	Note
[11]	Remote Jack CBA	D4	*CN5501	---
[12]	Audio CBA	D5	6(S-13), *CN2005, *CN2007, *CN2008	---
[13]	Video CBA	D6	4(S-14), *CN7101	---
[14]	AV PCB Bracket	D6	4(S-15)	---
	BD Main CBA & BD Mechanism Assembly	D6	4(S-16), *CN6001, *CN7601	3
[15]				
[16]	Loader Bracket	D6	6(S-17)	---
[17]	Power Supply CBA	D7	2(S-18), 2(S-19)	---
[18]	Power Holder	D7	3(S-20)	---
(1)		(2)	(3)	(4)
				(5)

Note:

- (1) Identification (location) No. of parts in the figures
- (2) Name of the part
- (3) Figure Number for reference
- (4) Identification of parts to be removed, unhooked, unlocked, released, unplugged, unclamped, or desoldered.
P = Spring, L = Locking Tab, S = Screw,
CN = Connector
* = Unhook, Unlock, Release, Unplug, or Desolder
e.g. 2(S-2) = two Screws (S-2),
2(L-2) = two Locking Tabs (L-2)
- (5) Refer to "Reference Notes."

2. Disassembly Method

ID/ Loc. No.	Part	Fig. No.	Remove/*Unhook/ Unlock/Release/ Unplug/Desolder	Note
[1]	Top Cover	D1	9(S-1)	---
[2]	Tray Panel	D2	-----	1
[3]	Front Assembly	D2	*5(L-1), *3(L-2), 9(S-2), *CN2002	2
[4]	Front A CBA	D2	*CN3001	---
[5]	Front B CBA	D2	-----	---
[6]	Front Bracket	D3	7(S-3), (S-4)	---
[7]	SD CBA	D3	2(S-5), *CN5001	---
[8]	Rear Panel	D4	5(S-6), (S-7), 2(S-8), (S-9), (S-10), 8(S-11), 2(S-12), *CN1006	---
[9]	Motor DC Fan	D4	-----	---
[10]	Inlet CBA	D4	*CN1001	---

When tightening screws, tighten them with the following torque.

Torque
0.45 ± 0.05 N·m

Reference Note

1. How to remove tray panel

- 1) Connect the wall plug to an AC outlet and press the [▲] button to open the tray.
- 2) To lift up, the tray panel is removed.
- 3) Press the [▲] button again to close the tray.
- 4) Press the [ON/STANDBY] button to turn the power off.
- 5) Unplug an AC cord.

2. **CAUTION:** Locking Tabs (L-1) and (L-2) are fragile. Be careful not to break them.

3. The BD Main CBA & BD Mechanism Assembly is adjusted as a unit at factory. Therefore, do not disassemble it. Replace the BD Main CBA & BD Mechanism Assembly as a unit.






Fig. D3




Fig. D6




Fig. D4




Fig. D5





Fig. D7

3. How to Eject Manually

1. Remove the Top Cover.
2. Insert a screwdriver, etc. into the straightly so that the Portion A is pushed.
3. Pull the tray out manually and remove a disc.



HOW TO INITIALIZE THE BLU-RAY DISC PLAYER

To put the program back at the factory-default, initialize the BD player as the following procedure.

1. Turn the power on.
2. Remove the disc on the tray and close the tray.
3. Press [1], [2], [3], [4], and [DISPLAY] buttons on the remote control unit in that order.

Fig. a appears on the screen.




Fig. a

4. Press [■] button on the remote control unit.

Fig. b appears on the screen and Fig. c appears on the VFD.




Fig. b

CLEAR

Fig. c

5. To exit this mode, press [POWER OFF] button.

FIRMWARE RENEWAL MODE

Note: The file extension of the available firmware is “b20”.

1. Turn the power on and remove the disc on the tray and close the tray.
 2. To put the BD player into version up mode, press [9], [8], [7], [6], and [POP UP MENU/MENU] buttons on the remote control unit in that order. The tray will open automatically.
- Fig. a appears on the screen and Fig. b appears on the VFD.




Fig. a Version Up Mode Screen




Fig. b VFD in Version Up Mode

3. Load the disc for version up.
4. The BD player enters the F/W version up mode automatically. Fig. c appears on the screen and Fig. d appears on the VFD. Make sure to insert the proper F/W for the state of this model.

"*****" differs depending on the models.




Fig. c Programming Mode Screen (Example)




Fig. d VFD in Programming Mode (Example)

The appearance shown in (*) of Fig. c is described as follows:

No.	Appearance	State
1	Now Loading...	Loading the disc
2	Reading...	Sending files into the memory. After reading, automatically the tray opens.
3	See FL Display	Writing new version data, the progress will be displayed as shown in Fig. e.




Fig. e VFD in Version Up Mode
5. After programming is finished, the checksum on the VFD (Fig. f).



- Fig. f VFD upon Finishing the Programming Mode (Example)
- Checksum appears on the VFD then the tray will open automatically. Remove the disc on the tray. At this time, no button is available.
6. Unplug the AC cord from the AC outlet. Then plug it again.
 7. Turn the power on.
 8. Press [1], [2], [3], [4], and [DISPLAY] buttons on the remote control unit in that order.
- Fig. g appears on the screen.




Fig. g

9. Press [■] button on the remote control unit.
Fig. h appears on the screen and Fig. i appears on the VFD.




Fig. h

CLEAR

Fig. i

To exit this mode, press [POWER OFF] button.

FIRMWARE RENEWAL MODE (Network Update)

1. Press [SETUP] button on the remote control unit in stop mode.
2. Use [\triangleleft / \triangleright] button to select “CUSTOM”, then press [ENTER] button.
3. Use [\triangleleft / \triangleright] button to select “Other”, then press [ENTER] button.
4. Use [\triangleleft / \triangleright] button to select “Network Update”, then press [ENTER] button.
Confirmation message will appear.
5. Use [\triangleleft / \triangleright] button to select “Yes”, then press [ENTER] button.
This unit will start checking for the latest firmware version.

NOTE:

If any error message concerning the network environment appears, please confirm the setting of your unit according to the error message. If you need to change any of your network environmental setting in order to execute the update, please contact to the internet service provider.

6. Confirmation message will appear.
Use [\triangleleft / \triangleright] button to select “Yes”, then press [ENTER] button.
The unit will start downloading the latest firmware version.
7. When the download completes, confirmation message will appear.
Press [ENTER] button.
The unit will start updating the firmware version.
It may take a while to complete the updating.
(Please wait until “100%” appears on the front panel display.)
8. After updating finishes, this unit will restart and open the disc tray automatically.

How to Verify the Firmware Version

1. Turn the power on.
2. Remove the disc on the tray and close the tray.
3. Press [1], [2], [3], [4], and [DISPLAY] buttons on the remote control unit in that order.

Fig. j appears on the screen.




Fig. j

4. To exit this mode, press [POWER OFF] button.

SERVICE MODE

Service Mode

		1st level	2nd level	3rd level	Description
1	MECHA TEST	1	Tray Aging		Aging of tray open/close
		2	TOC Read		TOC reading
		3	Heat Run		Tray close -> TT1 playback -> TT10 playback -> Tray open -> Tray close
2	VFD/LED TEST	1	A On		Turning on a VFD (The power LED lights red)
		2	A Off		Turning off a VFD (The power LED lights green)
3	ERROR RATE				Displaying Error rate during playback
				1	Off
				2	BD
				3	DVD
				4	CD
			Operating Time		Displaying LD Operation Time (with clear function)
			1	TEST TONE	1 Center/Subwoofer/ Front LR
					2 Surround LR/ Surround Back LR
4	LD TEST		2	Front Lch	
			3	Center	
			4	Front Rch	
			5	Surround Rch	
			6	Surround Back Rch	
			7	Surround Back Lch	
			8	Surround Lch	
			9	Subwoofer	
		6	SD CARD TEST		
5	CHANNEL TEST	7	DEFAULT SETTING		Default setting

Note: If some test are performed continuously, any error will occur

Entering Service Mode

In power on condition, no discs and tray close, it will be entered into service mode by the following operation using the remote controller. However, it will not be entered when Media Select Item is SD Memory.

Service Mode by using remote controller

Press the following buttons on the remote controller in power on condition, no discs and tray close;

[2]->[5]->[8]->[0]->[CLEAR]

Release from Service Mode

Press the [POWER OFF] button to turn off power.

Screen saver/Auto Power Off in Service Mode

These functions are not performed in Service Mode.

After entering, Fig. k appears on the screen and Fig. I appears on the VFD.




Fig. k Service Mode (Main Menu)

VFD : 1000

Fig. I Service Mode

Available button in service mode

Button	condition
ENTER	Enter the next level
POWER OFF	Turn the power off (when the service mode is completed)
1~7	Enter the selected item (next level)
OTHER	Not available

Note: Press the number key to select items. Or, press the cursor button (up/down) to select items and press [ENTER] button.

INDICATION	DESCRIPTION	REMARK
F/W Name	Model Name	E5K***D, etc.
Region	BD region - DVD region	A-1, etc.
Release Ver.	Release version	D,jpp, etc.

TRAY LOCK MODE

Tray Lock Mode prevents the tray opening or closing to prevent disc theft in demo mode.

Enter this mode using the following procedure.

1. Confirm that the TV Monitor is connected.
2. With playback stopped, press [SETUP], [TOP MENU], [3], [AUDIO], [0] and [SETUP] buttons on the remote control unit in that order. "Trade-On" appears in the upper right corner on the screen, and Fig. a appears on the VFD for 2 seconds.

Trade-On

Fig. a

3. To exit this mode, press [SETUP], [TOP MENU], [3], [AUDIO], [0] and [SETUP] buttons on the remote control unit in that order. "Trade-Off" appears in the upper right corner on the screen, and Fig. b appears on the VFD for 2 seconds.

Trade-Off

Fig. b

REMOTE LOCK MODE

SETTING MENU:

Remote Lock Off Mode:

This mode receives an input signal from the remote control unit or from the Remote In-Jack on the rear panel.

Remote Lock On Mode:

This mode dose not receive an input signal from the remote control unit or from the Remote In-Jack on the rear panel.

Perform the setting using the following procedure.

1. Press [POWER ON] and [STOP] buttons on the front panel simultaneously for over 3 seconds to set "Remote Lock Mode" and display mode.
2. Press [STILL/PAUSE] button on the front panel to set to "On" or "Off". When "Remote Lock On", "Remote Lock On" will appear in the upper right corner on the screen and appears on the VFD.

Lock -On

Fig. a VFD

When "Remote Lock Off", "Remote Lock Off" will appear in the upper right corner on the screen and appears on the VFD.


Lock -Off

Fig. b VFD


- a. If [STILL/PAUSE] button is not pressed for 2 seconds or any other button is pressed within 2 seconds, the unit will be released from "Remote Lock Mode".
- b. When initializing, set the Remote Lock Mode "off".

TROUBLESHOOTING


FLOW CHART NO.1




FLOW CHART NO.2




FLOW CHART NO.3








FLOW CHART NO.4




FLOW CHART NO.5




FLOW CHART NO.6**FLOW CHART NO.7****FLOW CHART NO.8****FLOW CHART NO.9****FLOW CHART NO.10**


FLOW CHART NO.11




FLOW CHART NO.12




FLOW CHART NO.13




FLOW CHART NO.14




FLOW CHART NO.15




FLOW CHART NO.16




FLOW CHART NO.17



FLOW CHART NO.18



FLOW CHART NO.19

BD Mechanism Replacement Guidelines

The guidelines describe how to determine whether a BD Mechanism Assembly is defective or not.
Confirm that the main function is eliminated after replacing the defective BD Mechanism Assembly with a new one.


*The BD Mechanism Assembly shall be acceptable when the following test disc can be played successfully;

BD-ROM	BLX-201S3(SONY) chp12
--------	-----------------------

*Select [4: LD Test] and select [2: Operating Time] in Service Mode.
If the Operating Time shows 3,000 hours or more, the BD Mechanism Assembly shall be determined that it has reached the end of its life.


Replacement of BD Main CBA & BD Mechanism Assembly

1. Remove the Top Cover, Tray Panel, Front Panel, Video Bracket, Vdeo CBA and AV PCB Holder.
 2. Disconnect Connectors and replace the BD Main CBA & BD Mechanism Assembly.
- Refer to CABINET DISASSEMBLY INSTRUCTIONS.




BLOCK DIAGRAMS


System Control Block Diagram




Digital Signal Process 1 Block Diagram




Digital Signal Process 2 Block Diagram




Video Block Diagram



Audio Block Diagram



Power Supply Block Diagram



---MEMO---

SCHEMATIC DIAGRAMS AND TEST POINTS

Standard Notes

WARNING


Many electrical and mechanical parts in this chassis have special characteristics. These characteristics often pass unnoticed and the protection afforded by them cannot necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts that have these special safety characteristics are identified in this manual and its supplements; electrical components having such features are identified by the mark "▲" in the schematic diagram and the parts list. Before replacing any of these components, read the parts list in this manual carefully. The use of substitute replacement parts that do not have the same safety characteristics as specified in the parts list may create shock, fire, or other hazards.

Notes:

1. Do not use the part number shown on these drawings for ordering. The correct part number is shown in the parts list, and may be slightly different or amended since these drawings were prepared.
2. All resistance values are indicated in ohms ($K = 10^3$, $M = 10^6$).
3. Resistor wattages are 1/4W or 1/6W unless otherwise specified.
4. All capacitance values are indicated in μF ($P = 10^{-6} \mu F$).
5. All voltages are DC voltages unless otherwise specified.

LIST OF CAUTION, NOTES, AND SYMBOLS USED IN THE SCHEMATIC DIAGRAMS ON THE FOLLOWING PAGES:

1. CAUTION:



FOR CONTINUED PROTECTION AGAINST FIRE HAZARD, REPLACE ONLY WITH THE SAME TYPE FUSE.

ATTENTION: POUR UNE PROTECTION CONTINUE LES RISQUES D'INCELE N'UTILISER QUE DES FUSIBLE DE MÊME TYPE.
RISK OF FIRE-REPLACE FUSE AS MARKED.



This symbol means fast operating fuse.

Ce symbole représente un fusible à fusion rapide.

2. CAUTION:


Fixed Voltage (or Auto voltage selectable) power supply circuit is used in this unit.

If Main Fuse (F1001) is blown, first check to see that all components in the power supply circuit are not defective before you connect the AC plug to the AC power supply. Otherwise it may cause some components in the power supply circuit to fail.

3. Note:

1. Do not use the part number shown on the drawings for ordering. The correct part number is shown in the parts list, and may be slightly different or amended since the drawings were prepared.
2. To maintain original function and reliability of repaired units, use only original replacement parts which are listed with their part numbers in the parts list section of the service manual.

4. Voltage indications for PLAY and STOP mode on the schematics are as shown below:



5. How to read converged lines

1-D3
↑ Distinction Area
Line Number
(1 to 3 digits)

Examples:

1. "1-D3" means that line number "1" goes to the line number "1" of the area "D3".
2. "1-B1" means that line number "1" goes to the line number "1" of the area "B1".


6. Test Point Information


○ : Indicates a test point with a jumper wire across a hole in the PCB.


□→ : Used to indicate a test point with a component lead on foil side.

◎ : Used to indicate a test point with no test pin.


● : Used to indicate a test point with a test pin.







POWER SUPPLY CBA




Ce symbole représente un fusible à fusible rapide.


Ce symbole représente un fusible à fusible rapide.

Risque de décharge électrique lorsque les pistes de même type sont courtes-circuées.

Risque de décharge électrique lorsque les pistes de même type sont courtes-circuées.


ONT A CBA







SD CBA
SUPPLY CN5001
03
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23


VIDEO SIGNAL →






BD MAIN CBA










(CONTINUE
P-N+1, AV)


PC MARTIN CGA




BD MAIN CBA















BD MAIN CBA

WAVEFORMS




NOTE:
Input Signal (DVD)
VIDEO: 75% COLOR BAR
AUDIO: 1KHz, 0dB


WIRING DIAGRAM




LEAD IDENTIFICATIONS



EL817(B, C)
LTV-817(B, C)-F
PS2561A-1(W)




MN101C77A GC




2SC3928A-T112-1Z

2SC5343SFG
2SC5343SG
KTC3875S-GR-RTK/P




KTA1273-Y-AT/P



PQ070XF01SZH
PQ070XF01SZF

2SK3563(Q)
2SK3563(Q M)




STC403

Note:

A: Anode
K: Cathode
E: Emitter
C: Collector
B: Base
R: Reference
G: Gate
D: Drain
S: Source

--MEMO--



PARTS LIST OF EXPLODED VIEW

* Parts for which "nsp" is indicated on this table cannot be supplied


* PWB ASSY for which "nsp" is indicated on this table cannot be supplied When repairing the PWB ASSY check the board parts table and order replacement parts

* The parts listed below are for maintenance only might differ from the parts used in the unit in appearances or dimensions

Ref. No.	Part No.	Part Name	Remarks	Q'ty	New
	9H2189002290D	AV ASSEMBLY VIDEO CBA AUDIO CBA		1VSA22251	1 *
	-	FRONT A CBA	-	-	
	-	FRONT B CBA	-	-	
	9H2189002300D	POWER ASSEMBLY POWER SUPPLY CBA REMOTE JACK CBA		1VSA22246	1 *
	-	SD CBA	-	-	
	-	INLET CBA	-	-	
1B1	9H2309002280D	BD MAIN CBA & BD MECHANISM ASSEMBLY		N77D1BUN	*
A1X	9H2402002230D	FRONT ASSEMBLY E5KC1UD		1VM123602	1 *
A2	nsp	CHASSIS E5KA0UD		1VM021192	1
A3	9H24030001970D	TOP COVER E5KA0UD		1VM021193	1
A4	9H2406002240D	REAR PANEL E5KC1UD		1VM227738	1 *
A6	9H2407001020S	FOOT ASSEMBLY E5H50UD		1VM430199A	4
A8	9H2418001990D	TRAY PANEL ASSEMBLY E5KA0UD		1VM227177	1
A21	nsp	LABEL SERIAL NO. E57E0UD		-	
A22	nsp	LICENSE LABEL E5KA0UD		-	
B2	nsp	FRONT BRACKET(B2 DENON MOLD) E5KC1UD	S/N.o.~04800	1VM330757	1
B2	nsp	FRONT BRACKET(B2 DENON MOLD) E5KC1UD	S/N.o.04801~	1VM330757C	1
B4	nsp	POWER HOLDER E5KA0UD		1VM122880	1
B39	nsp	LEAD CLAMPER 100MM		1790356	3
B70	nsp	HIMELON TAPE(5X40) E5KA0UD		1VM431686	1
B71	nsp	HIMELON TAPE(5X25) E5KA0UD		1VM431688	1
B72	nsp	AV PCB BRACKET E5KA0UD		1VM226905	1
B73	nsp	LOADER BRACKET E5KA0UD		1VM122901	1
B77	nsp	WASHER E5KB0UD	S/N.o.~04800	1VM432940	2
B77	nsp	WASHER E5KB0UD	S/N.o.04801~	1VM432940	2
		MOTOR DC FAN 2D65BL100190		MMEZR12XNR08	1
FM1001	9H2685001110S				
W006	9H2606002250S	WIRE ASSEMBLY FFC 8/177/1.0		WX1E5KC1-002	1
W007	nsp	WIRE ASSEMBLY VH 2/265/AWG20		WX1E5KA0-007	1
W009	nsp	WIRE ASSEMBLY PH 16/290/AWG24		WX1E5KA0-009	1
SCREWS					
2L015	nsp	SCREW TAP TIGHT WASHER+ P-TIGHT		GCJP3080	2
2L018	nsp	SCREW P-TIGHT M3X8 BIND HEAD+		GBJP3080	9
2L026	nsp	SCREW S-TIGHT M3X6 E5E10UD		1VM429667	3
2L027	nsp	SCREW S-TIGHT M3X6 E5E10UD		1VM429667	2
2L028	nsp	SCREW S-TIGHT M3X10 E5E10UD	0VM412936A	4	
2L032	nsp	SCREW S-TIGHT M3X6 E5E10UD	1VM429667	6	
2L034	nsp	SCREW S-TIGHT M3X6 E5E10UD	1VM429667	4	
2L036	nsp	SCREW S-TIGHT M3X6 BIND HEAD+	S/N.o.~04800	GBJS3060	7
2L036	nsp	SCREW S-TIGHT M3X6 BIND HEAD+	S/N.o.04801~	GBJS3060	9
2L040	nsp	SCREW P-TIGHT M3X8 BIND HEAD+	GBJP3080	4	

Ref. No.	Part No.	Part Name	Remarks	Q'ty	New
2L051	nsp	SCREW TAP TIGHT WASHER+ P-TIGHT		GCJP3080	2
2L054	nsp	SCREW C-TIGHT M3X6 E5610UD		0VM412937A	6
2L056	nsp	SCREW S-TIGHT M3X6 E5E10UD		1VM429667	4
2L057	nsp	SCREW S-TIGHT M3X6 BIND HEAD+		GBJS3060	1
2L070	nsp	B-TIGHT SCREW M3X8 E5E00UD		1VM428563	8
2L072	nsp	B-TIGHT SCREW M3X8 E5E00UD		1VM428563	1
2L073	nsp	B-TIGHT SCREW M3X8 E5E00UD		1VM428563	2
2L079	nsp	S-TIGHT SCREW M3X6 E5E00UD		1VM428564	1
2L081	nsp	S-TIGHT SCREW M3X6 E5E00UD		1VM428564	5
2L082	nsp	S-TIGHT SCREW M3X6 BIND HEAD+BLACK		GBHS3060	9
2L083	nsp	S-TIGHT SCREW M3X6 E5E00UD		1VM428564	1
2L089	nsp	S-TIGHT SCREW M3X6 E5E00UD		1VM428564	2

PACKING VIEW



PARTS LIST OF PACKING & ACCESSORIES

* Parts for which "nsp" is indicated on this table cannot be supplied

* The parts listed below are for maintenance only might differ from the parts used in the unit in appearances or dimensions

Ref. No.	Part No.	Part Name	Remarks	Q'ty	New
A20	nsp	BARCODE LABEL E5KC1UD		-	1
A30	nsp	CONTROL LABEL E5KC1UD		-	2
S1	9H2533002010D	SIDE PAD E5KA0UD	1VM123019	2	
S2	9H2531002260D	GIFT BOX CARTON E5KC1UD	1VM330859	1	*
S3	nsp	SET BAG E7708UA	0DM400731D	1	
X1	9H2541002270D	OWNERS MANUAL E5KC1UD	1VMN27754	1	*
X6	nsp	MANGANESE DRY BATTERY R6UWC/2STA	XB0M311MS003	2	
X6	nsp	MANGANESE DRY BATTERY R6UWC/2SK	XB0M311MS002	2	
X6	nsp	DRY BATTERY ES-GR6M-C	XB0M571GLP01	2	
X10	nsp	ACCESSORY BAG E5795ED	0VM416059	1	
X12	nsp	SERVICE CENTER SHEET E8700UD	1VM425536F	1	
X14	nsp	AV CORD 1000/BLACK	WPZ0102TM018	1	
X14	nsp	AV CORD RCA(M*)2)TO RCA(M*)2)	WPZ0102LTE01	1	
X15	00D9H26000887	AC CORD W/THA GND WIRE UL/CSA/162/NO/BLACK	WAV0162LW001	1	
△	X15	CORD W/O A GND WIRE UL/CSA(VW-1)/152/NO/	WAV0152LTE01	1	
△	X15	CORD W/O A GND WIRE UL/CSA(VW-1)/152/NO/	WAV152ZJIN001	1	
△	X19	9H2307002060D	NB420UD	1	
X38	nsp	REMOTE CONTROL UNIT NB420UD	1VM323952C	1	
		WARRANTY SHEET E6E80UD			