



# CIRCUIT DIAGRAM

## 1. POWER(SMPS) CIRCUIT DIAGRAM

### IMPORTANT SAFETY NOTICE

WHEN SERVICING THIS CHASSIS, UNDER NO CIRCUMSTANCES SHOULD THE ORIGINAL DESIGN BE MODIFIED OR ALTERED WITHOUT PERMISSION FROM THE ZENITH ELECTRONICS CORPORATION. ALL COMPONENTS SHOULD BE REPLACED ONLY WITH TYPES IDENTICAL TO THOSE IN THE ORIGINAL CIRCUIT SPECIAL COMPONENTS ARE SHADED ON THE SCHEMATIC FOR EASY IDENTIFICATION. THIS CIRCUIT DIAGRAM MAY OCCASIONALLY DIFFER FROM THE ACTUAL CIRCUIT USED. THIS WAY, IMPLEMENTATION OF THE LATEST SAFETY AND PERFORMANCE IMPROVEMENT CHANGES INTO THE SET IS NOT DELAYED UNTIL THE NEW SERVICE LITERATURE IS PRINTED.

NOTE:  
 1. Shaded (■) parts are critical for safety. Replace only with specified part number.  
 2. Voltages are DC-measured with a digital voltmeter during Play mode.




### LOCATION GUIDE

BD901	B5	IC905	E2
C901	A3	L902	E6
C902	A4	L903	E5
C903	B3	L904	E5
C904	B3	LB901	C2
C905	B5	LB902	G5
C906	C5	LF901	A4
C907	C4	PC901	D3
C908	C2	PT901	C6
C909	C2	Q901	F4
C910	D2	Q902	F4
C911	D2	Q903	F3
C913	D6	Q904	F2
C914	D5	Q908	F5
C915	D5	Q909	F4
C916	D4	R901	B4
C917	D3	R902	C2
C918	E6	R903	A5
C919	E5	R904	C5
C920	E4	R905	C5
C921	E6	R906	C5
C922	E5	R907	C4
C923	E4	R909	C2
C924	G6	R910	A4
C925	G5	R911	C2
C926	G4	R913	D6
C927	E2	R914	D5
C934	E3	R915	D5
CON901	A2	R917	E3
CON902	H6	R918	E2
CON903	H3	R921	E3
CON904	H4	R922	E2
D901	C5	R923	F6
D902	C4	R924	F4
D903	C3	R926	G2
D905	D4	R928	F5
D906	D4	R929	F3
D907	D6	R930	F3
D908	D5	R931	G5
D909	D5	R932	F5
D910	D5	R933	E3
D913	F4	R938	H4
F901	A3	Z901	A3
F902	G5	ZD901	D4
IC901	B3	ZD902	E3
IC902	F6		


'99 04.01 SI2050  
SMPS

NOTES) ⚠ Warning  
 Parts that are shaded are critical  
 With respect to risk of fire or  
 electrical shock.


## 2. RF & DVD DSP CIRCUIT DIAGRAM



### 3. DRIVE CIRCUIT DIAGRAM



# 4. MPEG & ENCODER CIRCUIT DIAGRAM



## LOCATION GUIDE

C301	A11	IC301	E8	R389	C11
C302	B11	IC303	D3	R390	L11
C303	C11	IC306	D3	R391	G11
C304	B11	IC307	G3	R392	G11
C305	B10	IC308	I2	R393	C10
C306	B9	IC309	K10	R394	C10
C307	B8	IC800	N10	R395	A11
C308	B7	IC801	N4	R396	I3
C309	B6	L309	B11	R397	G11
C310	B6	L310	B11	R398	G11
C311	B5	L310	B11	R399	I7
C312	C4	L801	O11	R801	L8
C313	D4	L802	O2	R802	L8
C314	D4	L804	L7	R803	O8
C315	E4	L804	L7	R804	O9
C316	E4	R802	M6	R805	M11
C317	F4	R804	M7	R806	M11
C318	G4	R805	N7	R807	O8
C319	G4	R807	N7	R808	O8
C320	G4	R807	N7	R809	N8
C321	H4	R145	J8	R810	N8
C322	H4	R160	J8	R811	N8
C323	I6	R160	J8	R813	M7
C324	I6	R302	I5	R814	M6
C325	I7	R304	B10	R815	M7
C326	I8	R305	B8	R816	M7
C327	I9	R305	B8	R817	M7
C328	I9	R307	B8	R819	M7
C329	H10	R308	B8	R820	M7
C330	G10	R308	B8	R821	N9
C331	F11	R309	B8	R822	N9
C332	F10	R311	B7	R823	L8
C333	E10	R312	B7	R824	K4
C334	D10	R313	B5	R825	K3
C335	B3	R315	F4	R826	L4
C336	B2	R315	F4	R827	K3
C337	H11	R316	F4	R828	K3
C338	I11	R316	F4	R829	N3
C344	J2	R317	F4	R852	D11
C345	J3	R319	F4	R860	M10
C346	I1	R320	H4	R861	N9
C347	J1	R321	H4	R862	N3
C378	E3	R320	H4	R863	O2
C379	E2	R323	H4	R864	O2
C380	K11	R335	G4	R869	L4
C381	J1	R335	G4	R870	M8
C382	I1	R339	I5	R871	M8
C383	I2	R340	I5	R872	M8
C384	I3	R340	I5	R873	K3
C802	O11	R351	I5	R874	M8
C803	M10	R360	I2	R880	N6
C804	N9	R361	J2	R894	M6
C805	N9	R361	J2	R895	L8
C806	N9	R362	J2	REOZ1	J6
C809	M10	R364	I7	REOZ1	Q8
C814	L4	R365	I8	X301	I1
C815	L5	R365	I8	ZISENB	D11
C816	L5	R366	I8	ZISENB	J6
C818	L4	R367	I8	ZISENB	Q7
C819	L7	R369	I9	ZISENB	P7
C820	L7	R370	I10	ZISERR	J5
C821	L4	R370	I10	ZISS	J4
C829	M9	R371	H11	ZOSERR	J5
C831	L3	R372	H11	ZOSERR	J5
C832	M3	R373	G10	ZOSERR	J5
C833	O2	R374	G10	ZOSERR	J5
C834	O3	R376	G10	ZOSERR	J5
C835	N3	R376	G10	ZOSERR	J5
CE301	A11	R377	G11		
CE302	B11	R378	F11		
CE310	J1	R379	E10		
CE311	I3	R380	D10		
CE312	O11	R381	D10		
CE313	O2	R383	D11		
CE314	M7	R384	D11		
CE315	M7	R385	C10		
CE316	M7	R385	C10		
CE317	M7	R385	C10		
CE318	M7	R385	C10		
CE319	K2	R387	C11		
CE320	K2	R387	C11		
CE321	K2	R388	C11		


- ① No power on
- ② 3.3V Reg.
- ③ No power on
- ④ No power on  
μ-com->MPEG address
- ⑤ The screen is distorted(DVD)  
Over 3V->Data error. GND:OK
- ⑥ No VCD screen display(option).  
No CD sound out.
- ⑦ No DVD screen display
- ⑧ Over 3V->Data error. GND:OK  
(CD/VCD option)
- ⑨ No power on
- ⑩ No Audio(check clock)
- ⑪ No 5.1CH Audio
- ⑫ No 2CH Audio
- ⑬ Audio signal doesn't appear
- ⑭ No screen
- ⑮ No power on  
μ-com->MPEG command data
- ⑯ No power on  
over 3V: normal
- ⑰ No power on  
Check 89MHz
- ⑱ Video Mute doesn't  
operate in power on/off
- ⑲ No Pb output
- ⑳ No Pr output
- ㉑ No Y output
- ㉒ No composite video output
- ㉓ No Luminance output in  
Y/C Video
- ㉔ No Chrominance  
output in Y/C Video
- ㉕ No power on
- ㉖ No power on

'99 04.01 Si2019  
MPEG & ENCODER

# 5. AUDIO CIRCUIT DIAGRAM

## LOCATION GUIDE


C601	C7	CE625	O5	R626	F6	R735	G8
C602	D8	CE626	F5	R627	G7	R736	F9
C603	E8	CE627	D3	R628	F4	R737	G9
C604	F8	CE628	I5	R629	G7	R738	J10
C605	F7	CE629	E4	R631	G6	R740	G9
C606	G7	CE630	G4	R632	H7	R741	J9
C607	C8	CE631	F4	R633	I7	R742	G8
C608	E7	CE632	E2	R634	J6	R743	H9
C609	H8	CE635	I4	R635	J6	R745	I9
C610	H7	CE636	G3	R636	C4	R746	J8
C611	E6	CE637	F3	R637	C4	R747	J8
C612	I1	CE639	I3	R638	C5	R748	O7
C613	H8	CE702	O9	R639	C5	R749	M7
C614	I11	CE703	O9	R640	D6	R750	M7
C615	G6	CE704	O8	R642	C5	R751	M7
C616	G6	CE706	D9	R643	C5	R752	M6
C618	G7	CE708	E10	R644	F6	R753	N6
C621	H7	CE709	F9	R646	G6	R754	O7
C622	E5	CE710	F9	R647	G6	R755	O6
C623	E6	CE711	G10	R650	G6	R756	O7
C624	F5	CE712	F10	R653	H6	R757	O7
C625	F5	CE713	E9	R654	I6	R758	M2
C626	C5	CE714	H8	R655	J5	R759	M3
C627	O5	CE716	I10	R656	J5	R760	N3
C629	H5	CE717	G9	R657	G4	R761	N3
C630	H6	CE718	F9	R658	G4	R762	O3
C631	E4	CE720	I9	R659	F5	R763	O3
C632	H5	CE721	O6	R661	G5	R764	N5
C633	G4	CE722	O6	R662	G5	R765	O5
C634	G4	CE723	O7	R664	G4	R766	N5
C635	G4	CE724	O6	R665	H5	R767	N4
C637	H5	CE725	N11	R666	I5	R768	N4
C638	D3	CE726	N11	R667	J4	R769	F10
C639	E4	CE728	O10	R668	J4	R770	M11
C640	E2	CE733	O11	R669	C2	R771	M10
C641	G3	CON701	P11	R670	C2	R772	M10
C642	G3	CON702	P7	R671	C2	R773	N10
C643	F3	D701	M3	R672	C3	R774	M11
C644	H2	IC601	E7	R673	D3	R775	N11
C645	H4	IC602	E5	R674	G3	R776	O11
C647	H4	IC603	E3	R675	G3	R777	L10
C648	G2	IC604	H7	R676	F4	R778	L11
C649	G2	IC605	H5	R677	J6	R779	K9
C651	G2	IC606	H3	R678	G3	R780	K9
C652	H2	IC607	I8	R679	J5	R781	K8
C702	O8	IC608	I7	R681	G4	R782	K7
C703	O9	IC609	I6	R682	G4	R783	K6
C704	P9	IC610	I5	R684	H3	R784	K5
C705	O8	IC611	I4	R685	H4	R785	K4
C707	C9	IC612	I2	R686	I4	R786	K2
C708	D10	IC702	P8	R687	J3	R787	C10
C710	F10	IC703	E9	R688	J3	R788	C8
C711	F9	IC704	H9	R689	G2	R789	C11
C712	O9	IC705	I10	R690	G2	R790	D11
C713	G10	IC706	I9	R691	F3	R791	D11
C715	H10	IC707	K10	R693	G2	R792	E11
C716	H9	IC708	N7	R694	J4	R793	F11
C718	H10	IC709	N3	R695	J2	R794	F11
C719	G8	IC710	N5	R696	G3		
C720	G9	IC711	O4	R697	G2		
C722	G9	IC712	E11	R698	H3		
C723	H9	IC713	C11	R699	I3		
C724	N6	L602	I12	R700	J2		
C725	O6	Q601	F8	R701	O8		
C726	O7	Q602	F6	R702	O8		
C727	M2	Q603	F4	R703	O9		
C728	P3	Q701	M3	R704	O9		
C729	O5	Q702	O3	R705	K10		
C730	N5	Q703	M11	R706	O9		
C731	N4	Q704	N11	R707	P9		
C732	N10	Q705	F10	R708	P9		
C733	N11	R600	J2	R709	C9		
C734	N11	R601	C6	R710	C9		
C735	O11	R602	C7	R711	C9		
C736	P10	R603	C7	R712	C9		
CE601	C7	R604	C7	R713	D10		
CE602	D7	R605	D8	R714	F10		
CE603	E8	R606	F8	R715	G9		
CE604	F7	R607	G7	R716	G9		
CE605	F8	R608	G7	R717	F10		
CE606	F8	R609	F8	R718	N3		
CE607	E7	R610	J8	R719	G10		
CE609	H12	R611	J8	R721	G10		
CE610	I12	R612	J7	R722	K10		
CE611	I8	R614	G8	R723	G10		
CE612	G7	R615	G8	R726	H10		
CE613	F7	R616	F8	R727	I10		
CE616	I7	R618	H8	R728	J10		
CE617	E6	R620	I8	R729	J9		
CE619	G6	R621	J7	R730	K10		
CE620	F6	R622	J7	R731	F9		
CE621	E5	R623	G6	R732	K10		
CE622	H4	R624	G6	R733	J9		
CE624	I6	R625	F7	R734	G8		



- AUDIO DIGITAL DATA INPUT
- CLOCK
- DIGITAL DATA OUT
- AUDIO 2CH R OUT
- AUDIO 2CH L OUT
- AUDIO 5.1 CH FR / RR OUT
- AUDIO 5.1 CH FL / RL OUT
- AUDIO 5.1CH CENTER OUT
- AUDIO 5.1CH WOOFER OUT


'99 04.07 R10434A  
AUDIO DM & 5.1CH

# 6. μ-COM/EXPANDER CIRCUIT DIAGRAM




'99 04.01 SI2022  
MICOM & EXPANDER

# 7. FRONT(TIMER) & KEY CIRCUIT DIAGRAM



'99 04.26 R10437A  
DVD-2200N,D/2250N,D/2300N

# 8. JACK CIRCUIT DIAGRAM




## LOCATION GUIDE

CV01	B4	JV08	L7
CV02	B4	JV09	K5
CV03	G2	QV01	I6
CV04	D2	QV02	J6
CV05	B2	QV03	I6
CV06	B2	QV04	H6
CV07	D2	RV01	B4
CV08	C2	RV02	C7
CV09	C2	RV03	I6
CV10	D7	RV04	I6
CV11	F5	RV05	J6
CV12	F5	RV06	I2
CV13	F7	RV07	J5
CV14	F7	RV08	I6
CV15	G6	ZV01	B3
CV16	G6	ZV02	B2
CV17	F7	ZV03	C3
CV18	G6	ZV04	C2
CV19	G6	ZV05	D3
CV20	H7	ZV06	D2
CV21	H6	ZV07	B2
CV22	I6	ZV08	B2
DV01	K6	ZV09	B3
DV02	J6	ZV10	B2
FV01	G3	ZV11	C3
FV02	C3	ZV12	C2
FV03	B3	ZV13	G3
FV04	B3	ZV14	G2
FV05	D3	ZV15	F3
FV06	C3	ZV16	F2
FV07	B3	ZV17	F3
FV08	D3	ZV18	F2
FV09	E3	ZV19	F3
FV10	E3	ZV20	F2
FV11	G3	ZV21	E3
FV12	F3	ZV22	E2
FV13	F3	ZV23	E3
FV14	G3	ZV24	E2
FV15	H3	ZV25	D2
FV16	I4	ZV26	D2
FV17	I3	ZV27	G3
FV18	I3	ZV28	G2
FV19	I5	ZV29	H3
FV20	I4	ZV30	H2
FV21	I2	ZV31	J7
IC851	F6	ZV32	J7
JJ01	C6	ZV33	J7
JJ02	C6	ZV34	J7
JJ03	D6	ZV35	J5
JJ04	D6	ZV36	J5
JJ05	D6	ZV37	J5
JJ06	D6	ZV38	J5
JJ07	D5	ZV39	J4
JJ08	D5	ZV40	J4
JJ10	G5	ZV41	J3
JJ11	G5	ZV42	J3
JJ12	G6	ZV43	J3
JV01	A2	ZV44	J3
JV02	G2	ZV45	J4
JV03	E2	ZV46	J4
JV04	H2	ZV47	J3
JV06	D8	ZV48	J3
JV07	A8		


'99 04.01 SI2040  
AV JACK



## WAVEFORM (POWER)




IC901 Pin ③  
STAND-BY(AC110V)




IC903 Pin ③  
PLAY(AC110V)


## (RF/SERVO)




IC201 Pin ⑳, Focus Error  
IC201 Pin ⑱, SBADD




IC201 Pin ⑳  
Tracking Error




IC201 Pin ⑳  
VBR TRACKING Error



IC201 Pin ⑳,  
RF




IC206 Pin ⑱, SLED Drive(FMO)  
IC202 Pin ⑱, SLED FG




IC201 Pin ⑳, Focus Error(in Focus Search)  
IC206 Pin ⑱, Focus Drive(FDO)


## (VIDEO ENCODER)




IC800 Pin ⑳~㉓, MPEG Data  
IC801 Pin ⑬~⑯, ⑲~㉒, MPEG Data




IC800 Pin ⑬, Luminance  
IC801 Pin ⑤⑨, Luminance




IC800 Pin ④⑨, Vertical SYNC  
IC801 Pin ②④, Vertical SYNC




IC801 Pin ④③, Component Pr




IC800 Pin ⑩, Composite  
IC801 Pin ⑤⑦, Composite




IC800 Pin ④⑩, ④①, SDA/SCL  
IC801 Pin ⑦⑤, ⑦⑥, SDA/SCL




IC800 Pin ⑤⑩, Horizontal SYNC  
IC801 Pin ⑤⑨, Horizontal SYNC




IC801 Pin ④④, Component Y



IC800 Pin ⑫, Chrominance  
IC801 Pin ⑤⑧, Chrominance



IC800 Pin ④③, MPEG Clock(27MHz)  
IC801 Pin ⑦①, MPEG Clock(27MHz)



IC801 Pin ④②, Component Pb