


Service Manual

FM/AM Stereo Receiver

SA-401

[M], [MC]



Simulated wood cabinet

Areas

- * [M] is available in U.S.A.
- * [MC] is available in Canada.

TECHNICAL SPECIFICATIONS (Specifications are subject to change without notice or further improvement.)**AMPLIFIER SECTION**

Rated minimum sine wave RMS power output
20 Hz ~ 20 kHz both channels driven
0.04% total harmonic distortion

1 kHz continuous power output
both channels driven
0.04% total harmonic distortion

Dynamic headroom
Total harmonic distortion
rated power at 20 Hz ~ 20 kHz
half power at 20 Hz ~ 20 kHz
half power at 1 kHz

SMPTE intermodulation distortion

Frequency response

PHONO
TUNER, AUX, TAPE

Input sensitivity

PHONO

TAPE 1, 2

S/N (IHF, A)

PHONO
TUNER, AUX, TAPE

Maximum input voltage

PHONO

Input impedance

PHONO

TAPE 1, 2

Tone controls

BASS

TREBLE

Acoustic controls (at tone "0" position)

LOW BOOST

HIGH BOOST

Low filter

High filter

Loudness control (volume at -30 dB)**Output voltage**

REC OUT

Low frequency damping factor

50 W per channel (8 ohms)

55 W per channel (8 ohms)
60 W per channel (4 ohms)
1.4 dB (2 ohms)

0.04% (8 ohms)
0.02% (8 ohms)
0.009% (8 ohms)

0.04% (8 ohms)
0.02% (8 ohms)
0.009% (8 ohms)

RIAA standard curve +0.3 dB
7 Hz ~ 45 kHz, -1 dB

20 Hz ~ 20 kHz, +0.2 dB, -0.2 dB

0.4 mV (2.5 mV, IHF '66)
20 mV (150 mV, IHF '66)

73 dB (80 dB, IHF '66)
78 dB (95 dB, IHF '66)

120 mV (150 mV, 1 kHz)

47 kilohms
27 kilohms

50 Hz, +10 dB ~ -10 dB
20 kHz, +10 dB ~ -10 dB

100 Hz, +6 dB
10 kHz, +6 dB

100 Hz, -6 dB/oct.
7 kHz, -6 dB/oct.

50 Hz, +9 dB

150 mV

34 (8 ohms)
17 (4 ohms)

Load impedance

MAIN or REMOTE
MAIN and REMOTE

4 ~ 16 ohms
8 ~ 16 ohms

FM TUNER SECTION E(500 ~ 599)

Frequency range 88 ~ 108 MHz
Sensitivity 10.8 dBf (1.9 μV, IHF '58)

50 dB quieting sensitivity
MONO 13.7 dBf (2.7 μV IHF '58)
STEREO 37.2 dBf (39.7 μV IHF '58)

Total harmonic distortion
100 Hz 0.15% (MONO), 0.3% (STEREO)
1 kHz 0.15% (MONO), 0.3% (STEREO)
10 kHz 0.3% (MONO), 0.4% (STEREO)

S/N **MONO** 75 dB
STEREO 70 dB

Frequency response 20 Hz ~ 15 kHz, +1 dB, -2 dB
Alternate channel selectivity 1.2 dB

Capture ratio 60 dB
Image rejection at 98 MHz 75 dB
IF rejection at 98 MHz 82 dB

Spurious response rejection at 98 MHz 55 dB
AM suppression 45 dB
Stereo separation 35 dB

1 kHz 45 dB
10 kHz 35 dB

Carrier leak -40 dB
19 kHz -50 dB
38 kHz

Antenna terminals 300 ohms (balanced)
75 ohms (unbalanced)

AM TUNER SECTION

Frequency range 525 ~ 1605 kHz
Sensitivity 30 μV, 300 μV/m

Selectivity 30 dB
Image rejection at 1000 kHz 50 dB
IF rejection at 1000 kHz 40 dB

GENERAL

Power consumption (E (700 ~ 799))
300 W, 345 VA

Power supply AC 120V, 60 Hz

Dimensions (W x H x D) 480 x 160 x 293 mm

(18-29/32" x 6-5/16" x 11-17/32")

Weight 8.4 kg
(18.5 lb.)

Weights and dimensions shown are approximate.

Technics

Panasonic Company
Division of Matsushita Electric
Corporation of America
One Panasonic Way, Secaucus,
New Jersey 07094



Panasonic Hawaii, Inc.
320 Waikamilo Road, Honolulu,
Hawaii 96817


Matsushita Electric of Canada Ltd.
5770 Ambler Drive,
Mississauga, Ontario L4W 2T3

■ CONTENTS

LOCATION OF CONTROLS	2, 3	TERMINAL GUIDE OF TRANSISTORS & IC'S	16
DISASSEMBLY INSTRUCTIONS	3~5	EXPLODED VIEW	17, 18
VARIABLE RESISTORS	5	REPLACEMENT PARTS LIST	
ALIGNMENT INSTRUCTIONS	6	(Cabinet, chassis & packing parts)	19
ALIGNMENT POINTS	8	REPLACEMENT PARTS LIST (Electric parts)	19, 20
BLOCK DIAGRAM	7	SCHEMATIC DIAGRAM	21, 22
DIAL CORD INSTALLATION GUIDE	8	REPLACEMENT PARTS LIST (Resistors & capacitors)	23, 24
BLOCK DIAGRAM OF IC'S	9		
PRINTED CIRCUIT BOARD WIRING VIEW (FM/AM tuner and equalizer circuit board)	12, 13		
PRINTED CIRCUIT BOARD WIRING VIEW (Tone, main amplifier, power supply and speaker protection circuit board)	14, 15		

■ LOCATION OF CONTROLS






■ DISASSEMBLY INSTRUCTIONS

* How to remove the top board


1. Remove the 3 setscrews (Fig. 1 : ① ~ ③) holding the top board and ventilation.
2. Move the top board and ventilation slightly toward the rear of the unit (Fig. 1 : ④).




[Fig. 1]

* How to remove the front panel and the bottom board

1. Loosen the 4 setscrews (Fig. 2 : ④ ~ ⑦) holding the side boards.
2. Remove the 5 setscrews (Fig. 2 : ⑧ ~ ⑫) holding the front panel and remove the 2 setscrews (Fig. 3 : ⑭, ⑮) holding the bottom board.
3. Pull the front panel outward from the front of the unit.
4. To remove the bottom board, remove the 12 setscrews (Fig. 3 : ⑯ ~ ㉓) holding the bottom board.




[Fig. 2]




[Fig. 3]

* How to remove the power IC

1. Remove the top board and bottom board. (Refer to the sections "How to remove the top board" and "How to remove the front panel and the bottom board".)
2. Remove the solder of power IC for both Lch and Rch.
3. Remove the transistor bracket setscrew (Fig. 5 : ㉔) to detach the transistor bracket.
- Unsolder the transistor Q701, and bend it down in the direction of the arrow ㉕. (Refer to Fig. 5.)
4. Remove the 2 setscrews (Fig. 5 : ㉖, ㉗) at the bottom of the heat sink and the 3 setscrews (Fig. 4 : ㉙ ~ ㉛) at the rear panel, and then remove the heat sink along with the power IC in the direction of the arrow ㉘. (Refer to Fig. 5.)
5. Remove the 2 setscrews (Fig. 5 : ㉟, ㉟) used to secure the power IC on the heat sink, and then pull the power IC.
6. When mounting the power IC, apply silicone compound (or equivalent heat diffuser) to the rear side of power IC, and then follow the steps 1 ~ 5 reversely.




[Fig. 4]




[Fig. 5]

• How to remove the LED indicator P.C.B. and LED indicator drive circuit P.C.B.


1. Remove the top board (Refer to the section "How to remove the top board".)
2. Remove the 2 setscrews (Fig. 6 : ㉓, ㉔) holding the dial scale ass'y. and remove the dial scale ass'y.
3. Remove the 2 setscrews (Fig. 7 : ㉕, ㉖) holding the dial pointer cover and remove the dial pointer cover.
4. Remove the 3 setscrews (Fig. 8 : ㉗ ~ ㉙) which fasten the LED frame in the direction of the arrow ㉚ (Fig. 8)
5. The LED indicator P.C.B. ass'y is secured with the lug projected from the LED frame. So, bend the lug down (㉛ in Fig. 9) to remove the LED indicator P.C.B.
6. Remove the setscrew (Fig. 9 : ㉚) which fastens the LED indicator drive circuit P.C.B. Then the LED indicator drive circuit P.C.B. can be detached.
7. When re-assembling, reversely follow the steps 1 through 7.




[Fig. 6]



[Fig. 7]



[Fig. 8]




[Fig. 9]

VARIABLE RESISTORS


• Alteration of resistance values according to the rotational angles of variable resistors

Alteration characteristics as shown below are often used for sets. All are intended to keep the frequency response of the set at optimum levels, and are used according to the types of circuits. For example, characteristic (B) is used for sound volume adjustment; (A) and (C) are for bass and treble sound quality adjustment; (G) is for medium sound quality adjustment; and (BH) is for the adjustment of sound balance between the right and left.


In the case of this unit, variable resistor with characteristic (C) which is short-circuited between its ends at rotational angle of 150° (center) is used for bass adjustment. Also, variable resistor with characteristic (C) whose resistance is zero at rotational angle of 150° (center) is used for treble adjustment.




Characteristic (B)



Characteristic (C)




Characteristic (A)




Characteristic (G)


VR1 is interlocked with VR2




Characteristic (BH)



Characteristic (C):
short-circuited at center



Characteristic (C):
opened at center



■ ALIGNMENT INSTRUCTIONS

Notes:

1. Band selector switch AM (AM Alignment)
1. Band selector switch FM (FM Alignment)
2. FM muting & mode switch . . . off/mono
3. Fix the bottom board to chassis before adjustment.



4. Connect stereo modulator to FM-SG
5. Maintain line voltage at 120 volts.
6. 300Ω dummy antenna
7. Output of signal generator should be no higher than necessary to obtain an output reading.

AM/FM SIGNAL GENERATOR CONNECTION	FREQUENCY	DIAL SETTING	INDICATOR (VTVM or SCOPE)	ADJUSTMENT POINTS	REMARKS	
AM ALIGNMENT						
1 High side through 0.001μF to AM antenna trimmer terminal. (point A). Common to chassis.	450kHz (30% Mod. with 400Hz)	Point of non-interference	Connect AC VTVM or scope to "SPEAKER" terminals.	T201 (1st IFT) T202 (2nd IFT)	Adjust the input frequency and adjustment points so that the output becomes maximum.	
2 Fashion loop of several turns of wire and radiate signal into loop of receiver	600kHz (30% Mod. with 400Hz)	600kHz	Connect AC VTVM or scope to "SPEAKER" terminals.	L202 (OSC Coil) L201 (ANT Coil)	Adjust for maximum output; Adjust L201 by moving coil bobbin along ferrite core.	
3 Fashion loop of several turns of wire and radiate signal into loop of receiver.	1500kHz (30% Mod. with 400Hz)	1500kHz	Connect AC VTVM or scope to "SPEAKER" terminals.	CT5 (OSC Trimmer) CT4 (ANT Trimmer)	Adjust for maximum output. Repeat steps 2 and 3.	
FM IF ALIGNMENT						
4	No-Signal.	Point of non-interference	Connect DC VTVM to TP102, TP103 terminals. (Refer to fig. 14)	T101 (DISCR1 IFT) A	<ul style="list-style-type: none"> • FM muting/mode switch to "on/auto" position. • Adjust T101 (A) core so that voltage measured in signal mode is OV in 300mV range. 	
FM RF ALIGNMENT						
5 Connect to FM 300Ω antenna terminal through 300Ω FM dummy antenna.	90MHz (100% Mod. with 400Hz) weak input	90MHz	Connect scope to "SPEAKER" terminals.	L5 (OSC Coil) L3 (RF DET Coil) L1 (ANT Coil)	<ul style="list-style-type: none"> • Add weak input so that noise is included in the output wave form. • Make the adjustment so that the output wave form is vertically symmetrical. (Fig. 15) • Repeat the steps 5 and 6 until the frequency correctly matches the dial scale. 	
6	106MHz (100% Mod. with 400Hz) weak input	106MHz	Connect scope to "SPEAKER" terminals.	CT3 (OSC Trimmer) CT2 (RF DET Trimmer) CT1 (ANT Trimmer)		
FM MONO DISTORTION ALIGNMENT						
7	Connect to FM 300Ω antenna terminal through 300Ω FM dummy antenna.	100MHz (100% Mod. with 400Hz)	100MHz	Connect distortion meter to "SPEAKER" terminals.	T102 (DISCR1 IFT) B	<ul style="list-style-type: none"> • Set the FM muting/mode switch to "on/auto" and then check step 4 in no signal mode. • If it is deflected, re-adjust A (primary side) of T101. • Adjust T102 core so that distortion of right and left channels are minimized. • Repeat steps (4) and (7).
LED SIGNAL METER LIGHT UP LEVEL ALIGNMENT						
8	Connect to FM 300Ω antenna terminal through 300Ω FM dummy antenna.	100MHz (100% Mod. with 400Hz)	100MHz	Connect scope to "SPEAKER" terminals.	VR102 (LED LIGHT UP LEVEL)	<ul style="list-style-type: none"> • With weak input signal (noise produced) at 100MHz (100% Mod. with 400Hz) applied, make tuning so that the upper and lower wave forms are symmetrical. • With the input set at 45dB (signal generator at 57dB), adjust VR102 so that all the signal strength LED's light up.
FM MUTING LEVEL ALIGNMENT						
9	Connect to FM 300Ω antenna terminal through 300Ω FM dummy antenna. Apply 16dB (6.3μV) to receiver.	100MHz (100% Mod. with 400Hz)	100MHz	Connect AC VTVM or scope to "SPEAKER" terminals.	VR101 (MUTING LEVEL)	FM muting/mode switch to "on/auto". Adjust so that output can be obtained.
FM MPX PILOT ALIGNMENT						
USING FREQUENCY COUNTER			USING ALTERNATE SYSTEM			
10	1. 100MHz Non-modulated mono signal applied to set. 2. FM muting/mode switch to "on/FM auto". 3. Connect frequency counter to TP301 through resistor (100kΩ). 4. Adjust VR301 to 19kHz, ± 30Hz.			1. Apply stereo signal from generator or stereo station to receiver. 2. Adjust VR301 until stereo indicator lights up. Cement arm of VR301 as shown in fig. 16.		


SEPARATION ALIGNMENT

PREPARATIONS	ADJUSTING PROCEDURE
<p>Add 100MHz, 1kHz, 30% pilot 10% modulation, 60dB stereo signal to the receiver.</p> <p>Connect AC VTVM or scope to speaker terminals through low pass filter. Refer to fig. 17.</p>	<p>1 FM muting/mode switch to "on/auto".</p> <p>2 Adjust VR302 so that R output is minimized when stereo modulator is in L (Lch.modulation) mode and that L output is minimized in R mode.</p>

ALIGNMENT POINTS




[Fig. 14]




A - B, D - E: Stereo OFF Position.
 B - D: Stereo ON Position
 (Indicator Lighting).
 C: Adjust Point of Pilot Circuit.

[Fig. 16]



AF output wave form


[Fig. 15]



Low Pass Filter
 $f_c = 15\text{kHz} \sim 19\text{kHz}$

[Fig. 17]


BLOCK DIAGRAM



DIAL CORD INSTALLATION GUIDE


* For threading a fresh cord, proceed as follows.

1. Prepare a fresh cord more than 180cm (70-15/16") in length.
2. Bring the variable capacitor into a state where the drum is completely turned to the right (maximum capacity and lowest frequency for the variable capacitor.)
3. Direct the cord in the order from 1 to 10.
4. Stretch the cord in such a tension as the spring length is elongated by 1.5 times that of the original state.
5. Fix the knot of the cord with the adhesive.




BLOCK DIAGRAM OF IC'S


- This is the basic block diagram of the inside circuit of IC. In an actual circuit, there may be sometimes idle terminals or some different functions other than the basic circuit.




IC101 (AN278)
FM IF amplifier




IC102 (AN7001)
AM converter, FM IF amplifier
FM detector & stereo decoder
(MPX)




IC103, 801 (AN6551)
Operation amplifier




IC104 (AN6876)
FM AM signal indicator driver




IC301 (AN6136)
AF muting




IC401, 402 (SVITAK7322P)
Equalizer amplifier




IC601, 602 (AN7060F)
Differential amplifier



IC603, 604 (SVISTK1050K)
Power amplifier



IC802, 803 (AN6875)
LED comparator




IC901 (SVITA7317P)
Speaker protection operation amplifier

PRINTED CIRCUIT BOARD WIRING VIEW

(Tone, main amplifier, power supply and speaker protection circuit board)

Ground (Earth) Lines




Notes:


1. S1-1 ~ S1-8: Selector switch in "FM" position.
① AM → ② FM → ③ phono → ④ AUX
2. S2-1, S2-2: Tape monitor switch in "SOURCE" position.
source → tape 2
3. S3-1, 3-2: Tape monitor switch in "SOURCE" position.
source ← tape 1
4. S4-1 ~ S4-3: FM muting mode switch "ON/FM AUTO" position.
on/FM auto → off/FM mode
5. S5-1, 5-2: Loudness switch in "OFF" position.
off → on
6. S6-1 ~ S6-4: Boost/filter switch (high) in "OFF" position.
① high boost → ② off → ③ high filter
7. S7-1 ~ S7-4: Boost/filter switch (low) in "OFF" position.
① low boost → ② off → ③ low filter
8. S8: Power display range selector switch in "X1" position.
① X0.1 → ② X1 → ③ off
9. S9: Speaker selector switch in "MAIN" position.
① remote → ② main → ③ main + remote
10. S10: Power source switch in "ON" position.
11. Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (high-impedance) with the chassis taken as standard. Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.
- Not apply signal to set and muting switch to OFF condition.
- AM signal reception.
12. ➡ AF signal lines ➡ FM signal lines ➡ AM signal lines.

Shorting Switch

This unit uses a shorting switch. As illustrated below, the circuit is shorted to the next circuit without being opened. In the circuit diagram, the shaded area represents the common terminal.




An example of circuit diagram

**TERMINAL GUIDE OF TRANSISTORS AND IC'S**

AN278, AN6551	3SK73	AN6876, AN6136, AN7160 AN6875	SVITA7322P	SVISTK1050K
SVITA7317P	2SA1123/2SC928, 2SC1507, 2SA564, 2SC1077, 2SC1675, 2SC1674	2SD762		AN7001

SCHEMATIC DIAGRAM MODEL SA-101:

(This schematic diagram may be modified at any time with the development of new technology.)



10 9 8 7 6 5 4 3 2 1 11 12 13 14 15 16 17 18 19 20