marantz			15-May2003	Model: SR5300,SR6300	
			1 / 1	REF.NBR: MZ03-019	
SERVICE BULLETIN		Subject:			
Circulation:	Application:	1. Modify a part of the indication on display. 2. Cirrus DSP code change Int.ref:			
x for information customer complaint in case of service mandatory	See Below				

[PHENOMENON]

1. A part of the modification item of SETUP MAIN MENU is the following.

OLD NEW
PL2 → PLII

DTS ES → DTS ES Matrix/Diacrete
Neo6 → Neo:6

2. The problem of Speaker Distance center delay is modified.

[SOLUTION]

Replace MICRO PROCESSOR IC107 on the MAIN PCB and IC704 on the DSP PCB. MICRO PROCESSOR version becomes V021125 01

[NECESSARY PART]

	IC107 IC704	*HU100700R *HC108450R	(CXP740010 (M27W401-80B6	Factory part no. J020740010173) Factory part no. J080493260030)
Old part POS.NO	IC107	*HU100610R	(CXP740010	Factory part no. J020740010163)
POS.NO	IC704		(M27W401-80B6	Factory part no. J000274010010)

[REMARKS]

This improvement has been done in the production as follows.

the serial no.MZ010307005811 and after (SR5300/N1B)

the serial no.MZ010307004544 and after (SR5300/N1G)

the serial no.MZ010307005811 and after (SR5300/U1B)

the serial no.MZ010308004696 and after (SR5300/K1G)

the serial no.MZ010308002489 and after (SR6300/N1B)

the serial no.MZ010308002019 and after (SR6300/N1G)

the serial no.MZ010309001808 and after (SR6300/K1G)

marantz.			15-May-2003	Model SR5300/SR6300	
			1/1	REF.NBR:MZ03-007	
SERVICE BULLETIN		Subject:			
Circulation:	Application:	Abnormal noise from speaker			
x for information customer complaint in case of service mandatory	See below				
		Int.ref:			

[PHENOMENON]

Abnormal noise appears from speaker after 10 minutes or so with digital input

[SOLUTION]

Replace DSP IC CS493263(IC709) to new type one (Parts No. *HC107260R).

The countermeasure needs to apply to this claim only.

[REMARKS]

New IC has been applied in the production after the following serial number and after.

SR5300/N1G: MZ000241001962 and later SR5300/N1B: MZ000241002811 and later SR5300/U1B: MZ000242002611 and later SR5300/A1B: MZ000242000326 and later SR5300/K1G: MZ000242000979 and later SR6300/N1G: MZ000241000987 and later SR6300/V1B: MZ000241001139 and later SR6300/U1B: MZ000241000862 and later SR6300/K1G: MZ000242000361 and later