



Service Information 541/541i

PROBLEM: *You may have a complaint about an odour coming from the cd player after it has been turned on for a while.*

CAUSE: *The rubber pad securing the toroid transformer is warming up slightly and emitting an odour from the unit.*

SOLUTION: *Replace the existing rubber pad with a new pad. The part number for this new pad is C541/C541I TRANS PAD. The existing pad will in no way have any effect on the transformer's performance or safety issues, aside from this odour. The new pad when installed will not have this odour.*

PRODUCTION:

The serial numbers of the affected models are C541- G18C54108001 - G1XC54110600

C541i- G1ZC541I00001 - G1ZC541I01800

Contact:

NAD Electronics International
633 Granite Court
Pickering, ON Canada L1K 3K1
Voice: 905-831-0799 FAX 905-837-6357
www.nadelectronics.com